
SHARP

SERVICE MANUAL SERVICE-HANDBUCH

S76L8VC-M23SM



VHS VIDEO CASSETTE RECORDER

VHS VIDEO-CASSETTENRECORDER



VC-M231SM/M431SM

MODELS VC-M23SM/M231SM MODELLE VC-M43SM/M431SM

In the interests of user-safety (Required by safety regulations in some countries) the set should be restored to its original condition and only parts identical to those specified should be used.

Im Interesse der Benutzersicherheit (gemäß den Sicherheitsvorschriften in einigen Ländern) muß dieses Gerät stets wieder in den Originalzustand versetzt werden. Es sind ausschließlich Ersatzteile gemäß Spezifikation zu verwenden.

CONTENTS —		INHALT	
F	age		Seite
1. SPECIFICATIONS	3	1. TECHNISCHE DATEN	3
2. DISASSEMBLY AND REASSEMBLY	4	2. AUSBAU UND WIEDERZUSAMMENBAU	56
3. FUNCTION OF MAJOR MECHANICAL		FUNKTIONEN DER WICHTIGSTEN	
PARTS	7	MECHANISCHEN TEILE	59
4. ADJUSTMENT, REPLACEMENT AND		4. EINSTELLUNGEN, AUSTAUSCH UND	
ASSEMBLY OF MECHANICAL UNITS	9	MONTAGE DER MECHANISCHEN TEILE	61
5. ELECTRICAL ADJUSTMENT	31	5. ELEKTRISCHE EINSTELLUNGEN	83
6. MECHANISM OPERATION FLOWCHART		ABLAUFDIAGRAMM ZUR LAUFWERKS-	
AND TROUBLESHOOTING GUIDE	37	FUNKTION UND FEHLERSUCHTABELLE	89
7. TROUBLESHOOTING	43	7. FEHLERSUCHE	95
8. BLOCK DIAGRAMS	109	8. BLOCKSCHALTBILDER	109
9. CIRCUIT DIAGRAM AND PWB		9. SCHALTPLAN UND	
FOIL PATTERN	117	PLATINENLEITERBILD	117
10. REPLACEMENT PARTS LIST	132	10. ERSATZTEILLISTE	132
11. EXPLODED VIEWS	145	11. EXPLOSIONSZEICHNUNGEN	145
12. PACKING OF THE SET	150	12. VERPACKUNG DES GERÄTES	150

SHARP CORPORATION

PRECAUTIONS IN PART REPLACEMENT

When servicing the unit with power on, be careful to the section marked white all over.

This is the primary power circuit which is live.

When checking the soldering side in the tape travel mode, make sure first that the tape has been loaded and then turn over the PWB with due care to the primary power circuit.

Make readjustment, if needed after replacement of part, with the mechanism and its PWB in position in the main frame.

- (1) Start and end sensors: Q851 and Q852 Insert the sensor's projection deep into the upper hole of the holder (LHLDZ1893AJ00). Referring to the PWB, fix the sensors tight enough.
- (2) Photocoupler RH-FX0005GEZZ: IC901 Refer to the symbol on the PWB and the anode marking of the part.
- (3) Cam switches A and B (RH-PX0238GEZZ): D852 and D853 Adjust the notch of the part to the white marker of the symbol on the PWB. Do not allow any looseness.
- (4) Take-up and supply sensors (RH-PX0252GEZZ): D855 and D854

 Be careful not to confuse the setting direction of the parts in reference to the symbols on the PWB. Do not allow any looseness.
- (5) Diode bridge (RH-DX0083GEZZ): D901

 Adjust the + marking of the part to the symbol's cathode marking on the PWB.

VORSICHTSMASSNAHMEN BEIM AUSWECHSELN VON TEILEN

Bei Wartungsarbeiten am Gerät mit eingeschalteter Stromversorgung ist besonders auf den weiß markierten Abschnitt zu achten. Es handelt sich um den Primärstromkreis, der spannungsführend ist.

Beim Überprüfen der Lötseite im Bandlaufmodus muß zunächst sichergestellt werden, daß das Band eingezogen wurde. Dann die Platine unter entsprechender Beachtung des Primärstromkreises umdrehen.

Eine ggf. erforderliche Neueinstellung nach dem Auswechseln von Teilen durchführen, während sich Bandlaufwerk und Platine im Hauptrahmen befinden.

- (1) Start- und Endsensoren: Q851 und Q852 Das vorstehende Teil des Sensors tief in die obere Öffnung des Halters (LHLDZ1893AJ00) führen. Die Sensoren in Bezug auf die Platine ausreichend befestigen.
- (2) Fotokoppler RH-FX0005GEZZ: IC901
 Siehe Symbol auf der Platine und Anodenmarkierung
 des Teils.
- (3) Nockenschalter A und B (RH-PX0238GEZZ): D852 und D853 Die Kerbe des Teils mit der weißen Markierung des Symbols auf der Platine ausrichten. Die Teile müssen fest sitzen.
- (4) Aufwickel- und Abwickelsensoren (RH-PX0252GEZZ): D855 und D854

 Darauf achten, daß die Ausrichtung der Teile in Bezug auf die Symbole auf der Platine nicht vertauscht wird. Die Teile müssen fest sitzen.
- (5) Diodenbrücke (RH-DX0083GEZZ): D901 Die Markierung + des Teils mit der Kathodenmarkierung des Symbols auf der Platine ausrichten.

1. SPECIFICATIONS

1. TECHNISCHE DATEN

Format:

VHS PAL standard

Video recording system:

Two rotary heads,

helical scan system

Video signal:

PAL/SECAM colour

and B/G signals, 625 lines

Recording/playing time:

240 min max, with SHARP E-240 tape (SP)

480 min max. with SHARP E-240 tape (LP) (VC-M43SM/M431SM)

Tape width:

12.7mm

Tape speed:

23.39 mm/s (SP)

11.70 mm/s (LP)

(VC-M43SM/M431SM) 75 ohm unbalanced

Antenna:

VHF Channel E2-S41

Receiving channel:

UHF Channel E21-E69

RF converter output signal:

UHF Channel E30-E39

(preset to CH E36) AC230V, 50Hz

Power requirement: Power consumption: Operating temperature:

Approx. 16 W 5°C to 40°C -20°C to 60°C

Storage temperature: Weight:

Approx. 3.5 kg

Dimensions:

380 mm (W) x 290.5 mm (D)

x 93 mm (H)

VIDEO

Input: Output:

1.0 Vp-p, 75 ohm 1.0 Vp-p, 75 ohm

S/N ratio:

45 dB

Horizontal resolution:

250 lines

AUDIO Input: 0 dBs = 0.775 VrmsLine: -3.8 dB, 47k ohm Line: -3.8 dB, 1k ohm

Output: S/N ratio:

42 dB

Frequency responce:

80 Hz ~ 10 kHz

Accessories included:

75 ohm coaxial cable

Operation manual Infrared remote control

Battery (2pcs.)

Format:

VHS-, PAL-Norm

Video-

Schrägspuraufzeichnung mit

Aufzeichnungssystem: Videosignal: zwei rotierenden Köpfen PAL/SECAM-Farb- und

B/G-Weißsignale, 625 Zeilen

Aufzeichnungs-/

240 Minuten max.,

Wiedergabezeit:

mit SHARP E240-Band (SP)

480 Minuten max., mit SHARP E-240 Band (LP) (VC-M43SM/M431SM)

12,7 mm

Bandgeschwindigkeit:

Bandbreite:

23,39 mm/s (SP)

11,70 mm/s (LP) (VC-M43SM/M431SM)

Antenne:

75 Ohm unsymmetrisch VHF-Kanäle E2-S41

Empfangskanäle:

UHF-Kanäle E21-E69

Ausgangssignal

UHF-Kanal E30-39

HF-Wandler:

(voreingestellt auf Kanal E36) Wechselsspannung AC230 V, 50 Hz

Stromversorgung: Leistungsaufnahme:

Ca. 16 W 5°C bis 40°C

Betriebstemperatur: Lagerungstemperatur:

-20°C bis 60°C

Gewicht: Abmessungen;

Ca. 3,5 kg 380 mm (B) x 290,5 mm (T)

x 93 mm (H)

VIDEO

Eingang: Ausgang:

1,0 Vs-s, 75 Ohm 1,0 Vs-s, 75 Ohm

Verhältnis Signal/Geräusch:

45 dB

Horizontale Auflösung:

250 Zeilen 0 dB = 0,775 Veff

AUDIO Eingang: Ausgang:

Direkteingang: -3,8 dB, 47 kOhm Direktausgang: -3,8 dB, 1 kOhm

Signal/Rausch Abstand:

42 dB 80 Hz ~ 10 kHz

Frequenzwiedergabe: Mitgeliefertes Zubehör:

75 Ohm-Koaxialkabel Bedienungsanleitung

Infrarot-Fernbedienung Batterie (2 Stück)

As part of our policy of continuous improvement, we reserve the right to alter design and specifications without notice.

Note:

The antenna must correspond to the new standard DIN 45325 (IEC 169 - 2) for combined UHF/VHF antenna with 75 ohm connector.

Im Sinne der ständigen Verbesserung behalten wir uns das Recht vor, äußere Aufmachung und technische Daten ohne Vorankündigung zu ändern.

Hinweis:

Die Antenne muß der neuen DIN-Norm 45325 (IEC 169-2) für VHF-UHF-Kombiantennen mit 75 Ohm-Anschluß entsprechen.

2. DISASSEMBLY AND REASSEMBLY

2-1 DISASSEMBLY OF MAJOR BLOCKS

TOP CABINET

: Remove 4 screws ①

BOTTOM PLATE

Remove 2 screws 2 and 6 hooks 3.

FRONT PANEL: Remove shuttle switch @ Remove 2

screws (5) and 7 clips (6).

OPERATION PWB: Remove 1 screw 7 and take it out of


connector (8).

MAIN PWB ASSEMBLY

MECHANISM/ : Remove 1 screw @, 2 screws @, 2 screws (1) and 1 connector (1). Lift the antenna terminal cover and take the

assembly out of the main frame.

alle programme de la Programme



2-2 DISASSEMBLING THE MECHANISM/MAIN PWB ASSEMBLY

ANTENNA TERMINAL COVER case. MECHANISM

CHASSIS/

: Remove 3 screw (3). Remove the shield

: Remove 3 FFCs (1) and 2 harnesses (6). Be carefull not to confuse the top and

CASSETTE HOUSING


ASSEMBLY

bottom of the FFC.Remove 1screw ® from behind the main PWB.

Remove the mechanism chassis assembly straight up from the main PWB with care not to damage theirs urrounding parts.

: Remove 2 screws 1.

CASSETTE HOUSING



2-3 PRECAUTIONS IN REASSEMBLING

MOUNTING THE CASSETTE CONTROLLER

THE RESERVE OF THE PARTY. near initial setting is indispensable before placing the cassette controller in the mechanism. The initial setting is made in two ways; electrical and mechanical.


aper out of an immisdering the

0:488 t-114

ALCHARTHA

Electrical setting:

Make a short-circuit between TP703 and TP704 and be sure that the mechanism is back to its initial setting position (*1). Now place the cassette controller in position. (This method is used when the mechanism has been already set on its PWB.)



Mechanical setting:

Turn the loading motor's pulley feed gear using a screwdriver and be sure that the mechanism is back to its initial setting position (*1). Now place the cassette controller in position. (This method is applicable for the mechanism alone.)

COUPLING THE MECHANISM TO THE PWB

Match the mechanism's projections with the two symbols (round reference and oval sub-reference) on the main PWB, Place the mechanism straight down in position with due care so that the mechanism chassis's outer edges should not damage any parts nearby.


Tighten up the two screws (one for fixing the mechanism and the head amplifier shield, the other on the main PWB's soldering side and located near the loading motor) to fix the mechanism and main PWB. Reconnect the FFC cables (AN and AS) and harness (AB) between the mechanism and main PWB.

Parts to pay attention to:


Start and end sensors Q851 and Q852

S851 Rec tip switch


Take special care of the AE connector (board to board) between the mechanism and main PWB.



3. FUNCTION OF MAJOR MECHANICAL PARTS (TOP VIEW)



No.	Function	No.	Function
1.	Full erase head ass'y Erase the old recording on the tape in the recording mode.	13.	Reverse guide lever ass'y Pulls out the tape and controls the tape drive train height with the upper and lower guides.
3.	Tension arm ass'y Detects the tension of tape while running, and brakes the supply reel disk via the tension band.	16.	Pinch roller lever ass'y Press-fits the tape to the capstan during tape
7.	Sup Main brake ass'y Brakes the supply reel disk to prevent tape slack-		running.
	ening when the unit is stopped in fast forward or rewind mode.	18.	Loading motor A motive power which drives the mechanism. It
9.	Take-up main brake ass'y Brakes the take-up reel disk to prevent tape slackening when the unit is stopped in fast for- ward or rewind mode.		transmits the power to the master cam and cas- sette housing control assembly.



No.	Function	No.	Function
1.	Slow brake lever Gets in contact with the capstan D.D. motor linking to the master cam in the slow still mode, and brakes it to a certain degree.	6.	Limiter pulley ass'y Transmits the power of the capstan D.D. motor to the reel disk via the drive idler.
	and brakes it to a certain degree.	8.	Shifter
3,	Capstan D.D. motor A motive power which runs the tape. It transmits	:	Transmits the operation of the master cam to break ass'y, loading gear, tension arm and clutch lever.
H com	the power via the Drive belt.	9.	Take-up Loading gear
4.	Drive belt Transmits the power to run the tape to the Limiter pulley.		Shifts the take-up pole base and guide roller via the loading gear T, and applies the tape around the drum assembly, as well as transmits the power to the loading gears.

4. ADJUSTMENT, REPLACEMENT AND ASSEMBLY OF MECHANICAL UNITS

Here we will describe a relatively simple service work in the field, not referring to the more complicated repairs which would require the use of special equipment and tools (drum assembly replacement, for example).

We are sure that the easy-to-handle tools listed below would be more than handy for periodical maintenance to keep the machine in its original working condition.

TOOLS NECESSARY FOR ADJUSTING THE MECHANICAL UNITS

The following tools are required for proper service and satisfactory repair.

No.	Jig Item	Part No.		Configuration	Remarks
1	Reel Disk Height Adjusting Jig	JiGRH0002	BR	Q	These Jigs are used for checking and
2	Master Plane Jig	JiGMP0001	вү	(6.0)	adjusting the reel disk height.
4	Torque Gauge (90g)	JiGTG0090	СМ		
.,	Torque Gauge (1.2kg)	JiGTG1200	CN		These Jigs are used for checking and adjusting the torque of take-up and sup-
5	Gauge Head	JiGTH0006	AW		ply reel disks.
6	Cassette Torque Meter	JiGVHT-063	CZ		This cassette torque meter is used for checking and adjusting the torque of take-up for measuring tape back tension.
7	Tension Gauge (300g)	JiGCG0300	BF		There are two gauges used for the ten-
	Tension Gauge (2.0kg)	JiGSG2000	BS	1	sion measurements, 300 g and 2.0kg.
8	Hex Wrench (0.9mm)	JIGHW0009	AE		These Jigs are used for loosening or
	Hex Wrench (1.5mm)	JiGHW0015	ΑE		tightening special hexagon type screws.
9	Alignment Tape (PAL)	VROCPSV	ск		These tapes are especially used for electrical fine adjustment.
11	Tension Gauge Adapter	JiGADP003	вк		This Jig is used with the tension gauge. Rotary transformer clearance adjusting jig.
12	Special Bladed Serewdriver	JiGDRiVERH-4	AP		This screwdriver is used for adjusting the guide roller height.

No.	Jig Item	Part No.		Configuration	Remarks
14	Torque Driver		СВ		This is used to screw down resinmade parts: the specified torque is 5kg.
15	M3 type 5.5 mm square box driver for reverse guide	JiGDRiVER11055		n iko	This Jig is used for height adjustment of the reverse guide. (for reverse guide height adjustment).
17	Reverse Guide Height Adjust- ing Jig	JiGRVGH-F18	BU		This Jig is used for height adjustment of the reverse guide.
18	Gear Driver	JiGDRiVER-6	вм	(F) 1.00384.04 (F) 1.00384.04	For X value adjustment

MECHANICAL PARTS REQUIRING PERIODICAL INSPECTION

Use the following table as a guide to maintain the mechanical parts in good operating condition.

Maintained Parts	500 hrs.	1000 hrs.	1500 hrs.	2000 hrs.	Possible symptom encountered	Remarks
Guide roller ass'y			□	0		Abnormal rotation or significant vibration requires replacement.
Sup Guide Shaft					Lateral noises Head occasion-	
Retaining guide					ally blocked	Clean tape contact part with the specified cleaning liquid.
Slant pole				0		
Upper and lower drum ass'y		00	0	00	Poor S/N ratio, no colour Poor flatness of the envelope with alignment tape	Clean tape contact area with
Full-erase head				0	Poor colour, beating	the specified cleaning liquid.
A/C head				0	Low or distorted audio	
Capstan D.D. Motor				0	No tape running, uneven colour	
Pinch roller				0	No tape running, tape slack	Clean rubber and rubber con-
Drive belt				0	No tape running, tape slack, no fast forward/rewind motion	tact area with the specified cleaning liquid.
Tension band ass'y				0		
Loading Motor				0	Cassette not loaded or unloaded	
Idler Wheel ass'y				0	No tape running	
Limiter pulley ass'y				0		2
Supply/take-up Main brake levers				0	Tape slack	·
AHC (Auto Head Cleaner) (VC-M43SM/M431SM)		0		0		Replace the roller of the cleaner when it wears down. Just change the AHC roller assembly for new one.

☐: Cleaning (For cleaning, use a lint-free cloth dampened with pure isopropyl alcohol).

 Δ : Oil refilling (The indicated point should be lubricated with high quality spindle oil every 1000hrs).

If the reading is out of the specified value, clean or replace the part.

REMOVAL AND REASSEMBLY OF CASSETTE HOUSING CONTROL ASSEMBLY

• Removal

- 1. Set the cassette ejected condition in the cassette eject mode.
- 2. Unplug the recorder from the main source.
- 3. Follow the procedures below in the specified order.
 - a) Remove the cassette housing installation screws 1.
 - b) Slide and pull out the cassette housing control assembly upward.




Figure 4-2.

- 2. Follow the procedures for removal in the reverse order. **Notes:**
- ① In using a magnet screw driver, be sure to keep it away from the A/C head, FE (Full Erase) head, and the drum.
- ② In removal and reassembly, take care not to hit the cassette housing control-assembly and tools against the guide pin, drum, or the like there about.
- 3 Load the cassette once onto the cassette housing control assembly after reassembly.

TO RUN A TAPE WITHOUT THE CASSETTE HOUSING CONTROL ASSEMBLY

- Be sure to make a short-circuit between TP5005 and TP5006, both located at the left on your side on the main PWB before turning on the power.
- 2. Plug in the power cord.
- 3. Turn on the power switch.
- 4. Open the lid of a cassette tape by hand.
- 5. Hold the lid with two pieces of vinyl tape.
- 6. Set the cassette tape in the mechanism shassis.
- Stabilize the cassette tape with a weight (500g) to prevent floating.
- 8. Perform running test.




Figure 4-1.

Reassembly

1. Before installation of the cassette housing control assembly, make a short-circuit between TP5005 and TP5006, both located at the left on your side on the main PWB. Plug in the power cord. The cassette control drive gear starts and stops just when the big face gear shows in the mechanism chassis window. Engage the tooth 2 of the casecon drive gear with the tooth 3 of the cassette control drive angle as shown in Fig.4 - 2, to position the cassette control on the mechanism chassis.




Figure 4-3.


Note:

The weight should not be more than 500g.

REPLACEMENT AND HEIGHT CHECKING AND ADJUSTMENT OF REEL DISKS

- Removal (Supply and Take-up reel disks)
- 1. Remove the cassette housing control assembly.
- 2. Pull the tension band out of the tension arm.
- Release the supply/take-up auxiliary brake lever by hand, which makes unnecessary removal of the supply main brake and the take-up main brake.
- Open the hook at the top of the reel disk, and remove the reel disk.

<In the EJECT or UL STOP mode>






Figure 4-4.

Reassembly (Supply reel disk)

- 1. Clean the reel disk shaft and apply oil to it.
- Align the phase of the reel disk to that of the reel relay gear, and install a new supply reel disk onto the shaft.
- Replace the tension band around the supply reel disk, and insert it into the hole of the tension arm with the supply auxiliary brake lever released.
- 4. Check the reel disk height.

Notes:

- Take enough care not to deform the tension band during installation of the supply reel disk.
- ② Be careful not to damage the supply main brake and the reel relay gear.

· Reassembly (Take-up reel disk)

- 1. Clean the reel disk shaft and apply oil to it.
- Release the take-up auxiliary brake lever to align the phase of the reel disk to that of the reel relay gear and to install a new take-up reel disk onto the shaft.
- Check the reel disk height and reassemble the take-up main brake.


Note:

Take care not to damage the take-up main brake.

* After reassembly, check the video search rewind back tension (see page 16), and check the brake torque (see page 18).

Height checking and adjustment Note:

Place the master plane onto the mechanism unit, taking care not to hit the drum (see Figure 4-6).



Set the master plane releasing the reverse guide by a finger.

Note:

When the tension band is pressed in the direction of the arrow for removal, the catch is hard to be deformed.



Figure 4-5.




Figure 4-6.

 Check that the reel disk is lower than part A but higher than part B. If the height is not correct, readjust the reel disk height by changing the poly-slider washer under the reel disk.

Note:

Whenever replacing the reel disk, perform the height checking and adjustment.




Figure 4-7.

CHECKING AND ADJUSTMENT OF TAKE-UP TORQUE IN FAST FORWARD MODE

- Remove the cassette housing control assembly.
- Make a short-circuit between TP5005 and TP5006, both located at the left on your side on the main PWB. Now turn on the power.

Setting

- Set a torque gauge to zero on the scale. Place it on the takeup reel disk.
- Press the FF button to set the mechanism to the fast forward mode.
- To calculate the remaining capacity of the play back mode, slowly rotate the supply reel disk, and then shift it into the forward mode.

Checking

- 1. Turn the torque gauge slowly (one rotation every 2 to 3 seconds) by hand in the take-up direction.
- Check to see if the take-up torque is higher than 69 mN·m (700 gf-cm).




Figure 4-8.

• (TAdjustment)

- If the take-up torque is putside the range, clean the capstan D.D. motor pulley, drive belt and limiter pulley with cleaning liquid, then recheck the torque.
- 2. If the take-up torque is still out of range, replace the drive belt.
- 1. Hold down the torque gauge so that it may not fly off.
- When checking the take-up torque, do not keep the reel disk locked for a longer time.

CHECKING AND ADJUSTMENT OF TAKE-UP TORQUE IN REWIND MODE

- Remove the cassette housing control assembly.
- Make a short-circuit between TP5005 and TP5006, both located at the left on your side on the main PWB. Now turn on the power.

Setting

- Set a torque gauge to zero on the scale. Place it on the supply reel disk.
- Press the REW button to set the mechanism to the rewind mode.
- To calculate the remaining capacity, slowly rotate the take-up reel disk, and then shift it into the rewind mode.

Checking

- 1. Turn the torque gauge slowly (one rotation every 2 to 3 seconds) by hand in the take-up direction.
- 2. Check to see if the take-up torque is higher than 69 mN·m (700 gf-cm).




Figure 4-9.

Adjustment

- If the take-up torque is outside the range, clean the capstan D.D. motor pulley, drive belt and limiter pulley with cleaning liquid, then recheck the torque.
- 2. If the take-up torque is still out of range, replace the drive belt.
- 1. Hold down the torque gauge so that it may not fly off.
- 2. When checking the take-up torque, do not keep the reel disk locked for a longer time.

CHECKING AND ADJUSTMENT OF TAKE-UP TORQUE IN PLAYBACK MODE

- 1. Remove the cassette housing control assembly.
- Make a short-circuit between TP5005 and TP5006, both located at the left on your side on the main PWB. Now turn on the power.
- 3. Open the lid of the cassette torque meter, and hold it with two pieces of vinyl tapes.
- 4. Load the cassette torque meter into the unit.
- 5. Put the weight (500g) on the cassette torque meter.
- 6. Press the REC button to put the unit in REC mode.

CHECKING AND ADJUSTMENT OF TAKE-UP TORQUE IN VIDEO SEARCH REWIND MODE

- Remove the cassette housing control assembly.
- Make a short-circuit between TP5005 and TP5006, both located at the left on your side on the main PWB. Now turn on the power.

Setting

- 1. Push the PLAY button to place the ass'y in the playback mode.
- 2. Push the REW button to place the ass'y in the video search rewind mode.

Checking

1. Place the torque gauge on the supply reel disk, and turn it counterclockwise very slowly (one rotation every 1 to 2 seconds) and check that the torque is within the set value 14.0 ± 3.9 mN·m (144 ± 40 gf·cm).

Set value SP 12 \pm 3.8mN·m (122 \pm 39gf·cm)(VC-M23SM/M231SM) Set value LP 10.5 \pm 3.8mN·m (107 \pm 39gf·cm)(VC-M43SM/M431SM)




Figure 4-10.




Figure 4-11.

Checking

- 1. Check that the torque is in the range of 12 \pm 3.8mN·m (122 \pm 39gf·cm) (VC-M23SM/M231SM) or 10.5 \pm 3.8mN·m (107 \pm 39gf·cm) (VC-M43SM/M431SM).
- The torque fluctuates due to the rotational deviation of the limiter pulley ass'y. Use the center of the fluctuation as the value.
- Place the ass'y in the SP (VC-M23SM/M231SM) or LP (VC-M43SM/M431SM) record mode, and check that the take-up torque is within the range.

Adjustment

If the take-up torque in the playback mode is outside the range, replace the limiter pulley ass'y.

Note:

Stabilize the cassette torque meter to prevent floating.

Note:

Set the torque gauge securely on the supply reel disk. If it is not secure, the measurement will be incorrect.

Adjustment

If the take-up torque in video search rewind mode is outside the range, replace the limiter pulley ass'y.

Note

The torque fluctuates due to the rotational deviation of the limiter pulley ass'y. Use the center of the fluctuation at the value.

CHECKING THE VIDEO SEARCH REWIND BACK TENSION FOR BURN WE SUCKED!

- Remove the cassette housing control assembly acras-
- . Make a short-circuit between TP5005 and TP5006 both located at the left on your side on the main PWB. Now turn on the power. a ward affects
- Checking

Other projection springing of a

1. Push the PLAY button to place the ass'y in the playback mode.

particula.

Arrest briggs

- 2. Push the rewind button to place the ass'y in the video search rewind mode.
- 3. Place the torque gauge on the take-up reel disk, and turn it counterclockwise very slowly (one rotation every 2:to 3-seconds) and check that the torque is within the set value 3:0±1mN·m (31±10gf/cm).




Figure 4-12.

Notes:

- Set the torque gauge securely on the take-up reel disk. If it is not secure, the measurement will be incorrect.
- Measure the torque applying the torque gauge's weight.

CHECKING THE PINCH ROLLER PRESSURE

- Remove the cassette housing control assembly.
- Make a short-circuit between TP5005 and TP5006, both located at the left on your side on the main PWB. Now turn on the power.
- Checking

William County of the Contract

CNUBBLE CONTRACTOR SECTION OF

Production of the Contract

Push the PLAY button to place the ass'y in the playback mode.





Figure 4-13.

- 1. Detach the pinch roller from the capstan shaft.
- 42. Set the tension gauge by hooking the tension gauge adapter onto the pinch roller shaft.
 - 3. Gradually release the pressure to allow the pinch roller to touch the capstan shaft. When the pinch roller just touches the capstan shaft, read the indication on the gauge.
 - 4. Check that the reading of the tension gauge is in the range of 900 to 1200 g.

CHECKING AND ADJUSTMENT OF TENSION POLE POSITION


- Remove the cassette housing control assembly.
- Make a short-circuit between TP5005 and TP5006, both located at the left on your side on the main PWB. Now turn on the power.
- Setting
- 1. Open the lid of cassette tape (E-180), and hold it with two pieces of vinyl tapes.
- 2. Load the cassette tape into the unit.
- 3. Put the weight (500g) on the cassette tape.
- 4. Make the adjustment with the beginning of a E-180 tape.



1. Set a cassette tape, press the REC button and get the tape loaded. Now check the tension pole position.

Stational Committee

2. Visually check to see if the center of the tension pole is in alignment with the line 1.3 mm left of the center line of the sup guide shaft. Readjust as required in the following steps.



1.3 Make the adjustment with the beginning of a E-180 tape. Figure 4-15.

① If the center of tension pole is at the left from the dotted line:




Figure 4-16.

Put a bladed screwdriver into the tension pole ADJUSTER and turn it clockwise.

② If the end is at the right from the dotted line:




Figure 4-17.

Put a bladed screwdriver into the tension pole adjuster to turn it counter-clockwise.

- 3 Adjustable range of the tension pole ajuster.
- 4 Adjustable range of tension pole adjusting cam.




Figure 4-18.

Adjust the tension pole adjuster so that the circle mark on the cam be within 90° left and right.

CHEKING AND ADJUSTMENT OF RECORD/ PLAYBACK BACK TENSION

- · Remove the cassette housing control assembly.
- Make a short-circuit between TP5005 and TP5006, both located at the left on your side on the main PWB. Now turn on the power.
- Setting
- 1. Open the lid of cassette torque meter, and hold it with two pieces of vinyl tapes.
- 2. Load the cassette torque meter into the unit.
- 3. Put the weight (500g) on the cassette torque meter.




Figure 4-19.

- Checking
- 1. Push the REC button to place the unit in the record mode.
- 2. Check that the back tension indicated by the gauge is within the set range 31 to 38 g·cm.

Notes:

- Make sure that the video cassette tape is over the retaining guide.
- 2. Make sure that the tape is not slack nor damaged at either end.

1. If the reading of the cassette torque meter is less than specified, move the tension spring hook toward Advantage.

Administra of the parties of the

2. If the reading of the cassette torque meter is more than specified, move the tension spring hook toward B.





Figure 4-20.

and the second of the control of the second of the control of the

CHECKING THE BRAKE TORQUE

· Checking the brake torque at the supply side



CCW: 5.9~9.8mN·m (60~100gf·cm) CW: 10~32mN·m (100~330gf·cm)

Figure 4-21.

- · Remove the cassette housing control assembly.
- Make a short-circuit between TP5005 and TP5006, both located at the left on your side on the main PWB. Now turn on the power.

Setting

- Set a torque gauge to zero on the scale. Place it on the supply real disk
- 2. Switch from the FF mode to the STOP mode.
- 3. Disconnect the AC power plug.

Checking

Rotate the torque gauge (approx. one revolution per 2 seconds) in the clockwise (CW) direction and counterclockwise (CCW) direction of the supply brake so that the reel disk and the indicator of the torque gauge rotate at an equal rate.
 Check that the values are within the range of CW direction = 10 ~32mN·m (100~330gf·cm), CCW direction = 5.9~9.8mN·m (60 ~100gf·cm), and that the brake torque in the CW direction is at least twice as high as that in the CCW direction.

Checking the brake torque at the take-up side




Figure 4-22.

- · Remove the cassette housing control assembly.
- Make a short-circuit between TP5005 and TP5006, both located at the left on your side on the main PWB. Now turn on the power.

Setting

- Set a torque gauge to zero on the scale. Place it on the takeup reel disk.
- 2. Switch from the FF mode to the STOP mode.
- 3. Disconnect the AC power plug.

Checking

- 1. Rotate the torque gauge (approx. one revolution per 2 seconds) in the clockwise (CW) direction and counterclockwise (CCW) direction of the take-up brake so that the reel disk and the indicator of the torque gauge rotate at an equal rate. Check that the values are within the range of CCW direction= 9.8~34mN·m (100~340gf·cm), CW direction = 4~8.3mN·m (40~85gf·cm), and that the brake torque in the CCW direction is at least twice as high as that in the CW direction.
- Adjustment of the brake torque at the supply side and the take-up side
- If the supply or take-up brake torque is outside the range, clean the supply or take-up reel disk brake lever pad, then recheck the torque.
- If the supply or take-up brake torque is still outside the range, replace the main brake ass'y.

Note:

When the main brake is replaced, perform the height checking and adjustment of reel disks (see page 13), and the brake torque checking.

REPLACEMENT OF A/C (Audio/Control) HEAD

- 1. Remove the cassette housing control assembly.
- Place the unit in the unloading mode, and unplug the power cord.

Removal

- 1. Remove the screw (A) (B) (C) (D).
- Unsolder the A/C head PWB soldered to the A/C head assembly.

Notes:

- After replacement, be sure to perform the adjustment of the tape drive train (see page 21). Under any circumstances, avoid touching the head. Clean the head, if touched with your finger, with alcohol.
- Take care that the springs do not fly off when removing the screws (A) (B) (C).




Figure 4-23.

Replacement

- Solder the removed A/C head PWB onto a new A/C head assembly.
- Using the slide calipers, set 10.3 mm for the height of the A/C head arm (bottom surface) to the A/C head plate (screw area). (3 places)
 (See the figure below.)






Figure 4-24.

3. Align the left and of the gear of the A/C head arm to the mark on the chassis, and temporarily tighten the screws ① and ② to allow the A/C head arm to smoothly move.

(Reference: Temporary tightening torque: 0.2 N.m as prefer-





Figure 4-25.

Note:

Take care that he adjustment or height of the A/C head may vary during final tightening if the screws ① or ② is temporarily tightened to be loose.

[A/C head height rough adjustment]






Figure 4-26.

- ① Set the cassette tape to the mechanism chassis.
- ② Press the PLAY button to the put the unit in the playback mode.
- ③ Roughly adjust the height of the A/C head by turning the screw
 © until the tape is in the position shown below.




Figure 4-27.

Adjustment

Adjust the screw (©) visually so that the control head is visible 0.3 to 0.5mm below the bottom of the tape.

HEIGHT ADJUSTMENT OF REVERSE GUIDE

[Height adjustment of reverse guide]




Figure 4-28.

- ①.Remove open lever(Figure 4-29(a)).
- ②. In the tape load mode, make adjustment at the 13.38mm side first and then rotate the reverse guide adjuster nut by 1/10 turn counterclockwise.
- 3. Actually load the unit with a tape, put it in the play mode, and make sure the tape is free from wrinkles near the reverse guide.
- ①. Use a commercially available box driver to turn the height adjusting nut.




Figure 4-29 (a).




Figure 4-29 (b).

ADJUSTMENT OF TAPE DRIVE TRAIN

- 1. Remove the cassette housing control assembly.
- 2. Make a short-circuit between TP5005 and TP5006, both located at the left on your side on the main PWB. Now turn on the power.
- Check and adjust the position of the tension pole. (See page 16.)
- 4. Check and adjust the video search rewind back tension. (See page 16.)
- 5. Set the A/C head. (See page 19.)
- 6. Rough adjustment of tape drive train.
 - a) Connect the oscilloscope to the test point for PB CHROMA envelope output (TP301). Set the synchronism of the oscilloscope to EXT. The PB CHROMA signal is to be triggered by the head switching pulse (TP302).
 - b) Loosen the setscrew at the lower part of the guide roller, and adjust it with an adjusting screw driver (JiGDRIVERH-4) so that the guide roller turns smoothly. (Do not overloosen the setscrew, which causes insecurity of the guide roller.) (See Figure 4-30.)
 - c) Set the alignment tape (monoscope pattern) on the reel disk, and place the unit in the playback mode. (Place a 500 g weight on the cassette tape to prevent floating of the cassette tape.)




Figure 4-30.

Hexagon wrench

Guide roller

Figure 4-31.

d) In the X value adjustment mode (see the Electrical Adjustment), change the envelope waveform from MAX to MIN, and MIN to MAX by pushing the (+) or (-) tracking button, and check a flat response is obtained on the waveform.

Weight of 500g

- e) If a flat response cannot be obtained, roughly adjust the guide rollers on the supply side and take-up side using an adjusting screw driver until a flat response can be obtained.
- f) Tighten the screw (A) to eliminate wrinkles from the tape of the retain guide flange area.
 - Replace the tape to check the tape on the retain guide flange area for wrinkles.
 - (1) No wrinkle is present.
 - Turn the screw (A) clockwise to generate wrinkles on the tape at the flange area, and then back off the screw (A) as far as the wrinkles are just eliminated.
 - (2) Wrinkles are present.
 - Turn the screw (A) counterclockwise as far as the wrinkles are just eliminated.

Reference:

If the screw (A) is turned clockwise, wrinkles will be produced on the lower flange.

Notes:

- Place the tracking control in the center position, and adjust the X-position so that the PB envelope becomes maximum for easier rough adjustment of the tape drive train.
- In the rough adjustment, pay particular attention to the outlet side.




Figure 4-32.

Figure 4-33.




Figure 4-34.

- 7. Adjustment of A/C head height and azimuth
 - a) Connect an oscilloscope to the audio output terminal.
 - b) Using the alignment tape with linear audio pre-recorded signal of 1 kHz, adjust the screws (2) and (2) to maximize the audio output, and adjust the screw A to eliminate wrinkles from the tape at the retain guide flange. (Refer to P21-6-f.) Repeatedly adjust the screws B, C and A in this sequence until the audio output becomes the maximum. (1 to 3 times as ordinary)
 - c) Using the alignment tape which records a linear audio signal of 6 kHz, finally adjust the screw ® until the audio output becomes the maximum.

- 8. Adjustment of tape drive train and X-Position (Use the alignment tape VROGPSV₄): Asset 4.1. The second is a
- a) Connect the oscilloscope to the test points (TP301) for PB envelope output. Set the synchronism of the oscilloscope
 - The PB signal is to be triggered by the head switching pulse (TP302).
- b) Play back the tape drive train alignment tape.

part of the second

- c) Push the (+) or (-) button to change the envelope waveform from MAX to MIN, and MIN to MAX. Adjust the guide roller's height on the supply and take-up sides with an adjusting screw driver, to obtain an envelope waveform that is as flat as possible in
 - d) If the tape is above or below the helical lead, the PB waveform will take the shape shown in Figure 4-35.
 - e) Adjust for maximum flatness of the envelope as the step 6, e) in page 21.
 - f) Push the (+) or (-) tracking button to check that a flat response is obtained on the envelope waveform.

New York Control of the Control of t

with the marking the party of the first three party of the first three first

Commission of the second

	When the tape is ab	ove the helical lead.	When the tape is below the helical lead.		
	Supply side	Take-up side	Supply side	Take-up side	
Adjustment	Supply side guide roller rotated in clockwise direction (lowers guide roller) to flatten envelope.	Take-up side guide roller rotated in clockwise direction (lowers guide roller) to flatten envelope.	Supply side guide roller rotated in counterclock-wise direction (raises guide roller) to make the tape float above the helical lead. The supply side guide roller is then rotated in the clockwise direction to flatten the envelope.	Take-up side guide roller rotated in counterclock-wise direction (raises guide roller) to make the tape float above the helical lead. The take-up side guide roller is then rotated in the clockwise direction to flatten the envelope.	

Figure 4-35.

- g) Secure the guide roller by tightening the guide roller setscrew in the unloading mode.
- h) Play back the tape drive train alignment tape to check that the envelope waveform does not change.
- 9. Adjustment of A/C head X-position.
 - a) In the X value adjustment mode (see the Electrical Adjustment), make a short-circuit between TP5005 and TP5006, both located at the left on your side on the main PWB, to center the tracking.
 - b) Move the A/C head arm with an adjusting gear driver, and adjust the A/C head position for maximum head switching pulse hi side envelope.
 - Finally tighten the screws ① and ②. (First tighten the screw ①, and next the screw ②.) (Figure 4-36①②)
 - (Reference: Final tightening torque: 0.6 N.m as preferable.)
 - c) Adjust the playback switching point.
 - d) Check the flatness of the envelope waveform and sound by playing back a recorded tape.




Figure 4-36.

REPLACEMENT OF THE CAPSTAN D.D. (DIRECT DRIVE) MOTOR

- Remove the cassette housing control assembly.
- Removal (Follow the order of indicated numbers.)
- Disconnect from the board-to-board connector on the main PWB.
- 2. Remove the drive belt ①.
- 3. Remove the screws 2.




Figure 4-37.

Reassembly

- Mount the capstan motor on the mechanism chassis making sure not to allow the capstan shaft to hit the mechanism chassis, and attach it with the three screws.
- Attach the reel belt. Reconnect to the board-to board connector on the main PWB.

Notes:

- After installing the capstan D.D. motor, be sure to rotate the capstan D.D. motor and chack the movement.
- 2. Check the servo circuit.

REPLACEMENT OF DRUM D.D. MOTOR

- 1. Put the unit in the cassette eject position.
- 2. Unplug the power cord.
- · Removal (Reverse the order in reassembly.)
- 1. Disconnect the FFC cable ①.
- 2. Unscrew the D.D. stator assembly fixing screws ②.
- 3. Take out the D.D. stator assembly 3.
- 4. Unscrew the D.D. rotor assembly fixing screws 4.
- 5. Take out the D.D. rotor assembly ⑤.

Notes:

- In removing the D.D. stator assembly, part of the drum earth spring pops out of the pre-load collar. Be careful not to lose it.
- Secure the D.D. rotor assembly so that the installation positioning holes in the D.D. rotor assembly and upper drum assembly match.
 - (Match the upper drum's notch with the rotor's hole.)
- 3. Be careful not to damage the upper drum or the video head.
- 4. Be sure that the hall device and the D.D. stator assembly are not damaged by the D.D. rotor assembly or other parts.
- 5. After installation, adjust the playback switching point.




Figure 4-38.

ASSEMBLE THE MECHANISM'S PARTS-REQUIRING THE PHASE MATCHING IN THE STEPS BELOW.

- Assembling the pinch roller assembly, reverse guide assembly and the pinch drive cam (on the front of the mechanism chassis).
- 2. Mounting the shifter (on the back of the mechanism chassis).
- Mounting the master cam (on the back of the mechanism chassis).
- Mounting the connection gear, slow brake and loading motor assemblies (on the back of the mechanism chassis).

1. Assembling the pinch roller assembly, reverse guide assembly and the pinch drive cam (on the front of the mechanism chassis).

Place the following parts in position in numerical order.




Figure 4-40-1.

③ Insert Pinch Roller/Pinch Double Action Lever Ass'y.




Figure 4-40-2.

④ Insert Open Lever.





Figure 4-40-3.

2. Mounting the shifter (on the back of the mechanism chassis).



- Make sure that the loading gear is at the point
 as shown below.
- 2. Place the shifter in position, keeping in mind the 6 insertion points and the three relief points.
- 3. For the phase matching at the insertion point ①, see the point ② as shown below.
- 4. Finally fix the shifter with two washers located on insert points ① and ④.




Figure 4-42.

3. Mounting the master cam (on the back of the mechanism chassis).

- (1) Make sure beforehand that the shifter is at the point as shown below.
- (2) Place the master cam in the position as shown below.

Note:

See the figure below for the phase matching between the master cam and the cassette control drive gear.

(3) Finally fix the master cam with E ring.




Figure 4-43.

to the hole on the master cam.

REPLACEMENT OF LOADING MOTOR

Removal states of statem, Secretary and violed condition and Remove 2 screws.

1500 a detailed a language will be a language.

1500 a detailed a language will be a language.

3. Mounting (no master can (on the back of the mechanism chemis).

Twinter, An. a.e. II was alimbred and braids settle. Alla Gast. (1)

The strain of the Market and State of the St




Figure 4-44.

Replacement

① Take out the old loading motor. Place a replacement loading motor as shown above (Figure 4-44.).




Figure 4-45.

Press-fit the loading motor pulley with a force of less than 98N (10 kgf). Be sure that the pulley is $7.7^{\circ}_{-0.1}$ mm away from the motor.

ASSEMBLY OF CASSETTE HOUSING

① Frame ass'y




Figure 4-46.






Figure 4-47.




Figure 4-48.

5. ELECTRICAL ADJUSTMENT

Notes:

· Before the adjustment:

Electrical adjustments discussed here are often required after replacement of electronic components and mechanical parts such as video heads.

Check that the mechanism and all electric components are in good working condition prior to the adjustments, otherwise adjustments can not be completed.

· Instruments required:

- O Colour TV monitor
- O Audio signal generator
- O DC voltmeter
- O Blank video cassette tape
- O Screwdriver for adjustment
- O Colour bar signal generator

- O Dual-trace oscilloscope
- O AC milli-voltmeter
- © Frequency counter
- Alignment tape (VROCPSV)
- O Alignment tape (VROATSV)
- Alignment tape (VROCBFFS)

X Servicing precations

When the IC804 (E²PROM) has been replaced, make the following reprogramming. Depending on models, the IC804 (E²PROM) has been factry-adjusted for it's memory function.

It's therefore necessary to reprogram the memory function for the model in question.

Note that the servo circuit requires readjustments for the head switching point, slow and still modes.

· Location of controls and test points




Figure 5-1.

SERVO CIRCUIT ADJUSTMENT

ADJUSTMENT OF HEAD SWITCHING POINT

1 1 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	A CONTRACT OF THE PARTY OF THE
Measuring instrument	Dual-trace oscilloscope Colour TV monitor
Mode	Playback
Cassette	Alignment tape (VROCPSV)
Test point	TP302 (H.SW.P.) to CH-1, VIDEO OUT jack to CH-2 (CH-1 trigger slope switch at (+), Internal trigger at CH-1 side.)
Specification	6.5 ± 0.5H (lines)

- Remove the front panel and play the alignment tape. (VROCPSV)
 - (Playback picture on the monitor screen.)
- Make for a moment short-circuit between TP5001 and TP5002, both located at the front side on the main PWB.

Be sure that all the fluorescent display tubes light up into the TEST mode.

(See Note below)

- 3. Press the PLAY button.
 - Be sure the "PLAY" appears in the fluorescent display tubes flashing (about 1Hz) into the auto PG adjustment operating.

Note:

When the manual PG adjustment, observe the waveform with an oscilloscope and make adjustment FF or REW button so that the specification.

- 4. Stop the "PLAY" appears in the flashing of fluorescent display tubes at adjusted.
- 5. Press the STOP button in the return to normal mode.
- Make this checking of waveform on the oscilloscope screen be as shown in Figure 5-2. just after the head switching point have been adjusted.

Note:

- ① Set-up of TEST mode. When the adjustment of HEAD SWITCHING POINT, AUTO TRACKING function is invalid.
- ② When the cassette housing control ass'y is removed, set-up of mechanism operating mode.
- 1) Replug the AC power cord it a few minutes later.
- Make a short-circuit between TP5005 and TP5006, both located at the front side on the main PWB with a 22 ohm resistor, to center the tracking.
- 3) AC power cord is plugged in.
- 4) You can mechanism operatig mode, Replug the AC power cord a few minutes later.




Figure 5-2.

ADJUSTMENT OF SLOW TRACKING PRE-SET (VC-M23SM/M231SM)

Measuring instrument	Colour TV monitor
Mode	Playback
Cassette	Self-recorded tape (See Note below)
Control	Tracking control buttons (+) or (-)
Specification	Minimized noise on monitor screen

- Have the unit to receive a good TV broadcast or feed a video signal to the VIDEO IN jack. (See note 2) below)
- 2. Record the signal on tape.
- Rewind and play the tape where signal was recorded in above step.
- Press the SLOW button on the remote control, and playback the recorded portion in the slow mode.
- Make for a moment short-ciucuit between TP5001 and TP5002, both located at the front side on the main PWB.

Be sure that all the fluorescent display tubes light up into the TEST mode.

- Look at the monitor screen and adjust the (+) or (-)
 TRACKING buttons so that the there is noise disappears from the screen.
- 7. Press the STOP button to return to normal mode.
- 8. Play the tape a few seconds then press the SLOW button again and make sure there is on noise in the screen.

Notes:

- ① Self-recorded tape means a cassette whose program was recorded by the unit being adjusted.
- ② The TV program will not be recorded if RCA or 21pin plugs are pluged in to the AUDIO/VIDEO input terminals.

ADJUSTMENT OF SP/LP SLOW TRACKING PRESET (VC-M43SM/M431SM)

Measuring instrument	Colour TV monitor
Mode	Playback
Cassette	Self-recorded tape (SP/LP mode) (See Note below)
Control	Tracking control buttons (+) or (-)
Specification	Minimized noise on monitor screen

- Have the unit to receive a good TV broadcast or feed a video signal to the VIDEO IN jack. (See note ② below)
- 2. Set the tape speed in SP mode by using the remote control and record the signal on tape.
- 3. Rewind and play the tape where signal was recorded in above step.
- 4. Press the SLOW button on the remote control, and playback the recorded portion in the slow mode.
- Make for a moment short-ciucuit between TP5001 and TP5002, both located at the front side on the main PWB.
 - Be sure that all the fluorescent display tubes light up into the TEST mode.
- Look at the monitor screen and adjust the (+) or (-) TRACKING buttons so that the there is noise disappears from the screen.
- 7. Press the STOP button to return to normal mode.
- Play the tape a few seconds then press the SLOW button again and make sure there is no noise in the screen.
 - (For the LP mode put adjustment at the same adjustment way as SP mode.)

Notes:

- ① Self-recorded tape means a cassette whose program was recorded by the unit being adjusted.
- ② The TV program will not be recorded if RCA or 21pin plugs are pluged in to the AUDIO/VIDEO input terminals.

ADJUSTMENT OF FV (False Vertical Sync) OF STILL PICTURE (VC-M23SM/M231SM)

Measuring instrument	Colour TV monitor
Mode	Playback still
Cassette	Self-recorded tape (See Note below ②)
Control	Tracking control buttons (+) or (-)
Specification	No vertical jitter of picture

- 1. Play a cassette which was recorded.
- 2. Press the PAUSE/STILL button to freeze the picture.
- 3. Look at the monitor screen and adjust (+) or (-) TRACKING buttons so that the vertical jitter of the picture to be minimized.
- 4. Play and freeze the self-recorded tape and make sure vertical litter of the picture is not noticeable.

Note:

- The FV goes back to the it's initial state when the unit is put into the system controller reset mode due to power failure, etc.
 - In this case, preset the FV once again.
- ② Self-recorded tape is a cassette whose program was recorded by the unit being adjusted.

ADJUSTMENT OF FV(False Vertical Sync) OF STILL PICTURE (VC-M43SM/M431SM)

Measuring instrument	Colour TV monitor
Mode	Playback still
Cassette	Self-recorded tape (SP mode) (See Note below ②)
Control	Tracking control buttons (+) or (-)
Specification	No vertical jitter of picture

- Play a cassette witch was recorded by the unit in SP mode.
- 2. Press the PAUSE/STILL button to freeze the picture.
- 3. Look at the monitor screen and adjust (+) or (-) TRACKING buttons so that the vertical jitter of the picture to be minimized.
- Play and freeze the self-recorded tape in SP mode and make sure vertical jitter of the picture is not noticeable.
 - (For the LP mode put adjustment at the same adjustment way as SP mode.)

Note:


- The FV goes back to the it's initial state when the unit is put into the system controller reset mode due to power failure, etc.
 - In this case, preset the FV once again.
- ② Self-recorded tape is a cassette whose program was recorded by the unit being adjusted.

Y/C CIRCUIT ADJUSTMENT

CHECKING OF VIDEO E-E LEVEL

Measuring instrument	Oscilloscope
Mode	E-E or Record
Input signal	EIA colour bar (1.0Vp-p)
Test point	VIDEO OUT jack
Specification	0.95 ± 0.1Vp-p

- Connect a 75 ohm terminating resistor to the VIDEO OUT jack and connect an oscilloscope across this terminating resistor. (See Note below.)
- 2. Feed a colour bar signal to the VIDEO IN jack.
- Make sure that the E-E signal amplitude is 1.0Vp-p as shown in Figure 5-3.



Notes:

Figure 5-3.

If the 75 ohm terminating resistor is missing, the signal amplitude will be doubled.

CHECKING OF WHITE CLIP LEVEL

Measuring instrument	Oscilloscope
Mode	E-E or Record
Input signal	EIA colour bar (1.0Vp-p)
Test point	Pin(48) of IC401, GND
Specification	190 ± 5% (See note below)

- Connect an oscilloscope to pin (48) of IC401 and GND.
- 2. Feed the colour bar signal to the VIDEO IN jack and set the unit in E-E or recording mode.
- 3. Make sure that the overshoot of the video signal is clipped at 190% as shown in Figure 5-4.




Figure 5-4.

Note:

From sync tip to white peak, the level is 100%. The white clip level is 90% above the white level.

CHECKING OF RECORD LEVEL

on Lordina of	TILOUTED ELVEL
 Measuring instrument	Dual-trace oscilloscope
Mode	Record mode
Input signal	EIA colour bar (1.0Vp-p)
 Test point	Chroma (Red) R514 terminal lead at L509 side (Sig.) ~ GND Sync tip R225 terminal lead at L210 side (Sig.) ~ GND
Specification	Chroma (Red): 205~290mVp-p Sync tip: 150~220mVp-p

- Feed the colour bar signal to the VIDEO IN jack and set the unit in recording mode.
- 2. Connect a dual -trace oscilloscope to each test point shown in table.
- Make sure so that the amplitude of the chroma (Red) portion and the sync tip portion are specified as shown in Figure 5-5.




Figure 5-5 (a).

Figure 5-5 (b).

CHECKING OF PLAYBACK LEVEL

Measuring instrument	Oscilloscope
Mode	Record/Playback
Input signal	EIA colour bar (1.0Vp-p)
Test point	VIDEO OUT jack
Specification	0.95 ± 0.1Vp-p

- 1. Be sure that E-E level has been correctly specificed.
- Connect a 75 ohm terminating resistor to the VIDEO OUT jack and connect an oscilloscope across this terminating resistor. (See Note below ①.)
- 3. Feed a colour bar signal to the VIDEO IN jack and set the unit in recording mode.
- 4. Play the colour bar portion of the recorded tape.
- 5. Make sure that the output signal amplitude is 1.0Vp-p as shown in Figure 5-6.

Note:

- ① If the 75 ohm terminating resistor is missing, the signal amplitude will be doubled.
- 2 Set the S.PICTURE switch turn off.




Figure 5-6,

ADJUSTMENT OF S.PICTURE

Measuring instrument	DC voltmeter/Colour TV monitor
Mode	EE 0r Record
Input Signal	EIA colour bar (1.0Vp-p) or monoscope (1.0Vp-p)
Test point	TP401(Sig.)~TP402(GND)
Control	R430 S.PICTURE control
Specification	7.9 ± 0.1V

- Connect a DC voltmeter to the test points TP401 (Sig.) ~ TP402 (GND).
- 2. Feed a colour bar or monoscope signal to the VIDEO IN jack.
- 3. Set the S.PICTURE switch turn on.
- Adjust R430 (S.PICTURE control) so that the DC voltmeter reads specified value, and checking of make sure so that the nothing unusual on the playback monoscope screen.

AUDIO CIRCUIT

CHECKING OF E-E LEVEL

Measuring instrument	AC milli-voltmeter
Mode	E-E/Record
Input signal	1kHz, -8.0dBs (at RCA type jack) 1kHz, -3.8dBs (at 21pin type jack)
Test point	AUDIO OUT jack
Specification	-8.0 ± 2dBs (at RCA type jack) -3.8 ± 2dBs (at 21pin type jack)

- 1. Connect an oscilloscope to the AUDIO OUT jack.
- 2. Feed the audio signal shown in table to the AUDIO IN jack.
- 3. Put the unit in E-E or recording mode.
- 4. Make sure that the output level is value shown in table.

CHECKING OF AUDIO PLAYBACK LEVEL

Measuring instrument	AC milli-voltmeter
Mode	Playback
Input signal	Alignmenttape.(VROCPSV) (1kHz level conrtol signal.)
Test point	AUDIO OUT jack
Specification	-9 ^{+2dBs} (at RCA type jack)
Specification	-7.8 +2clBs (at 21 pin type jack)

- 1. Playback the Alignment tape. (VROCPSV 1kHz level audio signal)
- Connect an AC milli-voltmeter to the AUDIO OUT jack.
- Make sure that the output level is value shown in table.

CHECKING OF AUDIO RECORD LEVEL

Measuring instrument	AC milli-voltmeter
Mode	Record/playback
Input signal	1kHz, -8.0dBs (at RCA type jack) 1kHz, -3.8dBs (at 21pin type jack)
Test point	AUDIO OUT jack
Specification	-8.0 ± 3dBs (at RCA type jack) -3.8 ± 3dBs (at 21pin type jack)

- 1. Connect an AC milli-voltmeter to the AUDIO O⊎T iack.
- Feed the audio signal shown in table to the AUDIO IN jack.
- 3. Make the self-recording and playback of the signal.
- 4. Make sure that the output level is value shown in table.

CHECKING OF ERASE VOLTAGE AND OS-CILLATION FREQUENCY

Measuring instrument	Oscilloscope
Mode	Record
Test point	Full erase head
Control	T601
Specification	70 ± 5kHz, 40Vp-p or greater

- 1. Put the unit in recording mode.
- 2. Connect an oscilloscope across the full erase head.
- Make sure the erase voltage across the full erase head is approx. 40Vp-p or more and frequency is 70 ± 5kHz.

RF CIRCUIT

ADJUSTMENT OF RF AGC CIRCUIT


Measuring instrument	DC voltmeter and VHF signal generator
Mode	RF signal at E12-CH (by VHF signal generator) (EBU colour bar signal at 87.5% modulated.)
Test point	TP1552 (Sig.) TP1554 (GND)
Control	VR001 AGC control
Specification	2.55 ± 0.1V


- Receive the E12 channel signal(colour bar signal at 87.5% modulated.) at Input field strength: 70dBμV of antenna terminal.
- 2. Connect a DC voltmeter to test points shown in table.
- 3. Adjust VR001 (AGC control) in the IF pack so that the voltage be specified.


6. MECHANISM OPERATION FLOWCHART AND TROUBLESHOOTING GUIDE


MECHANISM OPERATION FLOWCHART


CASSETTE INSERTION → STOP


















CLUB MOLLS



Replace IC901.

9

Check IC901.

Replace T901.

2


Check short-circuit or leak of T901.

YES

Check primary circuit, Q901, Q903

and C913.

*YES



Replace receiver.

2

the receiver when the infrared

remote control is activated?

▼YES

Replace IC801.

2


receiver and all the way up thru pin


(15) of IC801.

7. 7.1


-:


Check between at pin (1) of








C 14 7536.88;

















REPLACEMENT OF IC804 (E²PROM)

«Servicing precautions»

When the IC804 (E²PROM) has been replaced, make the following reprogramming. Depending on models, the IC804 (E²PROM) has been factory adjusted for it's memory function. It's therefore necessary to reprogram the memory function for the model in question. Note that the servo circuit requires readjustments for the slow and still modes.

Memory function reprogramming.

1. Check the power off, (power is standby mode)

2. Make for a moment short-circuit between TP5001 and TP5002, both located at the front side on the main PWB.

Be sure that all the fluorescent display tubes light up into the TEST mode.

3. Using the CHANNEL (+) and (-) buttons, select the right function numbers from among JP0-JP31, which appear in the fluorescent display tube, referring to the E²PROM map.

Press the DISPLAY button to pick up the functions (ON) and the CLEAR button to discard the functions (OFF).

DISPLAY and CLEAR buttons, are located on the remote control unit.

* When the DISPLAY button has been pressed (ON), the memory function No. starts flashing.

* When the CLEAR button has been pressed (OFF), the memory function No. lights up.

4. Make a short-circuit between TP5003 and TP5004, both located at the front side on the main PWB, and the settings will be displayed in hexadecimal notation.

Now you can see if the settings are correct.

5. Example: "ON" and "OFF" are taken as "1" and "0" respectively.

The numbers JP0 to JP31 are divided into four groups and each group's setting is displayed in hexadecimal notation.

J31 0	0- J30	J29 0	J28 0	J27 0	J26 0		J24 0	J23 0	J22 0 {	J21 0 }	J20 0	J19 0	J18 0 ,	J17 0	J16 0	
J15	SPA J14		J12	J11	J10	J09	ં ્ J08	J07	J06	J05	J04	J03) J02	J01	J00	
0	0 0	0 }	0	0	1	0 1 4	0	0	0 (0	0	1	1 (0 }	1	

[&]quot;000040D" appears in the fluorescent display tube.

6. Finally make for a moment short-circuit between TP5001 and TP5002, both located at the front side on the main PWB to clear the TEST mode or press the OPERATE button to turn the power on.

П
⋖
↸
_
≥
ᅎ
×

	910					Τ,		1			0	0	_	٥	0	0	0	_	0	_	0	0	_	0	0	٥	0	0	0	0	0	_	_ i	0	3024806
_	MACADIA		-		+		+	+		-	1	1	1	4						- [-	-	,	-	-	_		-			-	1	1	-	102 302
	HOODIN	O	0	0				0			0	0	0	0	٥	0	0	0	٥	-	0	0	-	0	0	0	0	0	0	0		0	-	٥	6 3004802
	Hocott	O	C	0				0	٥	-	0	0	0	٥	0	0	-	0	0	0	0	٥	-	0	0	0	0	0	0	0	0	-	-	0	1020806
	HOOGH	MC3UDIW O	c	c		,		0	0	-	0	0	0	0	0	0	0	0	0	0	0	0	-	0	0		0	0	0	0	0	0	-	0	1000802
	The state of the s	F) 0		,	0 0	0	-	0	-	-	-	0	-	-	-	0	0	-	-	-	-	-	0	-	0	0	0	-	0	-	-	0	EE7016
	Malayi	E	0			,	-	0	-	0	-	-	-	0	-	-	0	0	0	-	0	-	-	-	0	-	0	0	0	-	0	-	-	0	2EC5D162
		3				,	-	0	-	0	0	-	-	0	0	0	-	0	0	-	0	-	-	-	0	-	0	0	0	-	0	-	-	_	2625D162
		2		, ,) c	, ,		0	0	0	0	-	-	0	0	0	-	0	0	0	0	-	-	-	0	-	0	0	0	-	0	-	-		
	1072	5			+	, (0	<u> </u>	0	-	-	-	0	-	-	-	٥	0	-	-	-	-	0	0	0	0	0	0	0	0	-	0	-	2EE7805 2EE7805 0621D16
		E I	0		-	,	-	0	-	0	-	-	-	0	-	-	-	0	0	-	-	-	-	0	0	0	0	0	0	0	0	-	0	-	E7805 21
-		_				,	-	0	-	0	0	0	_	0	0	0	0	0	0	-	0	-	-	0	0	0	0	0	0	0	0	0	0		2205801 2
						,			0		0	0	_	0	0	0	0	0	0	0	0	_	-	0	0	0	0	0	0		0	0	0	-	1801 22
		CIM MISS	-		1	+	0	-	1	0	_	_				0	-	-	0		-	1	-		0		Ö	0	0	0	0	-	0	-	M 2018 OF 21805 2525805 2527805 2527805 0201801
			+	+	-	-	+	-	1	_				0	0			0		-	1			0			. !	0		0	0	_	0		7805 PES
_		불	1	-		+	0	-		0						_	<u> </u>	<u> </u>			1	1						_		_			_		GRUS DED
		₩ 4	1	-		,	0	0	-	0	0	_	_	0	0	_		0		1	0			0			0		0		0	_	0		RN5 282F
_		M25GM			-	1	0	0	٥	0	0	-	-	0	0	0	-	0	0	0	0	-	-	0	0	0	0	0	0	0	0	_	0	_	DE 08946
	2	W. W.	0 0	0	0 0		0	0	0	0	0	-	0	0	0	0	-	0	0	0	0	0	-	0	0	0	0	0	0	0	0	-	0	-	C.
		MH64CM					٥	0	-	0	-	-	-	0	-	0	0	-	0	-	-	-	-	-	0	0	0	٥	-	0	0	-	0	0	PERTO
		M24LM				>	0	0	0	-	0	٥	0	0	0	0	0	-	0	-	0	0	-	-	0	0	٥	0	-	0	0	0	0	0	401409
		MZ3LM		> 0		>	0	0	0	1	0	0	0	0	0	0	0	0	0	-	0	0	-	-	0	0	0	0	-	0	0	0	0	0	4004090
		≆			> 0	3	0	0	-	0	-	-	-	0	-	0	0	-	0	-	-	-	0	0	-	-	0	0	-	0	0	-	0	0	ACC700A
		-			-		0	0	0	1	0	-	-	0	0	0	0	-	0	-	0	-	0	0	-	-	0	0	-	0	0	-	0	0	4004220 1014220 1616324 2607324 1004C20 1014C20 2607C24
				-	-	>	0	0	0	-	0	0	0	0	0	0	0	-	0	-	0	0	0	0	-	-	0	0	-	0	0	0	0	0	000110
		_			0 0	>	0	0	0	-	0	0	0	0	0	0	0	0	0	-	0	0	0	0	-	-	0	0	-	0	0	0	0	0	COULD
-		25	-	1	1	+		EW		; ; ; ;		Š				1			-							1	_	0			ZE		-		
	MODELS		1			,	I-REPLAY	NTSC SKEW	HEAD 1	HEAD 0	三	SORT/CLOCK	DECODER		NICAM 1	NICAM D	CODE	G-CODE	OFM	Ы	F-AV	2 SCART	CATV	TUNER 2	TUNER 1	TUNERO	SYSTEM	SYSTEM (VCR 1	VCR 0	SPETIALIZ	VPS/PDC	COLOR	COLOR 0	
	MC	-	15.d	음 :	53	- 28 -	27 -		25 H	-	+	+	-		+	+	-		+	+	-	-	+	+	-	: -	-	9	:	•	┰	÷	-i	<u>:</u>	- 7
:		_ :	5	į	į		;			i		į	-	1	_	į_	į	į		1	1	į	L	į	i 1	1	<u></u>	-	ļ.,	1		!	1	<u> </u>	Ļ

(Note: "1" : flashing "0" : lights up)

2. AUSBAU UND WIEDERZUSAMMENBAU

2-1 ZERLEGUNG DER WICHTIGSTEN BAUGRUPPEN

BODENPLATTE

GEHÄUSEOBERTEIL : Die vier 4 Schrauben ① lösen.

: 2 Schrauben ② und 6 Haken ③

entfernen.

: Den Wechselschalter @ entfernen. **FRONTPLATTE**

2 Schrauben (5) und 7 Klammern (6)

lösen.

BEDIENUNGSPLATINE : 1 Schraube @ lösen und vom Steckverbinder ® nehmen.


BANDLAUFWERK/ HAUPTPLATINEN

: 1 Schraube (9, 2 Schrauben (1),

2 Schrauben ① und 1 Steckverbinder ②

entfernen. Die Abdeckung des

Antennenanschlusses anheben und die Einheit aus dem Hauptrahmen nehmen.



2-2 ZERLEGUNG DER BAUGRUPPE LAUFWERK/HAUPTPLATINEN

ANTENNEN-

ABDECKUNG DES: 3 Schrauben (3) lösen. Abschirmgehäuse

entfernen.

ANSCHLUSSES BAUGRUPPE LAUFWERK-CHASSIS/

: 3 flexible Flachkabel (1) und 2 Kabelbäume (f) entfernen. Darauf achten, daß die Oberund Unterseite der flexiblen Flachkabel


KASSETTEN-GEHÄUSE

nicht vertauscht wird. 1 Schraube ® hinter der Hauptplatine lösen.

Das Laufwerkchassis gerade von der Hauptplatine ziehen. Darauf achten,daß die umliegenden Teile nicht beschädigt

KASSETTEN-**GEHÄUSE**

: 2 Schrauben (7) lösen.



2-3 VORSICHTSMASSNAHMEN BEIM WIEDERZUSAMMENBAU 2018 P. 1. JARUD 3.1835 S. S.

EINBAU DES KASSETTENSTEUERTEILS


ABDECKUNG DES

Wor dem Einsetzen des Kassettensteuerteils muß die Anfangseinstellung erfolgen. Die Anfangseinstellung umfaßteine Heinstellung einstellung einstellung einstellung einstellung einstellung einstellung.

sa sa di sedi anamatikolo

Elektrische Einstellung:

Einen Kurzschluß zwischen TP703 und TP704 herstellen und kontrollieren, daß das Bandlaufwerk sich wieder in der Anfangseinstellposition (*1) befindet. Dann das Kassettensteuerteil einsetzen. (Dieses Verfahren erfolgt, wenn das Bandlaufwerk bereits auf die Platine gesetzt wurde.)



Mechanische Einstellung:

Das Riemenscheiben-Vorschubrad des Lademotors mit einem Schraubendreher drehen und darauf achten, daß das Bandlaufwerk in seine Anfangseinstellposition (*1) zurückkehrt. Das Kassettensteuerteil einsetzen. (Dieses Verfahren ist nur für das Bandlaufwerk vorgesehen.)

VERBINDUNG DES BANDLAUFWERKS MIT DER PLATINE

Die vorstehenden Teile des Laufwerks mit den beiden Symbolen (rundes Bezugssymbol und ovales Zusatzbezugssymbol) auf der Hauptplatine ausrichten. Das Laufwerk gerade nach unten einsetzen und darauf achten, daß die Außenkanten des Laufwerkchassis keine benachbarten Teile beschädigen.


Die beiden Schrauben (eine zur Feststellung des Laufwerks und der Kopfverstärkerabschirmung, die andere auf der Lötseite der Hauptplatine in der Nähe des Lademotors) anziehen, um das Laufwerk auf der Platine zu befestigen. Die flexiblen Flachkabel (AN und AS) und den Kabelbaum (AB) zwischen dem Laufwerk und der Platine wieder anschließen. Teile, auf die besonders zu achten ist;

Start- und Endsensoren Q851 und Q852


L'ask a la dans la transitation Cont

Löschschutzschalter S851

Der Steckverbinder AE (Platine zu Platine) zwischen dem Laufwerk und der Hauptplatine ist mit besonderer Vorsicht zu behandeln.




3. FUNKTIONEN DER WICHTIGSTEN MECHANISCHEN TEILE (DRAUFSICHT)



Nr.	Funktion	Nr.	Funktion
1.	Vollöschkopf Alte Bandaufnahmen im Aufnahmemodus löschen.	13.	Rücklaufführung Zieht das Band heraus und steuert mit den oberen und unteren Führungen die Bandantriebshöhe.
3,	Spannarm Erkennt die Bandspannung während des Bandlaufs und bremst die Abwickelspulenscheibe über das Spannband.	16.	Andruckrollenhebel Drückt das Band während des Bandlaufs an die Antriebsachse.
7.	Abwicklungshauptbremse Bremst die Abwickelspule, um beim Stoppen in den Betriebsarten Schneller Vorlauf oder Schneller Rücklauf eine lose Bandlage zu vermeiden.	18.	Lademotor Mechanischer Antrieb zur Steuerung des Laufwerks. Die Kraft wird über einen Riemenantrieb auf den Hauptnoken und die Kassettensteuerung übertragen.
9.	Hauptbremse Aufwickeleinheit Bremst die Aufwickelspule, um um beim Stoppen in den Betriebsarten Bandvorlauf und Bandrück- lauf eine lose Bandlage zu vermeiden.		

(ANSICHT VON UNTEN)



١	Nr.	Funktion	Nr.	Funktion
	1.	Langsambandlauf-Bremshebel Erhält im Modus Zeitlupe/Standbild Kontakt mit dem Capstan-Direktantriebsmotor, der mit dem Hauptnocken verbunden ist, und bremst ihn in einem gewissen Maß ab.	6.	Limiter-Riemenscheibe Überträgt die Kraft des Capstan-Direktantriebs- motors über das Spulenzwischenrad auf die Spu- lenscheibe.
*	3. - 1 1 1 1 1 1 1 1.	Capstan-Direktantriebsmotor Mechanischer Antrieb des Laufwerks. Die Kraft wird über einen Antriebsriemen übertragen.	8.	Schieber Überträgt die Bewegung des Hauptnockens auf die Bremse, das Laderad, den Spannarm und den Kupplungshebel
	4.	Antriebsriemen Überträgt die Kraft, um das Band zur Limiter- Riemenscheibe zu transportleren.	9.	Aufwickel-Ladezahnrad Schaltet die Aufwickelstabbasis und die Füh- rungsrolle durch das Ladezahnrad T um und legt das Band um die Trommel, Außerdem überträgt es die Kraft auf die Ladezahnräder.

4. EINSTELLUNGEN, AUSTAUSCH UND MONTAGE DER MECHANISCHEN TEILE

Imfolgenden werden einige relativ einfache Wartungsmaßnahmen für diese Komponenten beschrieben. Die komplizierteren Reparaturen, die den Einsatz von Spezialinstrumenten und -werkzeugen erfordern (z.B. Austausch der Trommel) werden hier nicht erwähnt.

Die im folgenden aufgeführten, einfach zu handhabenden Werkzeuge eignen sich für die regelmäßige Wartung, um das Gerät im Originalzustand zu halten.

WERKZEUGE FÜR DIE EINSTELLUNG DER MECHANISCHEN TEILE

Die folgenden Werzeuge sind für eine ordnungsgemäße Wartung und zufriedenstellende Reparatur erforderlich.

Nr.	Werkzeug	Teil Nr.		Aussehen	Bemerkungen				
1	Einstellvorrichtung für die Spulenscheibenhöhe	JiGRH0002	BR	<i>Q</i>	Diese Werkzeuge dienen der Über				
2	Hauptschablone	JiGMP0001	BY		prüfung und Einstellung der Spulen- scheibenhöhe.				
4	Drehmomentmesser (90 g)	JiGTG0090	СМ						
4	Drehmomentmesser (1,2 kg)	JiGTG1200	CN		Diese Werkzeuge dienen der Über- prüfung und Einstellung des Dreh-				
5	Drehmomentmesserkopf	JiGTH0006	AW		moments der Auf- und Abwickelspulen.				
6	Kasetten- Drehmomentmesser	JiGVHT-063	CZ		Dieser Kassetten-Drehmomentmesser wird zur Überprüfung und Einstellung des Drehmoments der Aufwickelspule und zum Messen des Bandrückzugs verwendet.				
7	Spannungsmesser (300 g)	JiGCG0300	BF		Mit diesen beiden Werkzeugen (300 g und 2,0 kg) wird die Spannung gemes-				
′	Spannungsmesser (2,0 kg)	JiGSG2000	BS	1	sen.				
8	Innensechskantschlüssel (0,9 mm)	JiGHW0009	ΑE		Mit diesen Werkzeugen werden die Innensechskantschrauben gelöst und angezogen.				
٥	Innensechskantschlüssel (1,5 mm)	JiGHW0015	ΑE						
. o	Abgleichband (PAL)	VROCPSV	СК		Mit diesen Spezialbändern ist eine elektrische Feineinstellung möglich.				
11	Adapter für Spannungsmesser	JiGADP003	ВК		Dieser Adapter wird zusammen mit dem Spannungsmesser verwendet, um das Spiel des Drehtransformators einzu- stellen.				
12	Spezialschraubendreher	JIGDRIVERH-4	AP		Mit diesem Schraubendreher wird die Höhe der Führungsrolle eingestellt.				

Nr.	Werkzeug	Teil Nr.	¥,	Aussehen	Bemerkungen
14	Drehmoment- Schraubendreher	சட்ட மக்க ஷீக - என்றிக்கை JiGTD1200 - :	СВ		Mit diesem Werkzeug werden Kunst- stofftelle angezogen. Das Anzugs- moment beträgt 5 kg.
15	Vierkantsteckschlüssel M3x5,5 mm für Rückwärtsführung	JiGDRiVER11055			Mit diesem Werkzeug wird die Höhe der Rückwärtsführung eingestellt.
17	Höheneinstellwerkzeug für Rückwärtsführung	JiGRVGH-F18	BU		Mit diesem Werkzeug wird die Höhe der Rückwärtsführung eingestellt.
18	Zahnschlüssel	JiGDRiVER-6	вм	(1.00 to 1.00	Für X-Wert-Einstellung.

MECHANISCHE TEILE, DIE REGELMÄSSIG ÜBERPRÜFT WERDEN MÜSSEN

Die folgende Tabelle dient als Richtlinie für die Instandhaltung der mechanischen Telle.

Wartungsabstände Teile	500 Std.	1000 Std.	1500 Std.	2000 Std.	Mögliche Störungen	Bemerkungen				
Führungsrollenbaugruppe				0		Bei unregelmäßiger Drehung oder starker Vibration austauschen.				
Abwickelführungswelle					Seitengeräusche, Kopf	Bandkontaktbereich mit				
Rückhalteführung					gelegentlich blockiert.	angegebenem Reinigungsmittel reinigen.				
Schrägstab				0						
Baugruppe obere und untere Trommel		00	00	00	Schlechter Rauschabstand, keine Farbwiedergabe. Unzu- reichende Flachheit der Hüllkurve mit dem Abgleichband.	Bandkontaktbereich mit angegebenem				
Vollöschkopf				0	Schlechte Farbwiedergabe, Überlagerungen.	Reinigungsmittel reinigen.				
Ton-/Steuerkopf				0	Klangwiedergabe zu schwach oder verzerrt.					
Capstan-Direktantriebsmotor				0	Kein Bandtransport, ungleich- mäßige Farbwiedergabe.					
Andruckrolle				0	Kein Bandtransport, lose Bandlage.	Gummiteile und Gummikontaktbereich mit				
Antriebsriemen				0	Kein Bandtransport, lose Bandlage, kein schneller Vorlauf/Rücklauf.	angegebenem Reinigungsmittel reinigen.				
Spannbandbaugruppe				0	Kassette wird nicht geladen					
Lademotor				0	oder nicht entladen.					
Spannrollenbaugruppe				0	Kein Bandtransport.					
Baugruppe Limiter-Riemenscheibe				0						
Hauptbremshebel Auf-/Abwicklung				0	Lose Bandlage.					
AHC (Automatischer Kopfreiniger) (VC-M43SM/M431SM)		0		0		Die Reinigerrolle erretzen, wenn sie abgenutzt ist. Die AHC-Rolle einfach durch eine neue erretzen.				

HINWEIS: O: Teil auswechseln

: Reinigung (zum Reinigen ein fusselfreies, mit reinem Isopropylalkohohl angefeuchtetes Tuch verwenden).

△: Ölen (die angegebene Komponente muß alle 1000 Betriebsstunden mit hochwertigem Spindelöl geschmiert werden).

Falls ein Meßwert außerhalb des angegebenen Bereiches liegt, das betreffende Teil reinigen oder austauschen.

AUS- UND EINBAU DES KASSETTENSTEUERTEILS

Ausbau

- Den Modus Kassettenauswurf w\u00e4hlen und die Kassette auswerfen lassen.
- 2. Netzstecker ziehen.
- Die nachfolgenden Schritte in der vorgegebenen Reihenfolge ausführen.
 - a) Die Montageschrauben ① am Kassettengehäuse lösen.
 - b) Das Kassettensteuerteil verschieben und nach oben herausziehen.




Abbildung 4-2.

Das Verfahren für den Einbau in umgekehrter Reihenfolge durchführen.

Hinweise:

- Wenn ein Schraubendreher mit magnetisierter Spitze benutzt wird, diese unbegingt vom Ton-/Steuerkopf, Vollöschkopf und von der Trommel fernhalten.
- ② Beim Ausbau und Einbau darauf achten, daß das Kassettensteuerteil oder die Werkzeuge nicht gegen den Führungsstift, die Trommel oder andere Bauteile stoßen.
- ③ Kassette nach dem Einbau einmal in das Kassettensteuerteil einlegen.

BANDLAUF OHNE KASSETTENSTEUERTEIL

- Vor dem Einschalten einen Kurzschluß zwischen TP5005 und TP5006 herstellen. Beide befinden sich auf der linken Seite der Hauptplatine.
- 2. Netzstecker anschließen.
- 3. Gerät einschalten.
- 4. Kassettendeckel von Hand öffnen.
- 5. Deckel mit zwei Klebestreifen fixieren.
- 6. Kassette in das Laufwerkchassis einlegen.
- 7. Kassette mit einem Gewicht (500 g) stabilisieren, um ein Flattern zu verhindern.
- 8. Testlauf durchführen.




Abbildung 4-1.

• Einbau

1. Vor dem Einbau des Steuerteils einen Kurzschluß zwischen TP5005 und TP5006 herstellen. Beide befinden sich auf der linken Seite der Hauptplatine. Netzstecker anschließen. Das Antriebsrad des Kassettensteuerteils bewegt sich und stoppt genau an dem Punkt, an dem das große Zahnrad im Fenster des Laufwerkchassis erscheint. Zahn 2 des Kassettensteuer-Zahnrades mit Zahn 3 des Antriebswinkels der Kassettensteuerung ausrichten, wie in Abb. 4-2 dargestellt. Damit wird das Kassettensteuerteil in seine korrekte Position auf dem Laufwerkchassis geführt.




Abbildung 4-3.

Hinweis:

Das Gewicht darf nicht schwerer als 500 g sein.

AUSWECHSELN, KONTROLLE DER HÖHENEINSTELLUNG UND EINSTELLUNG DER SPULENSCHEIBEN

- Ausbau (Abwickel- und Aufwickelspulenscheiben)
- 1. Kassettensteuerteil ausbauen.
- 2. Spannband aus dem Spannarm ziehen.
- Hilfsbremshebel der Abwickel-/Aufwickeleinheit per Hand lösen. Der Ausbau der Hauptbremse der Abwickel/ Aufwickeleinheit wird damit überflüssig.
- Haken an der Oberseite der Spulenscheibe öffnen und die Spulenscheibe herausnehmen.

<Im Modus EJECT oder UL STOP>






Abbildung 4-4.

Einbau (Abwickelspulenscheibe)

- 1. Spulenscheibenwelle reinigen und schmieren.
- Die Phase der Spulenscheibe mit der Phase des Spulenrelaiszahnrades ausrichten und eine neue Abwickelspulenscheibe auf der Welle montieren.
- Spannband um die Abwickelspulenscheibe montieren und in die Öffnung des Spannarms führen. Dabei muß der Hilfsbremshebel der Abwickelspule gelöst sein.
- 4. Spulenscheibenhöhe kontrollieren.

Hinweise:

- ① Darauf achten, daß das Spannband während des Einbaus der Abwickelspulenscheibe nicht verformt wird.
- ② Darauf achten, daß die Hauptbremse der Abwickeleinheit und das Spulenrelaiszahnrad nicht beschädigt werden.

Einbau (Aufwickelspulenscheibe)

- 1. Spulenscheibenwelle reinigen und schmieren.
- Hilfsbremshebel der Aufwickelspulenscheibe lösen und die Phase der Spulenscheibe mit der Phase des Spulenrelaiszahnrades ausrichten. Eine neue Aufwickelspulenscheibe auf der Welle montieren.
- Die H\u00f6he der Spulenscheibe kontrollieren und die Hauptbremse der Aufwickelspule einbauen


Hinweis:

Darauf achten, daß die Hauptbremse der Aufwickelspule nicht beschädigt wird.

Nach dem Einbau die Rückzugkraft des Bildsuchrücklaufs (siehe Seite 68) sowie das Drehmoment der Bremse (siehe Seite 70) prüfen.

Überprüfung und Einstellung der Höhe Hinweis:

Die Hauptplatte auf dem Laufwerk montieren und darauf achten, daß sie nicht gegen die Trommel stößt (siehe Abb. 4-6).



Hauptplatte aufsetzen und Rücklaufführung mit dem Finger lösen.




Abbildung 4-6.

Hinweis:

Wenn das Spannband beim Ausbau in Pfeilrichtung gedrückt wird, ist ein größerer Kraftaufwand zum Lösen der Arretierung erforderlich.





Abbildung 4-5.

 Die Spulenscheibe muß zwischen den Positionen A und B liegen. Wenn die Höhe der Spulenscheibe nicht korrekt ist, wird sie durch Auswechseln der Poly-Schieberscheibe unter der Spulenscheibe justiert.

Hinweis:

Bei jedem Auswechseln der Spulenscheibe muß die Höhe gemessen und justiert werden.




Abbildung 4-7.

ÜBERPRÜFUNG UND EINSTELLUNG DES AUFWICKELDREHMOMENTS IM MODUS SCHNELLER VORLAUF

- · Kassettensteuerteil entfernen.
- Einen Kurzschluß zwischen TP5005 und TP5006 herstellen. Beide befinden sich auf der linken Seite der Hauptplatine. Gerät einschalten.

Vorbereitung

- Einen Drehmomentmesser auf Null stellen und auf die Aufwickelspulenscheibe setzen.
- Die FF-Taste betätigen, um das Laufwerk in den Modus Schneller Vorlauf zu schalten.
- Um die Restkapazität des Wiedergabemodus zu pr
 üfen, die Abwickelspulenscheibe langsam drehen und dann in den Vorlaufmodus stellen.

Überprüfung

- 1. Den Drehmomentmesser langsam von Hand in Aufwickelrichtung drehen (eine Drehung alle 2 bis 3 Sekunden).
- Überprüfen, ob das Aufwickeldrehmoment größer als 69 mN m (700 gf cm) ist.




Abbildung 4-8.

• Einstellung

- 1. Wenn das Aufwickeldrehmoment außerhalb des angegebene Bereiches liegt, die Riemenscheibe des Capstan-Direkt-antriebsmotors, den Antriebsriemen und die Limiter-Riemenscheibe mit Reinigungsmittel reinigen. Das Drehmoment erneut kontrollieren.
- 2. Wenn das Aufwickeldrehmoment noch immer außerhalb des Bereiches liegt, den Antriebsriemen austauschen.

Hinweise:

- Den Drehmomentmesser nach unten drücken, damit er nicht abspringt.
- Beim Überprüfen des Aufwickeldrehmoments die Spulenscheibe nicht für längere Zeit blockieren.

ÜBERPRÜFUNG UND EINSTELLUNG DES AUFWICKELDREHMOMENTS IM RÜCKLAUFMODUS

- · Kassettensteuerteil entfernen.
- Einen Kurzschluß zwischen TP5005 und TP5006 herstellen. Beide befinden sich auf der linken Seite der Hauptplatine. Gerät einschalten.

Vorbereitung

- Einen Drehmomentmesser auf Null einstellen und auf die Abwickelspulenscheibe setzen.
- 2. Die REW-Taste betätigen, um das Laufwerk in den Rücklaufmodus zu schalten.
- Um die Restkapazität zu pr
 üfen, die Aufwickelspulenscheibe langsam drehen und dann in den R
 ücklaufmodus stellen.

Überprüfung

- Den Drehmomentmesser langsam von Hand in Aufwickelrichtung drehen (eine Drehung alle 2 bis 3 Sekunden).
- Überprüfen, ob das Aufwickeldrehmoment größer als 69 mN·m (700 gf·cm) ist.




Abbildung 4-9.

Einstellung

- 1. Wenn das Aufwickeldrehmoment außerhalb des angegebenen Bereiches liegt, die Riemenscheibe des Capstan-Direktantriebsmotors, den Antriebsriemen und die Limiter-Riemenscheibe mit Reinigungsmittel reinigen. Das Drehmoment erneut kontrollieren.
- 2 Wenn das Aufwickeldrehmoment noch immer außerhalb des Bereiches liegt, den Antriebsriemen austauschen.

Hinweise:

- 1. Den Drehmomentmesser nach unten drücken, damit er nicht abspringt.
- 2. Beim Überprüfen des Aufwickeldrehmoments die Spulenscheibe nicht für längere Zeit blockieren.

ÜBERPRÜFUNG UND EINSTELLUNG DES AUFWICKELDREHMOMENTS IM WIEDER-**GABEMODUS**

- 1 Kassettensteuerteil entfernen.
- 2. Einen Kurzschluß zwischen TP5005 und TP5006 herstellen. Beide befinden sich auf der linken Seite der Hauptplatine. Gerät einschalten.
- 3. Den Deckel des Kassetten-Drehmomentmessers öffnen und mit zwei Klebestreifen fixieren.
- 4. Den Kassetten-Drehmomentmesser in das Gerät legen.
- 5. Das Gewicht (500 g) auf den Kassetten-Drehmomentmesser
- 6. REC-Taste drücken, um das Gerät in den Aufnahmemodus zu schalten.

SP-Einstellwert 12 ± 3,8 mN·m (122 ± 39 gf·cm)(VC-M23SM/M231SM) LP-Einstellwert 10,5±3,8mN·m (107±39gf·cm)(VC-M43SM/M431SM)




Abbildung 4-10.

Überprüfung

- 1. Kontrollieren, ob das Drehmoment in einem Bereich von 12 ± 3,8 mN·m (122 ± 39 gf·cm) (VC-M23SM/M231SM) oder 10,5 ± 3,8mN·m (107 ± 39gf·cm) (VC-M43SM/M431SM) liegt.
- 2. Das Drehmoment schwankt aufgrund der Rotationsabweichung der Limiter-Riemenscheibe. Den Mittelwert der Messungen verwenden.
- 3. Das Gerät in den SP (VC-M23SM/M231SM) oder LP (VC-M43SM/M431SM)Aufnahmemodus schalten und kontrollieren, ob das Drehmoment innerhalb des o.a. Bereiches liegt.

Einstellung

Falls das Aufwickeldrehmoment im Wiedergabemodus außerhalb des Bereiches liegt, die Limiter-Riemenscheibe austauschen.

Hinweis:

Den Kassetten-Drehmomentmesser stabilisieren, um eine Verschiebung zu vermeiden.

ÜBERPRÜFUNG UND EINSTELLUNG DES AUFWICKELDREHMOMENTS IM MODUS BILDSUCHRÜCKLAUF

- Kassettensteuerteil entfernen.
- Einen Kurzschluß zwischen TP5005 und TP5006 herstellen. Beide befinden sich auf der linken Seite der Hauptplatine, Gerät einschalten.

Vorbereitung

- 1. Die PLAY-Taste betätigen, um das Gerät in den Wiedergabemodus zu schalten.
- 2. Die REW-Taste betätigen, um das Gerät in den Modus Bildsuchrücklauf zu schalten.

Überprüfung

1. Den Drehmomentmesser auf die Abwickelspulenscheibe setzen und sehr langsam gegen den Uhrzeigersinn drehen (eine Umdrehung alle 1 bis 2 Sekunden). Kontrollieren, ob das Drehmoment mit dem Vorgabewert von 14,0 ± 3,9 mN·m (144 ± 40 af·cm) übereinstimmt.




Abbildung 4-11.

Hinweis:

Den Drehmomentmesser vorsichtig auf die Abwickelspulenscheibe setzen. Wenn er nicht korrekt aufliegt, werden falsche Meßergebnisse angezeigt.

Einstellung

Wenn das Aufwickeldrehmoment im Modus Bildsuchrücklauf außerhalb des angegebenen Bereiches liegt, muß die Limiter-Riemenscheibe ausgetauscht werden.

Das Drehmoment schwankt aufgrund der Rotationsabweichung der Limiter-Riemenscheibe. Den Mittelwert der Messungen verwenden.

ÜBERPRÜFUNG DES RUCHZUGS MEDES BILDSÜCHLAUF RÜCKSPUL - BETRIEB

- Kassettensteuerteil entfernen.
- Einen Kurzschluß zwischen TP5005 und TP5006 herstelinter Beide befinden sich auf der linken Seite der sotHauptplatine: Gerät einschalten.

dan**seite**nsteile

19 No. 9 His

....

- Überprüfung
- Die PLAY-Taste betätigen, um das Gerät in den Wiedergabemodus zu schalten.
- 2. Die REW-Taste betätigen, um das Gerät in den Modus ... Bildsuchrücklauf zu schalten.
- Den Drehmomentmesser auf die Aufwickelspulenscheibe setzen und sehr langsam gegen den Uhrzeigersinn drehen (eine Umdrehung alle 2 bis 3 Sekunden). Kontrollieren, ob das Drehmoment mit dem Vorgabewert von 3,0 ± 1 mN·m (31 ± 10 gf.cm) übereinstimmt.




Abbildung 4-12.

Hinweise:

- 1 Den Drehmomentmesser vorsichtig auf die Aufwickelspulenscheibe setzen. Wenn er nicht korrekt aufliegt, werden falsche Meßergebnisse angezeigt.
- 2 Das Drehmoment messen, w\u00e4hrend das Gewicht des Drehmomentmessers auf die Spulenscheibe wirkt.

ÜBERPRÜFUNG DES ANDRUCKROLLEN-DRUCKS

- Kassettensteuerteil entfernen.
- Einen Kurzschluß zwischen TP5005 und TP5006 herstellen. Beide befinden sich auf der linken Seite der Hauptplatine. Gerät einschalten.
- Überprüfung

Die PLAY-Taste betätigen, um das Gerät in den Wiedergabemodus zu schalten.




Abbildung 4-13.

- 1. Andruckrolle von der Capstan-Welle trennen.
- Den Spannungsmesser montieren, indem der Adapter des Spannungsmessers an der Andruckrollenwelle eingehängt wird.
- Den Druck nach und nach verringern, bis die Andruckrolle die Capstan-Welle berührt. Genau in dem Augenblick den Meßwert ablesen.
- Der Meßwert muß in einem Bereich von 900 g bis 1200 g liegen.

ÜBERPRÜFUNG UND EINSTELLUNG DER SPANNSTABPOSITION

- · Kassettensteuerteil entfernen.
- Einen Kurzschluß zwischen TP5005 und TP5006 herstellen. Beide befinden sich auf der linken Seite der Hauptplatine. Gerät einschalten.
- Vorbereitung
- Den Deckel der Videokassette (E-180) öffnen und mit zwei Klebestreifen fixieren.
- 2. Die Kassette in das Gerät einlegen.
- 3. Das Gewicht (500 g) auf die Kassette legen.
- 4. Die Einstellung am Anfang des E-180-Bandes vornehmen.




Abbildung 4-14.

Überprüfung

 Eine Kassette einlegen und die REC-Taste drücken. Wenn das Band eingezogen ist, die Position des Spannstabes kontrollieren.

 Visuell überprüfen, ob die Mitte des Spannstabes auf einer Linie 1,3 mm links von der Mittelline der Abwickel-Führungswelle liegt. Bei Bedarf eine Einstellung nach folgenden Schritten vornehmen.




Abbildung 4-15.

Talls die Mitte des Spannstabes links von der gepunkteten Linie liegt:




Abbildung 4-16.

Die Klinge eines Schraubendrehers in den EINSTELLER des Spannstabes führen und im Uhrzeigersinn drehen.

② Wenn der Rand des Spannstäbes rechts von der gepunkteten Linie liegt:




Abbildung 4-17.

Die Klinge eines Schraubendrehers in den Einsteller des Spannstabes führen und gegen den Uhrzeigersinn drehen.

- 3 Einstellbereich des des Spannstabeinstellers.
- (4) Einstellbereich des Spannstabeinstellnockens.




Abbildung 4-18.

Den Spannstabeinsteller so justieren, daß die Kreismarkierung auf dem Nocken innerhalb von 90° links und rechts von der Mitte liegt.

ÜBERPRÜFUNG UND EINSTELLUNG DES RÜCKZUGS BEI AUFNAHME/WIND

- Kassettensteuerteil entfernen.
- Einen Kurzschluß zwischen TP5005 und TP5006 herstellen. Beide befinden sich auf der linken Seite der Hauptplatine. Gerät einschalten.

Vorbereitung

- Den Deckel der Drehmomentmesser-Kassette öffnen und mit zwei Klebestreifen fixieren.
- 2. Die Drehmomentmesser-Kassette in das Gerät einlegen.
- Das Gewicht (500 g) auf die Drehmomentmesser-Kassette legen.




Abbildung 4-19.

Überprüfung


- Die REC-Taste betätigen, um das Gerät in den Aufnahmemodus zu schalten.
- Kontrollieren, ob der Meßwert für den Rückzug in einem Bereich von 31 bis 38 g·cm liegt.

Hinweise.

- 1. Darauf achten, daß das Band um die Rückhalteführung läuft.
- 2. Darauf achten, daß das Band nicht lose aufgewickelt oder an einem Ende beschädigt ist.

Einstellung ^{242,5} (1944) 4, 744 (1944) 444 (1944)

- Wenn der Meßwert am Kassetten-Drehmomentmesser unter dem angegebenen Wert liegt, den Spannungsfederhaken nach A bewegen.
- Wenn der Meßwert am Kassetten-Drehmomentmesser über über dem angegebenen Wert liegt, den Spannungsfederhaken nach B bewegen.




Abbildung,4-20.

es aut daken Beite der

Maria de la companya della companya de la companya de la companya della companya

CHECKING THE BRAKE TORQUE

Überprüfung des Bremsdrehmomentes an der Abwickelseite



Gegen den Uhrzeigersinn: Im Uhrzeigersinn: 5,9~9,8mN·m (60~100gf·cm) 10~32mN·m (100~330gf·cm)


Abbildung 4-21.

- Kassettensteuerteil entfernen.
- Einen Kurzschluß zwischen TP5005 und TP5006 herstellen. Beide befinden sich auf der linken Seite der Hauptplatine. Gerät einschalten.
- Vorbereitung
- Einen Drehmomentmesser auf Null einstellen und auf die Abwickelspulenscheibe setzen.
- Vom Schnellen Vorlauf in den STOP-Modus umschalten.
- 3. Den Netzstecker ziehen.

Überprüfung

1. Den Drehmomentmesser langsam (ca. eine Umdrehung in 2 Sekunden) im und gegen den Uhrzeigersinn der Abwickelbremse drehen. Die Spulenscheibe und der Zeiger des Drehmomentmessers müssen sich mit gleicher Geschwindigkeit drehen. Kontrollieren, ob die Werte beim Drehen im Uhrzeigersinnn in einem Bereich von 10~32 mN·m (100~330 gf·cm) und beim Drehen gegen den Uhrzeigersinn in einem Bereich von 5,9~9,8 mN·m (60~100cf·cm) liegen. Das Bremsdrehmoment muß beim Drehen im Uhrzeigersinn mindestens doppelt so hoch wie beim Drehen gegen den Uhrzeigersinnsein sein.

Überprüfung des Bremsdrehmomentes an der Aufwickelseite



Gegen den Uhrzeigersinn: Im Uhrzeigersinn: 9,8~34mN·m (100~340gf·cm) 4~8,3mN·m (40~85gf·cm)

Abbildung 4-22.

- · Kassettensteuerteil entfernen.
- Einen Kurzschluß zwischen TP5005 und TP5006 herstellen. Beide befinden sich auf der linken Seite der Hauptplatine. Gerät einschalten.

Vorbereitung

- Ein Drehmomentmeter auf Null einstellen und auf die Aufwickelspulenscheibe setzen.
- 2. Vom Schnellen Vorlauf in den STOP-Modus umschalten.
- 3. Den Netzstecker ziehen.

Überprüfung

1. Den Drehmomentmesser langsam (ca. eine Umdrehung in 2 Sekunden) im und gegen den Uhrzeigersinn der Aufwikelbremse drehen. Die Spulenscheibe und der Zeiger des Drehmomentmessers müssen sich mit gleicher Geschwindigkeit drehen. Kontrollieren, ob die Werte beim Drehen im Uhrzeigersinnn in einem Bereich von 9,8~34 mN·m (100~340 gf·cm) und beim Drehen gegen den Uhrzeigersinn in einem Bereich von 4~8,3 mN·m (40~85 cf·cm) liegen. Das Bremsdrehmoment muß beim Drehen gegen den Uhrzeigersinn mindestens doppelt so hoch wie beim Drehen im Uhrzeigersinn sein.

Einstellung des Bremsdrehmomentes an der Abwickelund Aufwickelseite

- Wenn das Bremsdrehmoment außerhalb des angegebenen Bereiches liegt, den Bremshebelfilz der Abwickelspulenscheibe oder der Aufwickelspulenscheibe reinigen. Das Drehmoment erneut messen.
- Falls das Bremsdrehmoment an der Abwickel- oder Aufwickelseite noch immer außerhalb des Bereiches liegt, die Hauptbremse austauschen.

Hinweis:

Beim Austauschen der Hauptbremse die Höhe der Spulenscheiben überprüfen und einstellen (siehe Seite 65) und das Bremsdrehmoment kontrollieren.

AUSWECHSELN DES TON-/STEUERKOPFES

- 1. Kassettensteuerteil entfernen.
- Das Gerät in den Entlademodus schalten und den Netzstecker ziehen.

Aushau

- 1. Die Schrauben (A) (B) (C) (1) lösen.
- Die Ton-/Steuerkopfplatine, die an die Ton-/Steuerkopfbaugruppe gelötet ist, lösen.

Hinweise:

- Nach dem Auswechseln stets den Bandantriebszug einstellen (siehe Selte 73). Der Kopf darf keinesfalls berührt werden. Den Kopf nach versehentlichem Berühren mit Alkohol reinigen.
- Darauf achten, daß die Federn beim Lösen der Schrauben (A) B) nicht abspringen.





Abbildung 4-23.

Auswechseln

- Die ausgebaute Ton-/Steuerkopfplatine auf eine neue Ton-/ Steuerkopfbaugruppe löten.
- Die Höhe des Ton-/Steuerkopfarms (Unterkante) zur Ton-/ Steuerkopfplatte (Schraubenbereich) mit den Schiebern auf 10,3 mm einstellen. (3 Positionen) (Siehe folgende Abbildung.)







Abbildung 4-24.

3. Die linke Seite des Zahnrades am Ton-/Steuerkopfarm mitder Markierung auf dem Chassis ausrichten. Die Schrauben Dund vorläufig so anziehen, daß sich der Ton-/Steuerkopfarm reibungslos bewegen läßt.

(Hinweis: Drehmoment für das vorläufige Anziehen der Schrauben: 0,2 N·m als Richtwert)

8- 977

1 carrier 15



Hinweis:

Die Höheneinstellung des Ton-/Steuerkopfes kann beim endgültigen Anziehen der Schrauben variieren, wenn die Schrauben ① und ② vorläufig zu locker angezogen wurden.

[Grobeinstellung der Ton-/Steuerkopfhöhe]




Abbildung 4-26.

- ① Die Kassette in das Bandlaufwerk einlegen.
- ② Die PLAY-Taste betätigen, um das Gerät in den Wiedergabemodus zu schalten.
- ③ Die H\u00f6he des Ton-/Steuerkopfes durch Drehen der Schraube © grob einstellen, bis sich das Band in der folgenden Position befindet.




Abbildung 4-27.


Einstellung

gewicht (500 g)

Die Schraube (©) so einstellen, daß der Steuerkopf 0,3 bis 0,5 mm unterhalb der unteren Bandkante sichtbar wird.

HÖHENEINSTELLUNG DER RÜCKLAUF-FÜHRUNG

[Höheneinstellung der Rücklaufführung]



- ① Den Öffnungshebel entfernen (Abbildung 4-29(a)).
- ② Im Bandlademodus zunächst die Einstellung an der 13,38 mm-Seite vornehmen. Die Einstellmutter für die Rücklaufführung um 1/10 Drehung gegen den Uhrzeigersinn drehen.
- ③ Eine Kassette einlegen, den Wiedergabemodus einschalten und darauf achten, daß das Band in der Nähe der Rücklaufführung keine Falten aufweist.
- 4 Mit einem handelsüblichen Steckschlüssel die Höheneinstellmutter justieren.




Abbildung 4-29 (a).




Abbildung 4-29 (b).

EINSTELLUNG DES BANDANTRIEBSZUGS

- 1. Kassettensteuerteil entfernen.
- Einen Kurzschluß zwischen TP5005 und TP5006 herstellen. Beide befinden sich auf der linken Seite der Hauptplatine. Gerät einschalten.
- Die Rücklaufspannung des Bildsuchlaufs prüfen und einstellen. (Siehe Seite 68.)
- 5. Den Ton-/Steuerkopf einstellen. (Siehe Seite 71.)
- 6. Grobeinstellung des Bandantriebszugs.
 - a) Das Oszilloskop am Prüfpunkt für das Hüllkurvenausgangssignal PB CHROMA (TP301) anschließen. Die Synchronisation des Oszillators auf EXT einstellen. Das PB CHROMA-Signal wird durch den Kopfumschaltimpuls (TP302) ausgelöst.
 - b) Die Einstellschraube an der unteren Führungsrolle lösen und mit einem Justierschraubendreher (JiGDRIVERH-4) so einstellen, daß die Führungsrolle sich reibungslos dreht. (Die Einstellschraube nicht zu sehr lösen, da die Führungsrolle dadurch instabil wird.) (Siehe Abbildung 4-30.)
 - c) Das Abgleichband (Monoskopmuster) auf die Spulenscheibe setzen und das Gerät in den Wiedergabemodus schalten. (Ein Gewicht von ca. 500 g auf die Kassette legen, um sie zu stabilisieren.)




Abbildung 4-30.

Abbildung 4-31.

- d) Im Einstellmodus für den X-Wert (siehe unter Elektrische Einstellungen) die Hüllkurvenwellenform durch Betätigung der Spurlagentaste (+) oder (–) von MAX auf MIN und MIN auf MAX ändern. Überprüfen, ob die Wellenform linear ist.
- e) Wenn kein linearer Frequenzgang vorliegt, die Führungsrollen auf der Abwickel- und Aufwickelseite mit einem Justierschraubendreher grob einstellen, bis ein linearer Frequenzgang erreicht ist.
- f) Die Schraube (A) festziehen, um Falten im Band an den Flanschen der Rückhalteführung zu glätten.
 - Das Band herausnehmen, um es auf Faltenbildung im Flanschbereich der Rückhalteführung zu kontrollieren.
 - (1) Keine Faltenbildung.
 - Die Schraube (A) im Uhrzeigersinn drehen, bis im Flanschbereich Falten im Band entstehen. Die Schraube (A) dann exakt bis zu dem Punkt zurückdrehen, an dem die Falten sich auflösen.
 - (2) Faltenbildung erkennbar.
 - Die Schraube (A) gegen den Uhrzeigersinn exakt bis zu dem Punkt drehen, an dem die Falten sich auflösen. Hinweis:

Wenn die Schraube (A) im Uhrzeigersinn gedreht wird, entstehen Falten am unteren Flansch.

Hinweise:

- Den Spurlagenregler in die Mittelposition bringen und die X-Position so einstellen, daß die PB CHROMA Hüllkurve den Maximalpegel erreicht. Dadurch vereinfacht sich die Grobeinstellung des Bandantriebszugs.
- 2. Bei der Grobeinstellung besonders auf die Ausgangsseite.





Abbildung 4-32.

Abbildung 4-33.

PB CHROMA Hüllkurve (TP301)



Kopfumschaltimpuls (TP302)

Abbildung 4-34.

achten.

VIII MISS

airt light.


- 7. Einstellung der Höhe von Ton-/Steuerkopf und Azimut
 - a) Ein Oszilloskop an die Audio-Ausgangsbuchse anschließen.
 - b) Ein Abgleichband mit linearem Standardsignal von 1 kHz einlegen. Die Schrauben ® und © so einstellen, daß der Audioausgang seinen maximalen Wert erreicht. Schraube Å so einstellen, daß keine Faltenbildung im Band an der Flansch der Rückhalteführung auftritt. (Siehe S. 21, Punkt 6.) Die Schrauben B, C und A in dieser Reihenfolge wiederholt justieren, bis der Audioausgang seinen maximalen Wert erreicht (normalerweise ein- bis dreimal).
 - c) Ein Abgleichband mit einem linearen Audiosignal von 6 kHz einlegen. Schraube ® so einstellen, daß der Audioausgang seinen maximalen Wert erreicht.

- 8. Einstellung von Bandantriebszug und X-Position (mit Abgleichband VROCPSV).
- a) Das Oszilloskop am Prüfpunkt für das Hüllkurvenausgangssignal PB CHROMA (TP301) anschließen. Die Synchronisation des Oszillators auf EXT einstellen. Das PB CHROMA-Signal wird durch den Kopfumschaltimpuls (TP302) syncronisiert.
 - b) Das Abgleichband für den Bandantriebszug abspielen
 - c) Die Hüllkurvenwellenform mit der Taste (+) oder (-) von MAX auf MIN und von MIN auf MAX andern. Die Führungsrollenhöhe auf der Abwickel- und Aufwickelseite mit einem Justierschraubendreher so einstellen, daß eine Hüllkurve mit möglichst linearem Frequenzgang entsteht.
 - d) Wenn sich das Band über oder unter der Bandschrägführung befindet, nimmt die PB Hüllkurve die in Abbildung 4-35 dargestellte Form an.
 - e) Die Hüllkurve auf den maximalen linearen Frequenzgang einstellen, wie in Schritt 6. e) auf Seite 21 erläutert.
 - f) Die Spurlagentaste (+) oder (-) betätigen, um zu sicherzustellen, daß ein linearer Frequenzgang für die

Carrost 10


	Wenn sich das Band über der Bandschrägführung befindet.		Wenn sich das Band unter de	r Bandschrägführung befindet
	Abwickelseite	Aufwickelseite	Abwickelseite	Aufwickelseite
Einstellung	Die Führungsrolle auf der Abwickelseite im Uhrzelger- sinn drehen (Führungsrolle wird abgesenkt), um einen linearen Frequenzgang der Hüllkurve zu erzielen.	Die Führungsrölle auf der Aufwickelseite im Uhrzeiger- sinn drehen (Führungsrölle wird abgesenkt), um einen linearen Frequenzgang der Hüllkurve zu erzielen.	Die Führungsrolle auf der Abwickelseite gegen den Uhr- zeigersinn drehen (Führungs- rolle wird angehoben), um das Band über der Band- schrägführung anzuordnen, Die Führungsrolle auf der Abwickelseite wird dann im Uhrzeigersinn gedreht, um einen linearen Frequenzgang der Hüllkurve zu erzielen,	Die Führungsrolle auf der Aufwickelseite gegen den Uhrzeigersinn drehen (Führungsrolle wird ange-hoben), um das Band über der Bandschrägführung anzuordnen. Die Führungsrolle auf der Aufwickelseite wird dann im Uhrzeigersinn gedrent, um einen linearen Frequenzgang der Hüllkurve zu erzielen.

- g) Die Führungsrolle durch Feststellen der Führungsrollen-Einstellschraube im Endlademodus sichern.
- h) Das Abgleichband für den Bandantriebszug abspielen lassen und sicherstellen, daß sich die Hüllkurvenwellenform nicht ändert.
- 9. Einstellung der X-Position des Ton-/Steuerkopfes
 - a) Im Einstellmodus für den X-Wert (siehe unter Elektrische Einstellungen) einen Kurzschluß zwischen TP5005 und TP5006 herstellen, um die Spurlage zu zentrieren. Beide Bauelemente befinden sich auf der linken Seite der Hauptplatine.
 - b) Den Ton-/Steuerkopfarm mit einem Justierzahnschlüssel verstellen und die Position des Ton-/Steuerkopfes auf den maximalen Kopfumschaltimpuls an der oberen Flanke der Hüllkurve justieren.
 - Die Schrauben ① und ② festziehen. (Zuerst Schraube ①, dann Schraube ② anziehen.) (Abbildung 4-36 ①②). (Hinweis: Anziehdrehmoment: 0,6 Nm als Richtwert.)
 - c) Den Wiedergabe-Umschaltpunkt einstellen.
 - d) Den linearen Frequenzgang der Hüllkurve sowie den Ton bei der Wiedergabe eines bespielten Bandes überprüfen.



AUSWECHSELN DES CAPSTAN-DIREKTANTRIESMOTORS

- Kassettensteuerteil entfernen.
- Ausbau (in der Reihenfolge der angegebenen Nummern).
- 1. Den Platine-Platine-Steckverbinder auf der Hauptplatine lösen.
- 2. Den Spulenriemen ① entfernen.
- 3. Die Schrauben @ lösen.



Einbau

- Den Capstan-Motor auf dem Laufwerkchassis montieren. Darauf achten, daß die Capstan-Welle nicht gegen das Laufwerkchassis stößt. Mit den drei Schrauben befestigen.
- 2. Den Spulenriemen anbringen. Den Platine-Platine-Steckverbinder auf der Hauptplatine anbringen.

Hinweise:

- 1. Nach Einbau des Capstan-Direktantriebsmotors den Motor drehen und auf reibungslosen Lauf überprüfen.
- 2. Den Servoschaltkreis überprüfen.

AUSWECHSELN DES DIREKTANTRIEBS-MOTORS FÜR DIE TROMMEL


- 1. Das Gerät in den Kassettenauswurf-Modus schalten.
- 2. Den Netzstecker ziehen.

Ausbau (umgekehrte Reihenfolge beim Zusammenbau)

- 1. Das flexible Flachkabel lösen (1).
- Die Befestigungsschrauben für die Statorbaugruppe des Direktantriebs lösen ②.
- 3. Die Statorbaugruppe herausnehmen 3.
- Die Befestigungsschrauben für die Rotorbaugruppe des Direktantriebs lösen (4).
- 5. Die Rotorbaugruppe herausnehmen ⑤.

Hinweise:

- Beim Herausnehmen der Statorbaugruppe springt ein Teil der Trommelmassefeder aus der Vorspannungsmuffe. Dieses Teil darf nicht verlorengehen.
- Die Rotorbaugruppe so einsetzen, daß die Positionierungsöffnungen für die Installation in der Rotorbaugruppe und in der oberen Trommelbaugruppe aufeinanderliegen. (Die Kerbe in der oberen Trommel mit der Öffnung im Rotor ausrichten.)
- Darauf achten, daß die obere Trommel und der Videokopf nicht beschädigt werden.
- Darauf achten, daß das Hall-Bauelement der Statorbaugruppe nicht durch die Rotorbaugruppe oder andere Teile beschädigt wird.
- 5. Nach dem Einbau den Wiedergabe-Umschaltpunkt einstellen.





EINBAU DER TEILE DES BANDLAUFWERKS. DIE EINE PHASENANPASSUNG ERFORDERN


- 1. Einbau der Andruckrolle, der Rücklaufführung und des Andruckrollen-Steuernockens (auf der Vorderseite des Laufwerkchassis).
- 2. Montage des Schiebers (auf der Rückseite des Laufwerkchassis).
- 3. Montage des Hauptnockens (auf der Rückseite des Laufwerkchassis).
- 4. Montage des Verbindungsrades, der Langsambremse und des Lademotors (auf der Rückseite des Laufwerkchassis).
- 1. Einbau der Andruckrolle, der Rücklaufführung und des Andruckrollen-Steuernockens (auf der Vorderseite des Laufwerkchassis).


Die folgenden Teile in ihrer Reihenfolge anordnen.





















Abbildung 4-39.

② Andruckrollen-Steuernocken einsetzen.

Baugruppe des Rücklaufführungshebels gegen den Uhrzeigersinn zum Stopper

drehen.



all regulate activities to the

miss to eliminaria a la como en

2009 F. no. o.

History is

e i kanalasi. Marajaran

the case of the

Andruckrollen-Steuernocken einsetzen. Kerbe mit dem Vorsprung auf der Baugruppe des Andrucksteuerhebels ausrichten.

Baugruppe des Andrucksteuerhebels einsetzen. Kerbe mit dem Vorsprung am Chassis ausrichten.

Baugruppe des Andrucksteuerhebels

Abbildung 4-40-1.

- ③ Baugruppe mit Andruckrolle/doppelwirkendem Andruckhebel einsetzen.
- ④ Öffnungshebel einsetzen.




Abbildung 4-40-2.





Abbildung 4-40-3.

2. Montage des Schiebers (auf der Rückseite des Laufwerkchassis).



- 1. Das Laderad muß sichen Position: (*); wie untersdargestellt, c befinden.
- 2. Den Schieber in seine Position bringen. Dabei die 6 Einsetzpunkte und die drei Freigabepunkte beachten.
- 3. Für die Phasenpassung am Einsetzpunkt ① Punkt ② in der folgenden Abbildung beachten.
- 4. Den Schieber mit zwei Scheiben an den Einsetzpunkten (1) und (4) befestigen.





Abbildung 4-42.

3. Montage des Hauptnockens (auf der Rückseite des Laufwerkchassis)

- (1) Zunächst sicherstellen, daß sich der Schieber in der im folgenden markierten Position befindet.
- (2) Hauptnocken in die imfolgenden dargestellte Position bringen.

Hinweis:

Die Phasenpassung zwischen dem Hauptnocken und dem Antriebsrad der Kassettensteuerung ist in folgender Abbildung dargestellt.



Antriebsrad der Kassettensteuerung

Antriebsrad einsetzen, dabei den weißen Zahn mit der Öffnung im Hauptnocken ausrichten.

Abbildung 4-43.


(3) Hauptnocken mit dem E-Ring befestigen.

AUSWECHSELN DES LADEMOTORS 1946 1944

and share newsoning as the second haupthodes with a common and the common and the

iffe in perma

en los) areal cateach car agament 3 (sieuskároukad per viertalifi De Zienak List, sach einstellen den dem Stanieber in der ins-



e or insing from ourses, retablish กระทาง เกมสมรัสทางการ การเปลี่ยวการ เมื่อการ เมื่อการสมรัฐ Contract of the Later Contract

Abbildung 4-45.

einsetzen, wie oben dargestellt (Abbildung 4-44).

Die Preßpassung der Lademotor-Riemenscheibe mit einer Kraft von weniger als 98 N (10 kgf) einstellen. Datauf achten, daß die Riemenscheibe einen Abstand von 7,7 - mm vom

Service Control of the Control

ment by the end of the particle of the particl

Abbildung 4-44.

Die 2 Schrauben lösen.

- Auswechseln
- ① Den alten Lademotor ausbauen. Einen neuen Lademotor

MONTAGE DES KASSETTENGEHÄUSES




Abbildung 4-46.




Abbildung 4-47.




Abbildung 4-48.

5. ELEKTRISCHE EINSTELLUNGEN

Hinweise:

· Vor der Einstellung:

Die hier erläuterten elektrischen Einstellungen sind in vielen Fällen nach dem Auswechseln elektronischer Bauteile und mechanischer Komponenten, z.B. Videokopf, erforderlich.

Vor der Einstellung kontrollieren, ob der Mechanismus und alle elektrischen Komponenten in einwandfreiem Zustand sind. Ansonsten sind keine korrekten Einstellungen möglich.

- Benötigte Instrumente:
 - © Farbbildschirm (TV)
 - Audiosignalgenerator
 - O Gleichstrom-Voltmeter
 - O Unbespielte Videokassette
 - O Schraubendreher für Einstellungen
 - O Farbbalkensignal-Generator

- O Zweistrahloszilloskop
- Wechselstrom-Millivoltmeter
- Frequenzzähler
- O Abgleichband (VROCPSV)
- O Abgleichband (VROATSV)
- O Abgleichband (VROCBFFS)

X Vorsichtsmaßnahmen bei Wartungsarbeiten

Wenn das IC804 (E²PROM) ausgetauscht wurde, die folgende Neuprogrammierung vornehmen. In Abhängigkeit vom Modell ist das IC804 (E²PROM) ab Werk auf die Speicherfunktion eingestellt.

Daher muß die Speicherfunktion für das jeweilige Modell neu programmiert werden.

Am Servoschaltkreis sind Neueinstellungen für Kopfumschaltpunkt, Zeitlupen- und Standbildmodus erforderlich.

Position der Regler und Prüfpunkte




Abbildung 5-1.

EINSTELLUNG DES SERVOSCHALTKREISES

JUSTIERUNG DES KOPFUMSCHALTPUNKTES

Meßinstrument	Zweistrahloszilloskop Farbbildschirm (TV)
Modus	Wiedergabe
Kassette	Abgleichband (VROCPSV)
Prüfpunkt	TP302 (H.SW.P) zu CH-1, VIDEO OUT-Buchse zu CH-2 (CH-1 Triggerneigungsschalter auf (+), interner Trigger auf CH-1-Seite)
Spezifikation	6,5 ± 0,5 H (Zeilen)

- Frontplatte abnehmen und das Abgleichband (VROCPSV) abspielen lassen. (Wiedergabebild auf dem Bildschirm.)
- Kurzfristig einen Kurzschluß zwischen TP5001 und TP5002 herstellen. Beide befinden sich vorn auf der Hauptplatine.

Alle Leuchtdioden müssen im TEST-Modus aufleuchten.

(Siehe Hinweis unten.)

- 3. PLAY-Taste drücken.
 - "PLAY" muß auf der Flüssigkristallanzeige blinken (etwa 1 Hz). Das Gerät befindet sich jetzt im automatischen PG-Einstellmodus.

Hinweis:

Im Modus Manuelle PG-Einstellung die Wellenform mit einem Oszilloskop beobachten und die Einstellung mit der FF- oder REW-Taste so vornehmen, daß die Spezifikation eingehalten wird.

- Nach der Einstellung erlischt die blinkende Anzeige "PLAY" auf der Flüssigkristallanzeige.
- STOP-Taste drücken, um in den normalen Modus zurückzukehren.
- Die Überprüfung der Wellenform am Oszilloskop gemäß Abbildung 5-2 unmittelbar nach Einstellung des Kopfumschaltpunktes vornehmen.

Hinweis:

- TEST-Modus aktivieren, wenn eine korrekte Einstellung des KOPFUMSCHALTPUNKTES und der Funktion AUTOMATISCHE SPURLAGE nicht möglich ist.
- ② Das Kassettensteuerteil entfernen und das Bandlaufwerk in den Betriebsmodus setzen.
- Nach einigen Minuten den Netzstecker wieder anschließen.
- 2) Mit einem 22 Ohm-Widerstand einen Kurzschluß zwischen TP5005 und TP5006 herstellen, um die Spurlage zu zentrieren, Beide Bauelemente befinden sich vorn auf der Hauptplatine.
- 3) Der Netzstecker ist angeschlossen.
- Der Betriebsmodus für das Laufwerk kann aktiviert werden. Den Netzstecker nach einigen Minuten wieder anschließen.




Abbildung 5-2.

JUSTIERUNG DER VOREINSTELLUNG FÜR DIE ZEITLUPENSPURLAGE (VC-M23SM/M231SM)

Meßinstrument	Farbbildschirm (TV)
Modus	Wiedergabe
Kassette	Band mit eigener Aufnahme (siehe Hinweis unten)
Regler	Spurlagenregeltaste (+) oder (-)
Spezifkation	Minimale Störzeilen auf dem Bildschirm

- Mit dem Gerät einen starken Fernsehsender einstellen oder ein Videosignal an die VIDEO IN-Buchse anlegen. (Siehe Hinweis @ unten.)
- 2. Das Signal aufzeichnen.
- Das Band zurückspulen und ab Beginn der Aufzeichnung des Signals abspielen.
- Die SLOW-Taste auf der Fernbedienung betätigen und den Bandteil mit der Aufzeichnung in Zeitlupe abspielen.
- Kurzfristig einen Kurzschluß zwischen TP5001 und TP5002 herstellen. Beide befinden sich vorn auf der Hauptplatine.
 - Alle Leuchtdioden müssen im TEST-Modus aufleuchten.
- 6. Den Bildschirm beobachten und die TRACKING-Tasten (+) oder (-) so einstellen, daß keine Störungen mehr auf dem Bildschirm zu erkennen sind.
- 7. Die STOP-Taste betätigen, um in den normalen Modus zurückzukehren.
- Das Band einige Sekunden lang abspielen. Dann erneut die SLOW-Taste drücken und kontrollieren, ob keien Störungen mehr auf dem Bildschirm zu erkennen sind.

Hinweise:

- ① Band mit eigener Aufnahme bezeichnet eine Kassette, die an dem einzustellenden Gerät bespielt wurde.
- ② Das Fernsehprogramm wird nicht aufgezeichnet, wenn der Cinch- oder 21-Pin-Stecker an die AUDIO/VIDEO-Eingangsbuchse angeschlossen wird.

JUSTIERUNG DER SP/LP VOREINSTELLUNG FÜR DIE ZEITLUPENSPURLAGE (VC-M43SM/M431SM)

Meßinstrument	Farbbildschirm (TV)
Modus	Wiedergabe
Kassette	Band mit eigener Aufnahme (SP/LP-Modus) (siehe Hinweis unten)
Regler	Spurlagenregeltaste (+) oder (-)
Spezifkation	Minimale Störzeilen auf dem Bildschirm

- Mit dem Gerät einen starken Fernsehsender einstellen oder ein Videosignal an die VIDEO IN-Buchse anlegen. (Siehe Hinweis @ unten.)
- Mit Hilfe der Fernbedienung die Bandgeschwindig keit auf SP-Modus einstellen und das Signal auf das Band aufnehmen.
- Das Band zurückspulen und ab Beginn der Aufzeichnung des Signals abspielen.
- Die SLOW-Taste auf der Fernbedienung betätigen und den Bandteil mit der Aufzeichnung in Zeitlupe abspielen.
- Kurzfristig einen Kurzschluß zwischen TP5001 und TP5002 herstellen. Beide befinden sich vorn auf der Hauptplatine.
 - Alle Leuchtdioden müssen im TEST-Modus aufleuchten
- Den Bildschirm beobachten und die TRACKING-Tasten (+) oder (-) so einstellen, daß keine Störungen mehr auf dem Bildschirm zu erkennen sind.
- 7. Die STOP-Taste betätigen, um in den normalen Modus zurückzukehren.
- Das Band einige Sekunden lang abspielen. Dann erneut die SLOW-Taste drücken und kontrollieren, ob keine Störungen mehr auf dem Bildschirm zu erkennen sind.
 - (Für den LP-Modus die Justierung wie im SP-Modus vornehmen.)

Hinweise:

- Band mit eigener Aufnahme bezeichnet eine Kassette, die an dem einzustellenden Gerät bespielt wurde.
- ② Das Fernsehprogramm wird nicht aufgezeichnet, wenn der Cinch- oder 21-Pin-Stecker an die AUDIO/VIDEO-Eingangsbuchse angeschlossen wird.

EINSTELLUNG FV (falschevertikale Synchronisation) VOM STANDBILDES (VC-M23SM/M231SM)

Meßinstrument	Farbbildschirm (TV)
Modus	Standbildwiedergabe
Kassette	Band mit eigener Aufnahme (siehe Hinweis ② unten)
Regler	Spurlagenregeltaste (+) oder (-)
Spezifikation	Kein vertikales Zittern des Bildes

- 1. Eine bespielte Kassette wiedergeben.
- Die PAUSE/STILL-Taste betätigen, um das Bild als Standbild wiederzugeben.
- Den Bildschirm beobachten und die TRACKING-Tasten (+) oder (-) so einstellen, daß kein vertikales Zittern mehr auf dem Bildschirm zu erkennen sind.
- Das Band mit der eigenen Aufnahme im Wiedergabeund Standbildmodus daraufhin überprüfen, daß kein vertikales Zittern des Bildes wahrnehmbar ist.

Hinweise:

- ① Die FV kehrt in den Ausgangszustand zurück, wenn die Systemsteuerung des Gerätes durch einen Stromausfall o.ä. zurückgesetzt wird (Reset). In diesem Fall FV erneut einstellen.
- ② Band mit eigener Aufnahme bezeichnet eine Kassette, die an dem einzustellenden Gerät bespielt wurde.

EINSTELLUNG FV. (falsche vertikale Synchronisation) VOM STANDBILDES (VC-M43SM/M431SM)

Meßinstrument	Farbbildschirm (TV)
Modus	Standbildwiedergabe
Kassette	Band mit eigener Aufnahme (SP-Modus)(siehe Hinweis ② unten)
Regler	Spurlagenregeltaste (+) oder (-)
Spezifikation	Kein vertikales Zittern des Bildes

- Eine Kassette Wiedergeben, die vom Gerät im SP-Modus aufgenommen wurde.
- Die PAUSE/STILL-Taste betätigen, um das Bild als Standbild wiederzugeben.
- Den Bildschirm beobachten und die TRACKING-Tasten (+) oder (-) so einstellen, daß kein vertikales Zittern mehr auf dem Bildschirm zu erkennen sind.
- 4. Das Band mit der eigenen Aufnahme im SP-Modus Wiedergeben und in den Standbildmodus übergeben, um zu überprüfen, ob kein vertikales Zittern des Bildes wahrnehmbar ist. (Für den LP-Modus die Justierung wie im SP-Modus vornehmen.)

Hinweise:


- ① Die FV kehrt in den Ausgangszustand zurück, wenn die Systemsteuerung des Gerätes durch einen Stromausfall o.ä. zurückgesetzt wird (Reset). In diesem Fall FV erneut einstellen.
- ② Band mit eigener Aufnahme bezeichnet eine Kassette, die an dem einzustellenden Gerät bespielt wurde.

EINSTELLUNG DES Y/C-SCHALTKREISES

ÜBERPRÜFUNG DES VIDEO-E-E-PEGELS

Meßinstrument	Oszilloskop
Modus	E-E oder Aufnahme
Eingangssignal	EIA-Farbbalken (1,0 Vs-s)
Prüfpunkt	VIDEO OUT-Buchse
Spezifikation	0,95 ± 0,1 Vs-s

- Einen 75 Ohm-Anschlußwiderstand an die VIDEO OUT-Buchse und ein Oszilloskop über diesen Anschlußwiderstand anschließen. (Siehe Hinweis unten.)
- Ein Farbbalkensignal an die VIDEO IN-Buchse anlegen.
- 3. Die Amplitude des E-E-Signals muß 1,0 Vs-s betragen, wie in Abbildung 5-3 dargestellt.



Hinweis:


Abbildung 5-3.

Wenn der 75 Ohm-Anschlußwiderstand fehlt, verdoppelt sich die Signalamplitude.

ÜBERPRÜFUNG DER WEISSPEGEL-SPITZENBEGRENZUNG

Meßinstrument	Oszilloskop
Modus	E-E oder Aufnahme
Eingangssignal	EIA-Farbbalken (1,0 Vs-s)
Prüfpunkt	Pin (48) des IC401, GND
Spezifikation	190 ± 5 % (siehe Hinweis unten)

- Ein Oszilloskop an Pin (48) des IC401 und GND anschließen.
- Das Farbbalkensignal an die VIDEO IN-Buchse anlegen. Das Gerät in den Modus E-E oder Aufnahme schalten.
- 3. Die Überschwingung des Videosignals muß bei 190 % begrenzt werden, wie in Abbildung 5-4 dargestellt.



Hinweis:

Der Pegel von der Synchronisationsspitze zur Weißpegelspitze beträgt 100 %. Die Weißpegel-Spitzenbegrenzung erfolgt bei 90 % über dem Weißpegel.

ÜBERPRÜFUNG DES AUFNAHMEPEGELS

Meßinstrument	Zweistrahloszilloskop
Modus	Aufnahme
Eingangssignal	EIA-Farbbalken (1,0 Vs-s)
Prüfpunkt	Chroma (Rot) Klemmenzuleitung von R514 an L509 (Signal) ~ GND Synchronspitze Klemmenzuleitung von R225 an L210 (Signal) ~ GND
Spezifikation	Chroma (Rot): 205~290 mVs-s Synchronspitze: 150~220 mVs-s

- 1. Das Farbbalkensignal an die VIDEO IN-Buchse anlegen und das Gerät in den Aufnahmemodus schalten.
- 2. Ein Zweistrahloszilloskop an die Prüfpunkte anschließen, wie in der Tabelle angegeben.
- Die Amplitude des Chroma-Teils (Rot) und des Synchronspitzenteils muß der Spezifikationa aus Abbildung 5-5 entsprechen.




Abbildung 5-5 (a).

Abbildung 5-5 (b).


ÜBERPRÜFUNG DES WIEDERGABEPEGELS

Meßinstrument	Oszilloskop
Modus	Aufnahme/Wiedergabe
Eingangssignal	EIA-Farbbalken (1,0 Vs-s)
Prüfpunkt	VIDEO OUT-Buchse
Spezifikation	0,95 ± 0,1Vs-s

- 1. Der E-E-Pegel muß der Spezifikation entsprechen.
- Einen 75 Ohm-Anschlußwiderstand an die VIDEO OUT-Buchse und ein Oszilloskop über diesen Anschlußwiderstand anschließen. (Siehe Hinweis unten ①.)
- Ein Farbbalkensignal an der VIDEO IN-Buchse anlegen und das Gerät in den Aufnahmemodus schalten.
- Den Farbbalkenabschnitt der bespielten Kassette wiedergeben.
- 5. Die Amplitude des Ausangssignals muß 1,0 Vs-s betragen, wie in Abbildung 5-6 dargestellt.

Hinweis:

- Wenn der 75 Ohm-Anschlußwiderstand fehlt, verdoppelt sich die Signalamplitude.
- 2 Den Schalter S.PICTURE auf Aus setzen.



EINSTELLUNG DES SCHALTERS S.PICTURE

Meßinstrument	Gleichstrom-Voltmeter/ Farbbildschirm (TV)
Modus	E-E oder Aufnahme
Eingangssignal	EIA-Farbbalken (1,0 Vs-s) oder Monoskop (1,0 Vs-s)
Prüfpunkt	TP401 (Signal) ~ TP402(GND)
Regler	R430 S.PICTURE-Regler
Spezifikation	7,9 ± 0,1V

- Ein Gleichstrom-Voltmeter an die Pr
 üfpunkte TP401 (Signal) - TP402 (Masse) anschließen.
- Ein Farbbalkensignal an der VIDEO IN-Buchse anlegen.
- 3. Den S.PICTURE-Schalter auf Ein setzen.
- Den R430 (S.PICTURE-Regler) so einstellen, daß das Gleichstrom-Voltmeter den angegebenen Wert anzeigt, Das Monoskop-Wiedergabebild darf keine ungewöhnlichen Signale aufweisen.

AUDIOSCHALTKREIS ÜBERPRÜFUNG DES E-E-PEGELS

Meßinstrument	Wechselstrom- Millivoltmeter
Modus	E-E/Aufnahme
Eingangssignal	1kHz, -8,0dBs (Cinch-Buchse) 1kHz, -3,8dBs (Scart-Buchse)
Prüfpunkt	AUDIO OUT-Buchse
Spezifikation	-8,0 ± 2dBs (Cinch-Buchse) -3,8 ± 2dBs (Scart-Buchse)

- Ein Oszilloskop an der AUDIO OUT-Buchse anschlie-Ben.
- 2. Das in der Tabelle angegebene Audiosignal an die AUDIO IN-Buchse anlegen.
- 3. Das Gerät in den Modus E-E oder Aufnahme stellen.
- 4. Der Ausgangspegel muß den in der Tabelle angegebenen Wert aufweisen.

ÜBERPRÜFUNG DES AUDIO-WIEDERGABEPEGELS

Meßinstrument	Wechselstrom- Millivoltmeter
Modus	Wiedergabe
Eingangssignal	Abgleichband (VROCPSV) (1 kHz Pegelsteuersignal)
Prüfpunkt	AUDIO OUT-Buchse
Spezifikation	-9 ^{+2dBs} (Cinch-Buchse)
Spezifikation	-7,8 +2dBs (Scart-Buchse)

- Das Abgleichband (VROCPSV 1 kHz Audiosignalpegel) abspielen.
- Ein Wechselstrom-Millivoltmeter an der AUDIO OUT-Buchse anschließen.
- 3. Der Ausgangspegel muß den in der Tabelle angegebenen Wert haben.

ÜBERPRÜFUNG DES AUDIO-AUFNAMEPEGELS

Meßinstrument	Wechselstrom- Millivoltmeter
Modus	Aufnahme/Wiedergabe
Eingangssignal	1kHz, -8,0dBs (Cinch-Buchse) 1kHz, -3,8dBs (21-Pin-Buchse)
Prüfpunkt	AUDIO OUT-Buchse
Spezifikation	-8,0 ± 3dBs (Cinch-Buchse) -3,8 ± 3dBs (21-Pin-Buchse)

- Ein Wechselstrom-Millivoltmeter an der AUDIO OUT-Buchse anschließen.
- 2. Das in der Tabelle angegebene Audiosignal an die AUDIO IN-Buchse anlegen,
- 3. Das Signal aufnehmen und wiedergeben.
- 4. Der Ausgangspegel muß den in der Tabelle angegebenen Wert aufweisen.

ÜBERPRÜFUNG DER LÖSCHSPANNUNG UND DER SCHWINGUNGSFREQUENZ

Meßinstrument	Oszilloskop
Modus	Aufnahme
Prüfpunkt	Vollöschkopf
Regler	T601
Spezifikation	70 ± 5 kHz, 40 Vs-s oder höher

- 1. Gerät in den Aufnahmemodus schalten. Territ 3347
- 2. Ein Oszilloskop über den Vollöschkopf anschließen.
- 3. Die Löschspannung über den Vollöschkopf muß ca. 40 Vs-s oder mehr betragen. Die Frequenz muß bei 70 ± 5 kHz liegen.

HF-SCHALTKREIS

EINSTELLUNG DES REGELSCHALT-KREISES FÜR DIE AUTOMATISCHE HF-VERSTÄRKUNG

Meßinstrument	Gleichstrom-Voltmeter und VHF-Signalgenerator
Modus	HF-Signal in Kanal E12 (durch VHF-Signalgenerator) (EBU-Farbbalkensignal zu 87,5 % moduliert)
Prüfpunkt	TP1552 (Signal) TP1554) (Masse)
Regler	VR001 Regler für automatische Verstärkung
Spezifikation	2,55 ± 0,1V


- Das Signal von Kanal E12 (Farbbalkensignal zu 87,5 % moduliert) bei einer Eingangsfeldstärke von 70 dBmV am Antennenanschluß empfangen.
- 2. Ein Gleichstrom-Voltmeter an die in der Tabelle angegebenen Prüfpunkte anschließen.
- VR001 (Regler für die automatische Verstärkung) im ZF-Block so einstellen, daß die Spannung dem angegebenen Wert entspricht.


6. ABLAUFDIAGRAMM ZUR LAUFWERKFUNKTION UND FEHLERSUCHTABELLE


ABLAUFDIAGRAMM ZUR LAUFWERKFUNKTION


Dieses Ablaufdiagramm beschreibt die Funktionsweise des Bandlaufwerks


EINLEGEN DER KASSETTE → STOP


















7. ATRC

7. FEHLERSUCHE



C901 austauschen.

NEIN

C901 überprüfen.

T901 austauschen.

NIIN NIIN

T901 auf Kurzschluß oder Kriechstrom


überprüfen.

Š

Primärkreis, Q901, Q903 und C913


überprüfen.


3




| 日本の日本の日の日

The State of the Contract of t








in offertier in





(----














AUSWECHSELN DES IC804 (E2PROM)

<< Vorsichtsmaßnahmen bei der Wartung >>

Nach dem Auswechseln des IC804 (E²PROM) sind folgende Programmierungen vorzunehmen. Je nach Modell wurde das IC804 (E²PROM) ab Werk auf die Speicherfunktion eingestellt. Es ist daher erforderlich, die Speicherfunktion für das entsprechende Modell neu zu programmieren. Der Servo-Schaltkreis muß für den Zeitlupen- und Standbildmodus ebenfalls neu eingestellt werden.

Programmierung der Speicherfunktion.

1. Das Gerät muß ausgeschaltet sein (Standby-Modus).

2. Vorübergehend einen Kurzschluß zwischen TP5001 und TP5002 herstellen. Beide Bauelemente befinden sich vorn auf der Hauptplatine. Alle Lämpchen der Flüssigkristallanzeige müssen im TEST-Modus aufleuchten.

3. Mit den CHANNEL (+) und (-)-Tasten die korrekten Funktionsnummern zwischen JP0 und JP31 wählen. Die entsprechenden Nummern erscheinen auf der Flüssigkristallanzeige (in Übereinstimmung mit der E²RROM-Tabelle).

Die DISPLAY-Taste drücken, um die Funktionen zu aktivieren (ON), und die CLEAR-Taste drücken, um sie zu deaktivieren (OFF).

Die Tasten DISPLAY und CLEAR befinden sich auf der Fernbedienung.

* Wenn die DISPLAY-Taste gedrückt wird (ON), beginnt die Speicherfunktionsnummer zu blinken.

* Wenn die CLEAR-Taste gedrückt wird (OFF), leuchtet die Speicherfunktionsnummer ununterbrochen.

4. Einen Kurzschluß zwischen TP5003 und TP5004 herstellen. Beide Bauelemente befinden sich vorn auf der Hauptplatine. Die Einstellungen werden im Hexadezimalformat angezeigt. Sie können jetzt ablesen, ob die Einstellungen korrekt sind.

Beispiel: "ON" und "OFF" werden als "1" und "0" ausgedrückt.
 Die Nummern JP0 bis JP31 sind in vier Gruppen unterteilt. Jede einzelne Einstellung innerhalb einer Gruppe wird im Hexadezimalformat dargestellt.

J31	J30	J29	J28	J27	J26	J25	J24	J23	J22	J21	J20	J19	J18	J17	J16
0	. 0	0	0	- 0	0	0	0	0	0	0	0	0	0	0	0
	{	}			1	}			Ĺ	ļ			Ĺ	ļ	
	SPA	ACE			()			C)			()	
14.5	44.4	140	110												
	J14	J13		J11	J10	J09	J08	J07	J06	J05	J04	J03	J02	J01	J00
0	0	0	0	0	1	0	0	0	0	0	0	1	1	0	1
\Box				\Box			\Box				Û				
0					4	1			C))	

[&]quot;000040D" erscheint auf der Flüssigkristallanzeige.

 Vorübergehend einen Kurzschluß zwischen TP5001 und TP5002 herstellen. Beide Bauelemente befinden sich vorn auf der Hauptplatine. Der TEST-Modus wird aufgehoben. Alternativ die OPERATE-Taste drücken, um die Stromversorgung einzuschalten.

ROM-TABELLE

MZ3HM M24HM MZ3HM M24HM 0 0 0	MOCHIN						3														
M23+M		MH641HW			M241GN	1GM	CHMS	M451GM		M231SW	M431SM										
00000		MH64HM	MZ3LM	M24LM MI	MHB4LM M24GM	GM M25GM		GM MH64GM	MH64	GM M23SM		MH64SM	MH641SM	M25FPM	M45FPW	MH63FPM	MH64FPM	M230BM	M250BM M4	M430BM M4	M450BM
0000	0	0	0	0			0	0 0		0	0	0	0	0	0	0	0	0	0	0	0
0000	٥	0	٥	0	0	0		0	0	0	0	0	0	0	0	0	0	0	0	0	0
0 0 0	0	0	0	0						0	0	0	0	0	0	0	0	0	0	0	0
0	0	0	0	0		_	0	0 0	0	0	0	0	0	0	0	0	0	0	0	0	0
c	٥	0	0	0	0	0	0	0 0	0	0	0	0	0	0	0	0	0	0	0	0	0
>	0	0	0	0	1		0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
1	0	-	0	0	-	0	0	-	**	0	-	-	-	0	-	-	-	0	0	-	-
 	-	0	-	-	0	0	0	0 0	0	٥	0	0	0	0	0	0	0	-	-	-	-
H-Fi 0 0	0	-	0	0	-	0	0	1 0	+	0	0	-	-	٥	0	-	-	0	0	0	0
SORT/CLOCK 0 0	-	-	0	0	-	-	_	-	-	0	0	-	-	-	-	-	-	0	0	0	0
DECODER 0 0	-	-	0	0	-	0	-	-	-	-	-	-	-	-	-	-	-	0	0	0	-
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
NICAM 1 0 0	0	-	0	0	-	0	0	0 0	0	0	0	-	-	0	0	-	-	0	0	0	0
	0	0	0	0	0	0	0	0	0	0	0	-	-	0	0	-	-	0	0	0	0
G-CODE 1 0 0	0	0	0	0	0			-	-	0	0	-	-	-	-	0		0	-	0	0
0	-	-	0	-	-	0	0	0 0	0	0	0	0	0	0	0	0	0	0	0	0	-
0 0 0	0	0	0	0	0	0	0	0 0	0	0	0	0	0	0	0	0	0	0	0	0	0
LP	-	-	-	-	-	1	0	-	-	0		-	-	0	-	-		0	0	—	
F-AV 0 0	0	-	0	0	-		0	0	-	0	0	-	-	0	0	0	-	0	0	0	0
2 SCART 0 0	-	-	0	0	-	0	1	1 1	-	-	-	-	-	-	1	-	1	0	0	0	0
CATV 0 0	0	0	-	-	-	-	1	1	-	-	-	-	-	-	-	-	-	-	-	-	-
TUNER 2 0 0	0	0	-	-	-	0	0	0 0	0	0	0	0	0	-	-	-	-	0	0	0	0
TUNER 1 1 1	-		0	0		0	0	0 0	0	0	0	0	0	0	0	0	0	0	0	0	0
TUNER 0 1 1	-	-	0	0	0		0	0 0	0	0	0	0	0	-	-	-		0	0	0	0
SYSTEM 1 0 0	0	0	0	0	0	0	0	0 0	0	0	0	0	0	0	0	0	0	0	0	0	0
SYSTEM 0 0 0	0	0	0	0	0	0	0	0	0	0	٥	0	0	0	0	0	0	0	0	0	0
VCR 1 1 1		-	-	-	-		0	0 0		0	0	0	0	0	0	0	0	0	0	0	0
VCR0 0 0	0	0	0	0	0	0	0	0	0	0	0	0	0		-	-	-	0	0	0	0
SPETIALIZE 0 0	0	0	0	0	0	0	0	0 0	0	0	0	0	0	0	0	.0	0	0	0	0	0
	-	-	0	0	-	-	-	-	-	0	0	-	-	-	-	-	-	0	-	0	-
COLOR 1 0 0	0	0	0	0	0	0	0	0 0	0	0	0	0	0	-	-	-	-	-	-	-	-
	0	0	0	0	0	-	-	1	-	-	-	-	-	0	0	0	0	0	0	0	0
DISPLAY 1004320 1014320		4 2E97324	1004C20	1615324 2E97324 1004C20 1014C20 2E97C24	-	0420805 062	1805 262	0621805 2625805 2E27805	805 2E27805	35 0201801	1 220580	1 2EE780	2205801 2EE7805 2EE7805 0621D16 2625D16 2EC5D16 2EE7D16 1000802	0621D16	2625016	2EC5D162	EE7D16	1000802	1020806 30	3004802 30	3024806


(Hinweis: "1" : blinkt "0" : leuchtet)


			МЕМО		i i i i i i i i i i i i i i i i i i i	
***************************************	· · · · · · · · · · · · · · · · · · ·	·	***************************************			
***************************************						***************************************
***************************************						,


				***************************************	~ ·	************
	-					***************************************
				2.77.77.77.77.77.77.77.77.77.77.77.77.77		
	. <u> </u>					
			· ·			
	i .	* The second of				
	. 1	• • · · ·			'	
\ \	1	to the Eleven		- <u>-</u>		
\$\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\					<u> </u>	
\$\$####\$#\$\$\$\\\\\\\\\\\\\\\\\\\\\\\\\\\	-		,			************


**************************************	***************************************			-	•	*****
***********************				***************************************		*******
/0).05******	***************************************		***************************************	~~~~		*******
************************			***************************************			
		-				<u></u>
	-					
••••••			\$444446666118864411841141 ³ }************************************	***************************************		*****
***************************************	Pps::di:::b:::sama.a.a.a.a.a.a.a.a.a.a.a.a.a.a.a.a.a.a					
)	
				·····	1	***********
	**************************************	····›	***************************************	***************************************	······································	***********
	*****************************	·•		.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	***********
	***************************************	······································		······································		**********
***************************************			***************************************	***************************************	P441(
**************************************	*		 	***************************************		
FII 1FT-17T-)***>>ET-FF-1ET-	**************************************				***************************************	1 1 142
: 		***************************************	***************************************	,		-:
		•		a 1	A contract of the contract of	

8. BLOCK DIAGRAMS SERVO BLOCK DIAGRAM









SCHEMATIC DIAGRAM

THIORIC OIGHA

IMPORTANT SAPETY NOTICE BE SURE TO USE CENUINE PARTS FOR SE CURING THE SAFETY AND RELIABILITY OF THE Parts Marked With " 🗥 " and parts SHADED (IN BLACK) ARE ESPECIALLY IMPOR-TANT FOR MAINTAINING THE SAFETY AND PROTECTING ABILITY OF THE SET. BE SURE TO REPLACE THEM WITH PARTS OF PECIFIED PART NUMBER

SAFETY NOTES:

F E-E SIGNAL

- 1. DISCONNECT THE AC PLUG FROM THE AC OUTLET BEFORE REPLACING PARTS.
- 2. SEMICONDUCTOR HEAT SINKS SHOULD BE REGARDED AS POTENTIOL SHOCK HAZARDS WHEN THE CHASSIS IS OPERATING.

NOTES:

- 1. The unit of resistance "ohm" is omitted (k=1000 ohm, M=1 Meg ohm).
- 2. All resistors are 1/8 watt, unless otherwise noted.
- 3. The unit of capacitance "F" is omitted ($\mu = \mu F, p = \mu \mu F$).
- 4. The values in parentheses are the ones in the PB mode; the values without parentheses are the ones in the REC mode.

VOLTAGE MEASUREMENT CONDITIONS:


- 1. DC voltages are measured between points indicated and chassis ground by VTVM, with AC230V/ 50Hz supplied to unit and all controls are set to normal viewing picture unless otherwise noted.
- 2. Voltages are measured with 10000µV B & W or colour noted.

WAVEFORM MEASUREMENT CONDITIONS: 10000µV 87.5 percent modulated colour bar signal is fed into tuner.

CAUTION:


This circuit diagram is original one. Therefore there may be a slight difference from yours.

9. CIRCUIT DIAGRAM AND PWB FOIL PATTERN MAIN CIRCUIT (1) AND OPERATION CIRCUIT




VOLTAGE MEASUREMENT MODE

PB..... Parentheses () **REC..... Without Parentheses**




PB..... Parentheses ()
REC..... Without Parentheses




VOLTAGE MEASUREMENT MODE PB Parentheses ()

REC Without Parentheses




PB..... Parentheses ()
REC..... Without Parentheses




VOLTAGE MEASUREMENT MODE


PB Parentheses ()
REC Without Parentheses




PB Parentheses ()
REC Without Parentheses

PWB FOIL PATTERN







OPERATION DWE

TERMINAL PWB

1 2 3 4 5 6

10. REPLACEMENT PARTS LIST PARTS REPLACEMENT


Many electrical and mechanical parts in video cassette recorder have special safety-related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in this manual; electrical components having such features are identified by \triangle and shaded areas in the Replacement Parts Lists and Schematic Diagrams. The use of a substitute replacement part which does not have the same safety characteristics as the factory recommended replacement parts shown in this service manual may create shock, fire or other hazards.

"HOW TO ORDER REPLACEMENT PARTS"

To have your order filled promptly and correctly, please furnish the following informations.

- 1. MODEL NUMBER
- 3. PART NO.
- 2. REF. NO.
- 4. DESCRIPTION
- 5. PRICE CODE

HOW TO IDENTIFY CHIP TRANSISTORS AND DIODES BY ITS MARKING



- (1) Base/Input
- (2) Emitter/Ground
- (3) Collector/Output

Package	Marking	Parts No.
Fig. 1	BQ	VS2SC2412KQ-1
Fig. 1	FQ	VS2SA1037KQ-1
Fig. 1	25	VSDTC124EK/-1
Fig. 1	26	VSDTC144EK/-1
Fig. 1	24	VSDTC114EK/-1
Fig. 1	16	VSDTA144EK/-1

MARK ★: SPARE PARTS-DELIVERY SE

Ref. No.	Part No.	*	Description	Code
----------	----------	---	-------------	------

PRINTED WIRING BOARD ASSEMBLIES

(NOT REPLACEMENT ITEM)

DUNTK5290TEV3	*	Main Unit (VC-M23SM)	_
DUNTK5290TEVB	-	Main Unit (VC-M231SM)	_
DUNTK5290TEVH	-	Main Unit (VC-M43SM)	_
DUNTK5290TEVQ	-	Main Unit (VC-M431SM)	_

Ref. No.	Part No.	*	Description	Code
	DUNTK5301TEV3	-	Terminal Unit	_
			(VC-M23SM/M231SM)	
	DUNTK5301TEV5	-	Terminal Unit	_
			(VC-M43SM/M431SM)	
	DUNTK5304TEV0	-	Operation Unit	_

DUNTK5290TEV3 (VC-M23SM) DUNTK5290TEVB (VC-M231SM) DUNTK5290TEVH (VC-M43SM) DUNTK5290TEVQ (VC-M431SM) MAIN UNIT

TUNER AND ASSEMBLY

CNV4451	RCNVR0166UMZZ	U	Converter	вв
TU1551	VTUVTSR6HZ53/	U	Tuner	BD
UNT1501	RIFU-0656GEZZ	U	IF-Pack	BA

INTEGRATED CIRCUITS

	IC202	VHiMN3881\$/1E		J		AL
,	IC301	VHiAN3363S/-1	, .	J	(VC-M23SM/M231SM)	АН
ر. الو	IC301	VHIAN33645/-1	2.4	J	(VC-M43SM/M431SM),	AL
	IC401	VHiHA8201CF-1		J	20 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	AW
	IC701	VHiBA15218F1E	٠,	j	Something the	AF.
	IC801	RH-iX1204GEN2	٠.,	J		AZ
	IC802	VHiS806HZ//-1		J	* * · · · · · · · · · · · · · · · · · ·	AC:
	IC803	VHiBA6209//1E		j		AG.
	IC804	RH-iX2548CEZZ		J	(VC-M23SM/M231SM)	BA
	IC804	VHiXL24C04F-1	r 4	J	(VC-M43SM/M431SM)	AK
Δ	IC951	VHiUZT33///-1		J		AC
	IC2401	VHiLA7217M/-1	•	J		AG
	IC5001	VHiUPD16312-1		J		AQ
	IC5901	RH-iX1054GEZZ	•	J		AM

TRANSISTORS

INANSISTONS													
Q204	VS2SC2412KQ-1	J	2SC2412KQ	AA									
Q205	VS2SA1037KQ-1	J	2SA1037KQ	AA									
Q301	VS2SC2412KQ-1	J	2SC2412KQ	AA									
			(VC-M43SM/M431SM)										
Q302	VSDTC124EK/-1	J	DTC124EK	AB									
			(VC-M43SM/M431SM)										
Q303	VSDTC124EK/-1	J	DTC124EK	AB									
			(VC-M43SM/M431SM)										
Q304	VSDTC124EK/-1	J	DTC124EK	AB									
			(VC-M43SM/M431SM)										
Q305	VS2SC2412KQ-1	J	2SC2412KQ	AA									
			(VC-M43SM/M431SM)										
Q306	VS2SC2412KQ-1	J	2SC2412KQ	AA									
			(VC-M43SM/M431SM)										
Q307	VSDTC124EK/-1	J	DTC124EK	AB									
			(VC-M23SM/M231SM)										
Q308	VS2SC2412KQ-1	J	2SC2412KQ	AA									

Ref	, No.	Part No.	*	Description	Code	R	ef. No.	Part No.	*	Descripti	on !	Code
		TRANSITOR	3 S	(Continued)				DIODES	(Cc	ntinued)		
	Q401	VS2SC2412KQ-1	J	2SC2412KQ	AA		D699	RH-DX0053GEZZ	J	188132		AA
	Q402	VS2SC2412KQ-1	· J	2SC2412KQ	AA		D701	RH-DX0053GEZZ	J	188132	3 7 4 4	AA
	Q403	VS2SC2412KQ-1	J	2SC2412KQ	AA		D702	RH-DX0053GEZZ	J	1SS132	1 90	AA
	Q404	VS2SC2412KQ-1	J	2SC2412KQ	AA		D703	RH-DX0053GEZZ	J	1SS132		AA
	Q405	VS2SC2412KQ-1	J	2SC2412KQ	AA		D704	RH-DX0053GEZZ	J			
	Q406	VS2SC2412KQ-1	J	2SC2412KQ	AA		D705	RH-DX0053GEZZ	J	1SS132		AA
	Q407	VS2SC2412KQ-1	یل	.2SC2412KQ	. AA		D706	RH-DX0053GEZZ	Ĵ	188132		AA
	Q408	VS2SC2412KQ-1*	4 7	2SC2412KQ	AA		D707	RH-DX0053GEZZ	J	188132		AA
	Q409	VS2SA1037KQ-1		2SA1037KQ			D801	RH-DX0053GEZZ	j	155132		, AA
	Q410	VS2SA1037KQ-1	J	2SA1037KQ	AA		D802	RH-DX0053GEZZ	J	188132		AA
	Q411	VSDTC144EK/-1	J		AB		D851	RH-PX0234GEZZ	J	Photo Diode		-AD
	Q412	VS2SC2412KQ-1	J	2SC2412KQ	AA		D852	RH-PX0238GEZZ	j	Photo Diode		AF
	Q413	VS2SA1037KQ-1	پ اڻ.		AA		D853	RH-PX0238GEZZ	J	Photo Diode		
	Q416	VSDTC144EK/-1	. <u>y</u> J	DTC144EK	AB		D854	RH-PX0252GEZZ	-			AF
_	Q417	VSDTC144EK/-1	J	DTC144EK	AB		D855	RH-PX0252GEZZ	J	Photo Diode		AF
	Q540	VSDTC144EK/-1	J	DTC144EK	AB	Δ			J	Photo Diode	4.45	AF
÷	Q340	VOD10144EIV-(U	(VC-M43SM/M431SM)				RH-DX0083GEZZ	J	Diode Bridge		AC
	Q543	VSDTC144EK/-1	J	DTC144EK		Δ	D902	VHDERA2206/-1		m: /	:m004#	AC
	Q543	V3DTC144EN-1	J		AB	Δ	D903	RH-DX0220CEZZ	: J		1:969	.:AB
	0000	Venennáneon 4	-	(VC-M43SM/M431SM)		A	D904	RH-DX0053GEZZ	J	1SS132	10.33	AA
	Q603	VS2C3939SQR-1	J		AC	Δ	D907	RH-EX0723GEZZ	J	Zener Diode		AB
	Q702	VS2SA1037KQ-1	J		AA	\triangle	D908	RH-DX0053GEZZ	Ą	1SS132		AÀ
	Q703	VS2SA1037KQ-1	J	2SA1037KQ	AA		D921	VHDFR103///-1	J	FR103		AC
	Q801	VS2SA1037KQ-1	J	2SA1037KQ	AA	∇	D922	VHD1SS147//-1	J	188147		AA
	Q802	VSDTC114EK/-1	J	DTC114EK	AB	\triangle	D923	VHD30DF2-FC-1	J	30DF2		AE
Δ	Q901	VS2SC4231QR-3	J	2SC4231QR	· AH	\triangle	- D924	VHDRK34////-1	J	RK34		ΑE
∇	Q903	VS2SD2144S/-1	- J	2SD2144S	AC	Δ	D925	VHD1SS147//-1	J	155147		AA
Δ	Q921	VS2SC2412KQ-1	J	2SC2412KQ	AA	Δ	D926	RH-EX0807GEZZ	J	Zener Diode		AC
Δ	Q922	VS2SA1037KQ-1	J	2SA1037KQ	AA	\triangle	D927	RH-EX0613GEZZ	J	Zener Diode		AA
Δ	Q923	VS2SA1037KQ-1	J	2SA1037KQ	AA	Δ	D928	RH-DX0053GEZZ	J	SS132		AA
1	Q956	VS2SD468-C/-1	J	2SD468-C	AD	Δ	D929	RH-DX0053GEZZ	ل.	SS132		AA
1	Q957	VSDTA144EK/-1	J	DTA144EK	AC	Δ	D930	RH-EX0619GEZZ	J	Zener Diode		AA
• 1	Q958	VS2SC2412KQ-1	J	2SC2412KQ	AA		D954	RH-EX0634GEZZ	J	Zener Diode		AA
	Q963	VS2SC2001LK-1	J	2SC2001LK	- AA		D961	RH-DX0053GEZZ	J	188132		AA
4	Q964	VS2SC2001LK-1	J	2SC2001LK	AA		D964	RH-EX0609GEZZ	J	Zener Diode	\$	AA
1	Q965	VSDTA144EK/-1	J	DTA144EK	AC		D965	VHD1A3-F///-1		1A3-F		AA
	Q966	VSDTC114EK/-1	J	DTC114EK	AB		D966	VHD1A3-F///-1		1A3-F	:	AA
	Q970	VS2SD468-C/-1	J	2SD468-C	AD		D967	RH-DX0053GEZZ	J			AA
	Q2401	VS2SA1037KQ-1	J		AA		D2401	RH-DX0053GEZZ		1SS132		AA
	Q5901	VS2SA1037KQ-1		2\$A1037KQ	AA		D5001	RH-DX0053GEZZ		1SS132		AA
•	4000.	1020/1100/110	-		74.		D5002	RH-DX0053GEZZ		1SS132		
							D5002	RH-DX0053GEZZ				AA
							D5004	RH-DX0053GEZZ				AA
		DIC	וחר	=9		•				1SS132	!	AA
				·		Δ		RH-FX0005GEZZ	J			AE
	D343	RH-DX0053GEZZ	J	1SS132	AA		Q851	RH-PX0233GEZZ	J	- //010	4	AD
				(VC-M43SM/M431SM)			Q852	RH-PX0233GEZZ	J	Photo Diode		AD
	D401	RH-DX0053GEZZ	J	1SS132	AA							31.9 1
	D402	RH-DX0053GEZZ	J		AA							
	D403	RH-DX0053GËZZ	J	188132	AA							
	D405	RH-DX0053GEZZ	J	1SS132	AA			PACKAGI	=D	CIRCUIT		
	D406	RH-DX0053GEZZ	J	1SS132	AA		X501	RCRSB0166GEZZ	J	Crystal, 4.43MH	z	AG
.	D407	RH-DX0053GEZZ	J	188132	AA		X801	RCRSB0190GEZZ		· ·		AM
	D540	RH-DX0053GEZZ	J	188132	AA		X5901	RCRSB0184GEZZ		-		AM
				(VC-M43SM/M431SM)	."					-		
	D698	RH-DX0053GEZZ	J	1SS132	AA							

nei.	. No.	Part No.	*	Description C	ode	Ref. No.	Part No.		*	L	escr	iption	Code
		COILS AND TE	RAI	NSFORMERS			CAPACITO	ORS	3 (Conti	nuec	d)	
	FL2401	RFILA0020CEZZ	J	Filter	AD	C214	VCKYCY1CF224	4Z	J	0.22	16V	Ceramic	AA
	JA206	VP-XF2R2K0000	J	2.2µH	AB	C215	VCCCCY1HH10	1J	J	100p	50V	Ceramic	AA
	JA339	VP-XF4R7K0000	J	4.7μH	AB	C216	VCCCCY1HH10	0D	J	10p	50V	Ceramic	A
	JA423	VP-XF4R7K0000	J	4.7μΗ	AB	C217	VCKYCY1AF109	5Z	J	1	10V	Ceramic	A
	L205	VP-XF100K0000	J	10μH	AB	C218	VCKYCY1HF103	3Z	J	0.01	50V	Ceramic	A
	L206	VP-DF470K0000	J	47μH	AB	C219	VCKYCY1HB10	2K	J	1000p	50V	Ceramic	A
	L207	VP-XF560J0000	J	56μH	AB	C220	VCEAEM1HW33	35M	J	3.3	50V	Electrolytic	. A
	L208	VP-XF151K0000	J	150μΗ	AB	C221	VCKYCY1HF47	3Z	J	0.047	50V	Ceramic	Α
	L209	VP-XF121K0000	J	120µH	AB	C222	VCKYCY1EF104	4Z	J	0.1	25V	Ceramic	Α
	L210	VP-XF151K0000	. J	150µH	AB	C223	VCEAEM1HW33	35M	J	3.3	50V	Electrolytic	: A
	L301	VP-MK101K0000	J	100μΗ	AB	C224	VCEAEM1HW22			2.2	50V	Electrolytic	
	L303	VP-XF8R2K0000	J	8.2μH	AB	C226	VCEAEM1HW47				50V	Electrolytic	
		VP-XF221J0000	J	220μΗ	AB	C228	VCKYCY1CF22		J		16V	Ceramic	⊿
	L401	VP-XF151K0000	J	150μΗ	AB	C229	VCKYCY1EF10	. —	J	0.1	25V	Ceramic	A
	L402				AB	C230	VCEAEM0JW10					Electrolytic	
	L403	VP-XF150J0000	J	15µH	AB	C230	VCKYD41CY10		J	0.01	16V	Ceramic	, ,
	L404	VP-XF330J0000	J	33µH.		C232	VCKYD41CY10		J	0.01	16V	Ceramic	F
	L405	VP-XF2R7J0000	J	2.7μH	AC	C233	VCKYCY1HF47		J			Ceramic	, ,
	L406	VP-XF101K0000	J	100μH	AB AB	C234 C235	VCEAEM1CW1			10	16V	Electrolytic	
	L407	VP-XF330K0000	J	33µH			VCKYD41HF10		J		50V	Ceramic	, ,
	L408	VP-XF101K0000	J	100µH	AB	C236					50V	Ceramic	. /
	L501	VP-MK561K0000	J	560μH	AB	C237	VCCCCY1HH33		J	•			
	L504	VP-XF150J0000	J	•	AB	C238	VCCCD41HH4F			•	50V	Ceramic	
	L505	VP-XF100K0000	J	10μΗ	AB	C239	VCCCCY1HH56		J		50V	Ceramic	-
	L506	VP-XF390K0000	J	39μH	AB	C240	VCKYCY1HB39					Ceramic	- 1
	L509	VP-XF151K0000	J		AB	C241	VCCCCY1HH82		J.		50V	Ceramic	1
	L511	VP-XF680K0000	J	68µH	AB	C244	VCCCCY1HH22	213	J	220p	50V	Ceramic	. 1
	L512	VP-XF390K0000	J	39µН	AB	C292	VCKYCY1HF10		J			Ceramic	/
	L602	VP-DF221K0000	J	•	AB	C293	VCKYD41CY10		J		16V	Ceramic	/
	L650	VP-XF2R2K0000	J	•	AB	C294	VCCCCY1HH18		J	18p	50V	Ceramic	-
	L901	RCiLF0227GEZZ	J	Coil	AM	C301	VCEAEM0JW47			47		Electrolytic	
	L921	RCILP0171CEZZ	J	Coil	AD	C302	VCKYCY1HF10	3Z	J			Ceramic	-
	L922	RCiLP0175CEZZ	J	Coil	AD					(VC-N		//M431SM)	
	L1552	VP-XF120K0000	J	12μH	AB	C303	VCEAEM1HW1			1		Electrolytic	
	L1553	VP-XF120K0000	J	12µH	AB	C304	VCKYCY1HF10)3Z	J	0.01	50V	Ceramic	-
	L1554	VP-XF120K0000	J	12μΗ	AB	C305	VCKYCY1HF22	23Z	J	0.022	50V	Ceramic	
	L1555	VP-XF120K0000	J	12μΗ	AB					(VC-N	143SN	//M431SM)	
	L4402	VP-XF270K0000	J	27μΗ	AB	C306	VCKYCY1HF22	23Z	J	0.022	50V	Ceramic	
	L5901	VP-XF150J0000	J	15µH	AB					(VC-N	143SN	л/M431SM)	
	L5902	VP-DF101K0000	J	100μΗ	AB	C307	VCKYCY1HF22	23Z	J	0.022	50V	Ceramic	- 1
	L5903	VP-DF101K0000	J	100µH	AB	C308	VCKYCY1HF22	23Z	J	0.022	50V	Ceramic	
	T601	RTRNH0053GEZZ	J	OSC. Transformer	AE	C309	VCCCCY1HH2	70J	J	27p	50V	Ceramic	
	T901	RTRNZ0063UMZZ		Transformer	AQ					(VC-N	143SN	//M431SM)	
•						C310	VCCCCY1HH2	70J	J	27p	50V	Ceramic	1
										(VC-N	143SN	//M431SM)	
						C311	VCCCCY1HH2	70J	J	27p	50V	Ceramic	,
		CON	TF	OLS		C312	VCCCCY1HH2					Ceramic	
					AD	C313	VCKYCY1HF10				50V	Ceramic	
	R430	HVH-W4/82GEZZ	J	2.2k(B), S.S.P. Adj.	AB							M/M431SM)	
						C314	VCKYCY1HF10)3Z	J				
						20.1			_			M/M431SM)	
			۵.	TO DO		C324	VCKYCY1HF10)3Z	J			Ceramic	· .
		CAPA	Cl	TORS		C325	VCKYCY1EF10					Ceramic	
	C211	VCCCCY1HH330.	J	33p 50V Ceramic	AA	C325	VCKYCY1HB10						,
	C212	VCEAEM1HW474	M J	0.47 50V Electrolytic	AB	Ç520	VOICTOTTIBLE	J_ \	J	•		M/M431SM)	
	C213	110101010111111111111111111111111111111		1000p 50V Ceramic	AA					1000	יוטטיייי	ANTALAD LOUAL)	1

Ref. No.	Part No.	*	4	Desc	ription	Code	Ref. No.	Part No.	*		Descrip	otion (Code
	CAPACITO	ORS	(Cont	inue	d)		•	CAPACITO	RS	(Cont	inued)		
A4 C330	VCKYCY1HF10	3Z J	0.01	50V	Ceramic	AA	C622	VCKYCY1HF103Z	Z J	0.01	50V C	Ceramic	AA
C331	VCKYCY1HF10	3Z J	0.01	50V	Ceramic	AA	· C623	VCKYD41CY103N	1 J	0.01	16V C	Ceramic	AA
C401	VCEAEM1CW4	76M J	47	16V	Electrolytic	c AB	C624	VCQPYA2AA562	J	5600p	100V M	/lylar	- AC
C402	VCKYCY1HF10	3Z J	0.01	50V	Ceramic	AA	C625	VCCCCY1HH221.	J	220p	50V C	Ceramic	AA
C403	VCKYD41HB22	1K J	220p	50V	Ceramic	AA	C630	VCKYCY1HB102h	(J	1000p	50V C	eramic :	AA
: C404	VCKYCY1HB39	1K J	390p	50V	Ceramic	AA	C650	VCKYCY1HB102F	(J	1000p	50V C	Ceramic	AA
□ C405	VCCCCY1HH33	30J J	33p	50V	Ceramic	AA	C702	VCKYD41HB102k	J	1000p	50V C	eramic	AA
10 C406	VCCCD41HH15	iou j	15p	50V	Ceramic	AA	C707	VCKYCY1HB102k	(J	1000g	50V C	Ceramic	· AA
C408	VCCSD41HL396	U LO	-39p	50V	Ceramic	AA	65 C709	VCEAEMOJW476	МJ	47	6.3V E	lectrolytic	. AB
- C410	VCKYCY1HB10	2K J	1000	50V	Ceramic	AA	C710	VCEAEMOJW476I	M J			lectrolytic	· AB
*** C411	VCKYCY1HB33	1K J	330p	50V	Ceramic	AA	5 C711	VCKYCY1HF103Z	Z J	0.01		Ceramic	AA
3- C412	VCKYCY1HB10	2K J	1000	50V	Ceramic	AA	≈ C712	VCEAEM1HW225				lectrolytic	AB
C414	VCKYCY1HF10	3Z J	0.01	50V	Ceramic	AA	5 C713	VCEAEM1HW225				lectrolytic	AB
C418	VCEAEM1HW4	74M J	0.47	50V	Electrolytic	c AB	30 C714	VCEAEM1CW226				lectrolytic	
C419	VCKYCY1HB39	2K J	3900r	50V		AA	C715	VCKYCY1HB102k				ceramic	· AA
56 C421	VCKYCY1HF10	3Z J		50V	Ceramic	AA	84 C716	VCEAEM1CW226				Electrolytic	: AB
C422				50V		AA	- C717	VCEAEM1HW105		1.		Electrolytic	AB
AA C423				50V		∴ AA	5A C719	VCEAEM1HW105		on to †Pistoso		lectrolytic	
C424	VCKYCY1HF10			50V		AA	C720	VCKYCY1HF103Z				Ceramic	
C427	VCKYCY1HF10			50V		AA	C721	VCKYCY1HF103Z					
C428	VCKYD41CY10			16V		AA	C721	VCKYCY1EF104Z				Peramic	· AA
C429	VCKYD41CY10			16V		AA	C723					eramic '	AA
C501	VCKYCY1HB33		3300			AA	C723	VCKYCY1HF103Z				Ceramic	AA
· C503	VCKYCY1HF10		0.01					VCKYCY1HF103Z				eramic	AA
						AA	C725	VCKYCY1HB472H				Ceramic	AA
C504 C505	VCEAEM0JW10 VCKYCY1HF47		100 0.047	6.3V			C726	VCKYCY1HF103Z				eramic	AA
						AA	C727	VCEAEMOJW107I				lectrolytic	AB
C506	VCKYD41CY10		0.01	16V	Ceramic	AA	C728	VCKYCY1HB472k		,	50V C		AA
C508	VCKYCY1HF103		0.01	50V	Ceramic	AA	C729	VCKYCY1HF103Z				Ceramic	AA
C509	VCKYCY1EB15		0.015		Ceramic	AA	C730	VCEAEMOJW336I		33		lectrolytic	AA
C510	VCEAEM1HW30		3.3	50V	Electrolytic		C731	VCKYCY1HB102k		1000p		eramic	AA
C511	VCCCCY1HH33		33p	50V	Ceramic	AA	C732	RC-FZ5334BMNK				Mylar	AB
C512	VCKYCY1HF10		0.01	50V	Ceramic	AA	C733	VCKYCY1EF104Z				eramic	AA.
C513	VCKYCY1EF104			25V	Ceramic	AA	C734	VCKYCY1EF104Z				Ceramic	AA
C514	VCKYCY1HF33		0.033		Ceramic	AA	· C737	VCKYCY1HB102k				Ceramic	AA
C515	VCKYCY1HF47				Ceramic	AA	C740	VCKYCY1HB472k			50V C	eramic	AA
C516	VCEAEM1HW47			50V	Electrolytic		C750	VCEAEM1CW476	ΜJ	47	16V E	ectrolytic	AB
C517	VCCCCY1HH18		•	50V	Ceramic	AA	C751	VCEAEM1CW226	ΜJ	22	16V E	Electrolytic	AB
C520	VČEAEM1HW47			50V	Electrolytic		C754	VCKYD41CY103N	J	0.01	16V C	eramic	AA
C521	VCKYCY1HF22			50V	Ceramic	AB	C801	VCCCCY1HH101	J	100p	50V C	eramic	AA
C522	VCKYCY1AF105	5Z J	1	10V	Ceramic	AC	C802	VCCCCY1HH470	J J	47p	50V C	eramic	. AA
C523	VCEAEM1CW10	06M J	10	16V	Electrolytic	C AB	C803	VCCCCY1HH101	J	100p	50V C	eramic	AA
C525	VCKYD41CY103	3N J	0.01	16V	Ceramic	AA	C804	VCKYCY1EF104Z	. J	0.1	25V C	eramic	AA
C526	VCCSD41HL680	JJ J	68p	50V	Ceramic	AA	C805	VCEAEM1HW105	ΜJ	1	50V E	lectrolytic	AB
C527	VCCSD41HL470	J J	47p	50V	Ceramic	AA	C807	VCCCCY1HH220	J	22p	50V C	eramic	AA
Ac. C528	VCCSD41HL560) J	56p	50V	Ceramic	AA	C808	VCCCCY1HH220.	J	22p	50V C	eramic	AA
[≙] C529	VCEAEM1HW47	75M J	4.7	50V	Electrolytic	c AB	C811	VCKYCY1HF103Z	J	0.01		Ceramic	AA
C530	VCCCCY1HH12	1J J	1 20 p	50V	Ceramic	AA	C812	VCKYCY1HF103Z				Ceramic	AA
C531	VCCCCY1HH1F	ROC J	1p	50V	Ceramic	AA	C813	VCKYCY1HF103Z				Geramic	AA
C536	VCCCCY1HH18		180p	50V	Ceramic	AA	C814	VCKYCY1HF103Z				eramic	AA
C537	VCKYCY1HF103		0.01	50V	Ceramic	AA	C815	VCKYCY1HF103Z				Ceramic	AA
6 C539	VCCCCY1HH10		10p	50V	Ceramic	AA	C816	VCKYD41CY103N		0.01		eramic eramic	AA
^{1.} C541	VCKYCY1EF104			25V	Ceramic	AA	C817	VCKYCY1HB102k			50V C		
C544	VCKYCY1HF103			50V		AA	* *.	VORTOTINGIUZ	· J				AA
C590	VCKYCY1HF103			50V	Ceramic		0810	VCEAGAO BARROS	A 1			//431SM)	40
C621	VCEAEM1CW47					AA N AB	C819	VCEAGAOJW108N				-	AC
0021	VOEACIVITOVV4/	OWI J	47	16V	Electrolytic	AB	C820	VCKYD41HF104Z	J	U.1	50V C	eramic	AA

R	ef. No.	Part No.	*		Desci	ription	Code	Ref. No.	Part No.	*		Desc	ription	Code
		CAPACITO	RS	(Conti	inue	d)			RESISTO	RS (Conf	inued)	
	C821	VCKYCY1HF1032	z J	0.01	50V	Ceramic	AA	C2407	VCQYTA1HM56	3J J	0.05	6 50V	Mylar	AB
	C823	VCKYCY1HF1032	Z J	0.01	50V	Ceramic	AA	C2408	VCEAEM1HW1	05M J	1	50V	Electrolytic	: AB
	C824	VCEAEM1CW476	M J	47	16V	Electrolytic	AB	C4404	VCEAEM1CW4	76M J	47	16V	Electrolytic	: AB
	C825	VCKYCY1EF1042	z J	0.1	25V	Ceramic	AA	C5001	VCKYD41CY10	3N J	0.0	16V	Ceramic	AA
	C826	VCE9EM1HW105		1	50V	Elect.(N.P.)	AB	C5002	VCEAEM0JW47	76M J	47	6.3V	Electrolytic	: AB
	C829	VCKYCY1HF1032		0.01	50V	Ceramic	AA	C5003	VCKYCY1HF10	3Z J	0.0	50V	Ceramic	AA
	C830	VCKYCY1HB102		1000p		Ceramic	AA	C5004	VCKYCY1HF10	3Z J	0.0	50V	Ceramic	AA
	C831	VCKYCY1HB102		1000		Ceramic	AA	C5005	VCCCCY1HH4	70J J	47p	50V	Ceramic	AA
	C832	VCKYD41HB102l		1000p		Ceramic	AA	C5006	VCKYD41HB22	tK J	220	p 50V	Ceramic	AA
	C833	VCKYCY1HB102		1000p		Ceramic	AA	C5007	VCKYD41HB22	1K J	220	р 50V	Ceramic	AA
	C834	VCQYTA1HM473		•		Mylar	AA	C5008	VCKYD41HB22	1K J			Ceramic	AA
	0004	70Q117(111M-70				//M431SM)		C5009	VCKYD41HB22			•	Ceramic	AA
	C840	VCKYD41HF1042	Z J	0.1		Ceramic	AA	C5501	VCEAEMOJW4			6.3V		
Δ	C901	RC-FZ029CUMZZ				/ Mylar	AD	C5901	VCCCCY1HH3				Ceramic	AA
_		RC-KZ0310CEZZ				/ Ceramic	AC	C5902	VCCCCY1HH3				Ceramic	AA
\triangle	C905					/ Ceramic	AC	C5903	VCCCCY1HH4				Ceramic	AA
Ţ	C906	RC-KZ0310CEZZ						C5906	VCEAEM1HW1			50V	Electrolytic	
Ť	C907	RC-EZ0440GEZZ				/ Electorolyti	AD	C5900	VCCCCY1HH4				Ceramic	AA AA
$\overset{\diamond}{\nabla}$	C908	VCFYAA2GA333				/ Mylar			VOKYCY1EF10			25V	· ·	
Ň	C909	RC-KZ0112CEZZ		100p	1kV		AB	C5908					Ceramic	AA
Ą	C910	VCKYPA1HB472		4700p			· AA	C5909	VCCCCY1HH1				Ceramic	AA
Δ	C912	VCQYTA1HM273		0.027			AB	C5910	VCCCCY1HH8			50V	Ceramic	AA
Δ	C913	VCQYTA1HM333		0.033		Mylar	AA	C5911	VCEAEMOJW4				*	
Δ	C921	VCEAGA0JW107		100		Electrolytic		C5912	VCKYCY1HF10				Ceramic	AA
Δ	C922	VCEAGA1HW10	SM J	10 .	50V	•		C5913	VCKYCY1HF10				Ceramic	AA
Δ	C923	VCEAVA1VN477	M J			Electrolytic		C5914	VCEAEM1CW4			16V	Electrolytic	
Δ	C924	RC-QZ0104GEZZ	Z J	2200	250\	/ Mylar	AC	C5915	VCKYCY1HB2				Ceramic	
Δ	C925	VCEAVA1AN477	M J	470	:10V	Electrolytic	: AC	C5916	VCKYD41HB10)2K .	100	0p 50V	Ceramic	AA
Δ	C927	VCQYTA1HM103	J J	0.01	50V	Mylar	AA							
Δ	C928	VCEAGA1EW337	7M J	330	25V	Electrolytic	: AC					•		
Δ	C929	VCEAGA1AW33	7M J	330	10V	Electrolytic	AB	. 11	2					
Δ	C930	VCEAGA1HW47	6M J	47	50V	Electrolytic	AB		RI	ESIS	TOR:	3		
Δ	C931	VCEAEA1HW105	5M J	1	50V	Electrolytic	: AB	R212	VRS-CY1JF22	2J .	2.2	k 1/16\	V Metal Oxid	de AA
Δ	C932	VCKYCY1EF104	ΖJ	0.1	25V	Ceramic	AA	R213	VRS-CY1JF27	2J ,	J 2.7	k 1/16\	V Metal Oxid	de AA
Δ	C935	VCKYCY1EF104	Z J	0.1	25V	Ceramic	AA	R214	VRS-CY1JF10	3J ,	J 10	1/16\	W Metal Oxid	de AA
	C952	VCEAEM1HW10	5M J	1	50V	Electrolytic	: AB	R215	VRS-CY1JF39	2J .	J 3.9	k 1/16\	W Metal Oxid	de AA
	C957	VCEAEA1CW106	SM J	10	16V	Electrolytic	: AB	R217	VRS-CY1JF10	2J .	J 1k	1/16\	W Metal Oxid	de AA
	C958	VCEAEM1HW10	5M J	1	50V	Electrolytic	AB	R219	VRS-CY1JF12			k 1/16\	W Metal Oxid	
	C961	VCEAEM1CW10	6M J	10	16V	Electrolytic	: AB	R220	VRD-RA2BE15				Carbon	AA
	C989	VCKYCY1HF223	Z J	0.022	2 50V	Ceramic	AB	R228	VRS-CY1JF56				N Metal Oxid	
	C1551	VCKYCY1EF104	Z J	0.1	25V	Ceramic	AA						M/M231SM)	
	C1552	VCEAGA1CW10			16V	Electrolytic	AB	R228	VRS-CY1JF10	2.1	J 1k		N Metal Oxi	
	C1553	VCKYCY1HF103			50V	•	AA	TIZZO	VIID 01 101 10				M/M431SM)	
	C1554	VCKYCY1HF103			50V		AA	R229	VRS-CY1JF10	21	•		W Metal Oxid	
	C1555	VCEAGA1CW22			16V									
	C1556	VCKYCY1HF103			50V		AA	R230	VRS-CY1JF10				W Metal Oxid	
		VCEAEM1CW10			16V			R301	VRD-RA2BE68				Carbon	A.A
	C1557				50V		AA	R304	VRD-RA2BE68	32J			Carbon	A.A
	C1560	VCCCCY1HH47		,							•		M/M231SM)	
	C1561	VCEAEM1CW10			16V	•		R304	VRD-RA2BE1	53J			Carbon	A.A
	C2202	VCE9EM1HW33			50V						•		M/M431SM))
	C2401	VCKYCY1HF103			50V		AA	R305	VRD-RA2BE18	32J	J 1.8	k 1/8W	Carbon	A/
	C2402	VCEAEM1CW10	6M .		16V	•					(V	C-M23S	M/M231SM)	1
	C2403	VCKYCY1HF103	3Z .	0.01	50V	Ceramic	AA	R305	VRD-RA2BE3	32J	J 3.3	k 1/8W	/ Carbon	AA
	C2404	VCEAEM1HW10	5M .	J 1	50V		c AB				(V	C-M43S	M/M431SM))
	C2405	VCKYCY1HB102	2K .	1000	p 50V	Ceramic	AA	R306	VRD-RA2BE1	D3J	J 10	k 1/8W	/ Carbon	AA
	C2406	VCKYCY1HF223	37 .	0.02	2 50V	Ceramic	AB							

Ref. No.	a - Part No.	*		Description	Code ·	F	Ref. No.	Part No.	*		Description	Code
	RESISTOR	S (Cont	inued)		_		RESISTOR	S (Cont	inued)	
			(VC-	M23SM/M231SM)			R426	VRS-CY1JF822J	J	8.2k	1/16W Metal Oxi	de AA
R307	VRS-CY1JF473J	J.	47k	1/16W Metal Oxide	AA e		R427	VRS-CY1JF104J			1/16W Metal Oxi	
ÇH			(VC-	M43SM/M431SM)			R428	VRD-RA2BE471J		470	1/8W Carbon	AA
R308	VRD-RA2BE473J	J	47k	1/8W Carbon	AA		R429	VRS-CY1JF681J		680	1/16W Metal Oxi	
· .	:		"(VC-	M43SM/M431SM)			R431	VRS-CY1JF272J	Ĵ		1/16W Metal Oxi	
R309	VRS-CY1JF470J	J	47	1/16W Metal Oxide	AA e		R432	VRS-CY1JF103J	J		1/16W Metal Oxi	
•			(VC-	M43SM/M431SM)			R433	VRS-CY1JF103J	J		1/16W Metal Oxi	
R310	VRD-RA2BE470J	J		1/8W Carbon	AA		R434	VRS-CY1JF103J	J		1/16W Metal Oxi	
	•		(VC-	M43SM/M431SM)			R435	VRS-CY1JF272J	J		1/16W Metal Oxi	
R311	VRS-CY1JF332J	J	•	1/16W Metal Oxide	AA e		R436	VRS-CY1JF333J	J		1/16W Metal Oxi	
			4	M43SM/M431SM)			R437	VRS-CY1JF335J	J		1/16W Metal Oxi	
9 R312	VRS-CY1JF152J	J		1/16W Metal Oxide	AA e		R438	VRD-RA2BE335J	J		1/8W Carbon	AA
,Ta				M43SM/M431SM)			R439	VRD-RA2BE103J	J		1/8W Carbon	AA
R313	VRS-CY1JF102J	J	ik	1/16W Metal Oxide	AA e		R440	VRD-RA2BE335J	J		1/8W Carbon	AA '
:,.			(VC-	M43SM/M431SM)			R443	VRS-CY1JF473J	٦		1/16W Metal Oxi	
R314	VRS-CY1JF152J	. J	,	1/16W Metal Oxide	AA e		R444	VRS-CY1JF473J	J		1/16W Metal Oxi	
3.1				M43SM/M431SM)			R445	VRD-RA2BE103J	_		1/8W Carbon	AA
^ R315	VRS-CY1JF222J			1/16W Metal Oxide	. ΔΔ		R490	VRD-RA2BE821J	J		1/8W Carbon	··· AA
				M43SM/M431SM)			R501	VRS-CY1JF102J	J		1/16W Metal Oxi	71/1
R316	VRS-CY1JF103J	J.	. *	1/16W Metal Oxide	AA		R502	VRS-CY1JF821J	J.		1/16W Metal Oxi	
11010	***************************************	·		M43SM/M431SM)	, ,,,,		R506	VRS-CY1JF103J	J.		1/16W Metal Oxi	
R323	VRD-RA2BE103J	.1		1/8W Carbon	AA		R507	VRS-CY1JF103J	J		1/16W Metal Oxi	
11020	VIID THE DETOO	٠		M43SM/M431SM)	^^		R508	VRS-CY1JF103J	Ť.			
R326	VRS-CY1JF562J	1		1/16W Metal Oxide	AA		R510		J		1/16W Metal Oxi	
11020	V110-01 101 3020	Ü		M43SM/M431SM)	, 44			VRS-CY1JF273J	J		1/16W Metal Oxi	
R330	VRS-CY1JF103J	1	10k	1/16W Metal Oxide	AA		: R511	VRS-CY1JF272J	J		1/16W Metal Oxi	
R331	VRS-CY1JF102J	J		1/16W Metal Oxide			R513	VRD-RA2BE102J	J		1/8W Carbon	. AA
R332	VRS-CY1JF333J	J		1/16W Metal Oxide			R517	VRS-CY1JF392J	j		1/16W Metal Oxi	
R333	VRS-CY1JF333J	J		1/16W Metal Oxide			R520	VRD-RA2BE102J	J		1/8W Carbon	AA
R334	VRS-CY1JF152J	_		1/16W Metal Oxide			R523	VRD-RA2BE103J	J		1/8W Carbon	AA
R401	VRS-CY1JF272J						R524	VRD-RA2BE103J	J		1/8W Carbon	AA
		J		1/16W Metal Oxide			R540	VRS-CY1JF103J	J		1/16W Metal Oxi	
R402 R403	VRS-CY1JF821J	J		1/16W Metal Oxide			D004	VD0 0V4 IE400 I		•	M43SM/M431SM)	
	VRS-CY1JF273J	J		1/16W Metal Oxide			R601	VRS-CY1JF100J	J	10	1/16W Metal Oxi	
- R404	VRS-CY1JF103J	J		1/16W Metal Oxide			R631	VRS-CY1JF470J	J	47	1/16W Metal Oxi	
R405	VRS-CY1JF561J	J		1/16W Metal Oxide			R632	VRS-CY1JF682J			1/16W Metal Oxi	
R406	VRD-RA2BE331J	J		1/8W Garbon	AA		R633	VRG-SC2EB4R7J	J		1/4W Fuse Res	istor AB
R407	VRS-CY1JF182J			1/16W Metal Oxide			R635	VRD-RA2BE273J	J		1/8W Carbon	AA
R408	VRS-CY1JF152J			1/16W Metal Oxide			R643	VRS-CY1JF272J	J		1/16W Metal Oxi	
R409	VRS-CY1JF101J		100	1/16W Metal Oxide			R701	VRS-CY1JF272J	J		1/16W Metal Oxi	
R410	VRS-CY1JF472J			1/16W Metal Oxide			R705	VRS-CY1JF155J	J		1/16W Metal Oxi	
R411	VRS-CY1JF102J		1k	1/16W Metal Oxide			R707	VRS-CY1JF102J	J		1/16W Metal Oxi	de AA
R412	VRS-CY1JF821J		820	1/16W Metal Oxide			R708	VRD-RA2BE103J	J	10k	1/8W Carbon	AA
R413	VRD-RA2BE821J		820	1/8W Carbon	AA		R709	VRS-CY1JF103J	J	10k	1/16W Metal Oxi	de AA
R414	VRS-CY1JF273J			1/16W Metal Oxide			R710	VRS-CY1JF102J	J		1/16W Metal Oxi	
R415	VRS-CY1JF103J		-	1/16W Metal Oxide			R711	VRS-CY1JF102J	J	1k	1/16W Metal Oxi	de AA
R416	VRS-CY1JF472J			1/16W Metal Oxide			R713	VRD-RA2BE102J	J	1k	1/8W Carbon	AA
R417	VRS-CY1JF332J			1/16W Metal Oxide			R714	VRS-CY1JF562J	J	5.6k	1/16W Metal Oxi	de AA
R418	VRS-CY1JF222J	J	2.2k	1/16W Metal Oxide	AA		R715	VRS-CY1JF682J	J	6.8k	1/16W Metal Oxi	de AA
R419	VRS-CY1JF152J	J		1/16W Metal Oxide			R716	VRS-CY1JF393J	J	39k	1/16W Metal Oxi	de AA
R420	VRS-CY1JF562J	J	5.6k	1/16W Metal Oxide			R717	VRS-CY1JF183J	J	18k	1/16W Metal Oxi	de AA
R421	VRS-CY1JF102J	J		1/16W Metal Oxide			R718	VRS-CY1JF102J	J	1k	1/16W Metal Oxi	de AA
R422	VRS-CY1JF103J	J		1/16W Metal Oxide			R719	VRS-CY1JF823J	J	82k	1/16W Metal Oxi	de AA
R423	VRS-CY1JF392J	J	3.9k	1/16W Metal Oxide	AA		R720	VRS-CY1JF153J	J	15k	1/16W Metal Oxid	de AA
R424	VRS-CY1JF471J	J	470	1/16W Metal Oxide	AA		R723	VRS-CY1JF154J	J	150k	1/16W Metal Oxid	de AA
R425	VRS-CY1JF272J	J	2.7k	1/16W Metal Oxide	AA		R724	VRS-CY1JF154J	J	150k	1/16W Metal Oxid	de AA

Ref. No.	Part No.	*		Descri	ption	Co	de 	Re	f. No.	Part No.	*		Descri	ption Co	de
	RESISTOR	S (C	Conti	nued)						RESISTOR	S (C	Conti	nued)		
R725	VRS-CY1JF273J	J	27k	1/16W!	Metal O	xide	AA		R864	VRS-CY1JF154J	J	150k	1/16W	Metal Oxide	ΑA
R726	VRS-CY1JF564J	J	560k	1/16W	Metal O	xide	AA		R865	VRS-CY1JF102J	J	1k	1/16W	Metal Oxide	AΑ
R727	VRS-CY1JF272J	J	2.7k	1/16W	Metal C	xide	AA		R866	VRS-CY1JF471J	J	470	1/16W	Metal Oxide	ΑA
R728	VRS-CY1JF224J	J	220k	1/16W	Metal C	xide	AA		R867	VRS-CY1JF102J	J	1k	1/16W	Metal Oxide	AΑ
R729	VRS-CY1JF683J	J		1/16W			AA					(VC-	M43SM	/M431SM)	
R730	VRS-CY1JF334J	J		1/16W	Metal C	xide	AA		R891	VRS-CY1JF102J	J	1k	1/16W	Metal Oxide	ΑA
R731	VRS-CY1JF392J	J		1/16W			AA	\triangle	R901	VRD-RA2HD105J	J	1M	1/2W	Carbon	AA
R732	VRS-CY1JF473J		47k	1/16W			AA	\triangle	R902	VRC-UA2HG685K	J	6.8N	1/2W	Solid	AA
R733	VRS-CY1JF155J	_		1/16W			AA	$\overline{\Delta}$	R903	VRC-UA2HG685K	J	6.8N	1/2W	Solid	AA
	VRS-CY1JF223J		22k		Metal C		AA	Δ	R904	RR-WZ0003GEZZ		4.7	2W	Wire	ΑD
R734		_	10k		Metal C		AA	$\overline{\triangle}$	R905	RR-SZ0007GEZZ	J	68k	2W	Acid Metal	AE
R735	VRS-CY1JF103J				Metal C		AA	Δ	R906	VRD-RA2HD154J	J		1/2W	Carbon	AA
R736	VRS-CY1JF103J	J		.,				Δ	R907	VRD-RA2HD154J	J		1/2W	Carbon	A
R737	VRS-CY1JF103J	<u>ل</u>			Metal C		AA	\triangle	R908	VRS-VV3AB820J	J		1W	Metal Oxide	A/
R738	VRS-CY1JF223J	J			Metal C		AA			VRD-RA2EE821J	. J		1/4W	Carbon	A/
R739	VRS-CY1JF473J	J		-,	Metal C		AA	\triangle	R916		J	1	1/4W	Fuse Resisto	
R741	VRS-CY1JF563J	J	56k		Metal C		AA	\triangle	R921	VRG-SC2EB1R0J					A/
R742	VRS-CY1JF223J	J			Metal C		AA	\triangle	R922	VRD-RA2HD100J	J		1/2W	Carbon	
R743	VRS-CY1JF564J	· J	560k	1/16W	Metal C	Oxide	AA	\triangle	R924	VRG-SC2EB100J	J		1/4W	Fuse Resisto	
R746	VRS-CY1JF222J	J	2.2k	1/16W	Metal C	Oxide	AA	\triangle	R925	VRD-RA2BE221J	J		1/8W	Carbon	A
R748	VRD-RA2BE223J	J	22k	1/8W	Carbor	١.	AA	Δ	R926	VRS-CY1JF221J	J			Metal Oxide	A
R752	VRS-CY1JF471J	J	470	1/16W	Metal C	Oxide	AA	Δ	R927	VRD-RA2BE272J	J	2.7k		Carbon	A
R801	VRD-RA2BE102J	J	1k -	1/8W	Carbor	1:	AA	Δ	R928	VRS-CY1JF103J	J	10k	1/16W	Metal Oxide	A
R802	VRD-RA2BE102J	J	1k	1/8W	Carbor	1	AA	Δ	R929	VRS-CY1JF183J	J	18k	1/16W	Metal Oxide	A
R803	VRS-CY1JF471J	J	470	1/16W	Metal (Oxide	AA		R930	VRS-CY1JF392J	J	3.9k	1/16W	/ Metal Oxide	A
R804	VRS-CY1JF471J	J	470	1/16W	Metal (Oxide	AA	Δ	R931	VRS-CY1JF682J	J	6.8	1/16W	/ Metal Oxide	A
R805	VRS-CY1JF471J	J	470	1/16W	Metal (Oxide	AA	\triangle	R932	VRS-CY1JF221J	J	220	1/16V	/ Metal Oxide	A
R806	VRS-CY1JF471J	J			Metal (AA	\triangle	R933	VRD-RA2BE222J	ل	2.2	1/8W	Carbon	A
R807	VRS-CY1JF471J	J			Metal (AA		R952	VRD-RA2HD561J	J	560	1/2W	Carbon	A
R809	VRS-CY1JF471J	J			Metal		AA		R963	VRS-CY1JF330J	J	33	1/16V	Metal Oxide	A
		J			Metal	1	AA		R964	VRD-RA2HD392J	ا ا	3.9	1/2W	Carbon	A
. R811	VRS-CY1JF471J				Metal		AA		R965	VRS-CY1JF223J		22k		V Metal Oxide	A
R812	VRS-CY1JF471J	J					AA		R966	VRS-CY1JF103J	_	1 10k		V Metal Oxide	A
R813	VRS-CY1JF103J	J			/ Metal (R967	VRD-RA2BE183J				Carbon	Α
R814	VRS-CY1JF102J	J			Metal		AA			VRD-RA2HD561				Carbon	A
R815	VRS-CY1JF104J	J		< 1/16W			AA		R971					Carbon	
R821	VRS-CY1JF152J	-		1/16W	_		AA		R972	VRD-RA2BER56					A.
R822	VRD-RA2BE183J	J	1 18k				AA		R973	VRD-RA2BER56				Carbon	
R824	VRS-CY1JF103J	L	J 10k	1/16V	/ Metal	Oxide	AA		R976	VRD-RA2BE472J				Carbon	A
R825	VRS-CY1JF103J	·	J 10k	1/16W	/ Metal	Oxide	AA		R979	VRD-RA2EE561				Carbon	A
R826	VRS-CY1JF103J		J 10k	1/16	/ Metal	Oxide	AA		R980	VRS-CY1JF473J				V Metal Oxide	
R827	VRS-CY1JF103J	·) 10k	1/16	√ Metal	Oxide	AA		R981	VRS-CY1JF183J		J 18k		V Metal Oxide	
R831	VRD-RA2BE102	J,	J 1k	1/8W	Carbo	n	AA		R982	VRD-RA2EE391		J 390		Carbon	Α
R832	VRS-CY1JF102J		J 1k	1/16V	V Metal	Oxide	AA		R983	VRS-CY1JF183J	1.	J 184		W Metal Oxide	A
R840	VRG-SC2EB2R2	J.	3 2.2	1/4W	Fuse	Resisto	orAC		R989	VRD-RA2BE333	J	J 331	: 1/8W	Carbon	Α
R841	VRG-SC2EB1R0	J	J 1	1/4W	Fuse	Resisto	or AB		R1551	VRS-CY1JF224J		J 220	k 1/16	N Metal Oxide	A
R851	VRD-RA2EE151		J 150	1/4W	Carbo	n	AA		R1552	VRS-CY1JF474J		J 470	k 1/16	W Metal Oxide	F
R854			J 12k	1/8W	Carbo	n	AA		R1553	VRS-CY1JF101J		J 100	1/16	N Metal Oxide	F
R855			J 12k		Carbo	on	AA		R2401	VRS-CY1JF392J		J 3.9	k 1/16	N Metal Oxide	F
R856			J 10k		V Metal				R2402			J 680	1/16	N Metal Oxide	. A
		_	J 270		Carbo		AA		R2403					N Metal Oxide	
R857				k 1/16V					R2404					W Metal Oxide	
R858									R2405					W Metal Oxide	
R859				1/8W			AA							W Metal Oxide	
R860				k 1/16\					R2406					W Metal Oxide	
R861			J 1k		Carbo		AA		R2410						
R862	VRD-RA2BE154	J	J 150	k 1/8W			AA		R5001					/ Carbon	F
R863	VRD-RA2BE102	J	J 1k	1/8W	Carbo	on	AA		R5002	2 VRD-RA2EE3R3	S.J	J 3.3	1/41	/ Carbon	A

F	Ref. No.	Part Nö.	*	Description	Code	Ref. No.	Part No.	*	T Description	.ºCode
		RESISTOR	S ((Continued):			DUNTK	53	301TEV3	
	R5003	VRD-RA2BE393J	·	39k 1/8W Carbon	AA		(VC-M239	SM	I/M231SM)	250
	R5004	VRS-CY1JF123J	Ų	12k 1/16W Metal Oxide	e AA				301TEV5	git.
	- R5005	VRS-CY1JF472J	U	4.7k 1/16W Metal Oxide	a AA	÷ 7.				7
	R5006	VRS-CY1JF472J	J	4.7k 1/16W Metal Oxide	e AA	3.4	(VC-101435		I/M431SM)	145
	R5007	VRS-CY1JF472J		4.7k 1/16W Metal Oxide			TERM	N/	AL UNIT	
,	R5008	VRS-CY1JF472J		4.7k 1/16W Metal Oxide						
	R5010	VRS-CY1JF223J		22k 1/16W Metal Oxide			INTEGRA	ΓEΩ	CIRCUITS	
	R5501	VRD-RA2BE331J	J	330 1/8W Carbon	AA	IC601	VHiBA7795LS-1	J	i	AG
	R5901	VRD-RA2BE181J	J		AA	IC250	VHIBA7630F/1E	J	1	AM
	R5902	VRD-RA2BE181J	J		AA	IC6651			•	AK
	R5904	VRD-RA2BE102J	. J		AA					711
	R5910	VRD-RA2BE152J	J		AA				1.	
				HOR WOW GAIDON	77					
						to .	TRAN	SIS	STORS	120
		MISCELLAN	IE(DUS PARTS		Q601	VS2SC2412KQ-1	J	2SC2412KQ	AA
Δ		QACCV2007AJZZ	٧	AC Cord	AS	A Q606	VSDTC144ES/-1	J		: AB
	DG500	1 VVK10BT143G-1	J	Fluorescent Display Tub		AAQ2501	VS2SA1037KQ-1	J		AA
Δ	F901	QFS-C2026CEZZ	· J	Fuse, T2AH/250V	AE	44 Q2502		i.J		ABAMAA
	FB701	RBLN-0043CEZZ	J		AB	Q2503		J		AA
	FB801	RBLN-0013GEZZ	J	Balun	AB	Q6652		J		
	FB902	RBLN-0043CEZZ	J	Balun		Q6654	VS2SD1306-D1E	J		AC
		RBLN-0043CEZZ	J	Balun	AB	Q6655	VSDTC144EK/-1	J.		AB
Δ		QFSHD1013CEZZ	J		AB	Q8851	VSDTA144EK/-1	_		.≒ AB
_	FH902		_	Fuse Holder	AC	Q0051	VSD1A144EN-1	J	DTA144EK	AC
Δ		QFSHD1014CEZZ	J	Fuse Holder	AC		:			
	JA139	RBLN-0043CEZZ	J		AB					. 4
	JA191	RBLN-0043CEZZ	J	Balun	AB		D.			
	P301	QPLGZ0331GEZZ	J	Plug, 3pin	AB		الل	OD	ES	**
	P401	QPLGN0347REZZ	J	Plug, 3pin	AA	D2501	RH-EX0646GEZZ	J	Zener Diode	AA
	P601	QPLGN0247REZZ	J	Plug, 2pin	AA	D2502	RH-EX0646GEZZ	J	Zener Diode	AA
	P701	QPLGZ0631GEZZ	J	Plug, 6pin	AA	D2503	RH-EX0646GEZZ	J	Zener Diode	AA
	P702	QPLGN0247REZZ	J	Plug, 2pin	AA	D2602	RH-EX0646GEZZ	J	Zener Diode	AA
	P703	QPLGN0247REZZ	J	Plug, 2pin	AA	D2603	RH-EX0646GEZZ	J	Zener Diode	AA
	P704	QPLGZ0974GEZZ	J	Plug, 9pin	AD	D2604	RH-EX0646GEZZ	J	Zener Diode	AA
Δ	P901	QPLGN0269GEZZ	J	Plug, 2pin	AB	D8851	RH-EX0646GEZZ	J		AA
	P1551	QPLGN0447REZZ	·J	Plug, 4pin	AA					
	P4401	QPLGZ1431GEZZ	J	Plug, 14pin	AC	423				
	P4402	QPLGZ1431GEZZ	J	Plug, 14pin	AC					
	P5002	QPLGN0247REZZ	J	Plug, 2pin	AA		COILS AND T	RΑ	NSFORMERS	
				(VC-M43SM/M431SM)		L601	VP-YF822J0000			
	R50	RBLN-0043CEZZ	J	Balun	AB	L6604			8200µH	AC
	RMC5501	RRMCU0056GEZZ	J	Remote Receiver	AQ	1.0004	VP-XF3R9K0000	J	3.9µH	AB
	S851	QSW-F0042AJZZ	V	Switch	AG	1.0004	VD VEDDOVOGO		(VC-M23SM/M231S	-
	S5001	QSW-K0086GEZZ	J	Switch	AC	L6604	VP-XF2R2K0000	J	2.2µH	AB
	S5004	QSW-K0086GEZZ	J	Switch	AC		1 Im 1 Im 1		(VC-M43SM/M431S	M)
	S5005	QSW-K0086GEZZ	J	Switch	AC	L6605	VP-XF330K0000	J	33µН	AB
	SC301	QSOCN0494REZZ		Socket, 4pin	AC				(VC-M23SM/M231SI	M)
			,	(VC-M23SM/M231SM)	AU	L6605	VP-XF2R2K0000	J	2.2µH	AB
	SC301	QSOCN0799REZZ	J	Socket, 7pin	40				(VC-M43SM/M431SI	VI)
	50001	GOOGHO/ SSINEZZ	U	· ·	AC	L6606	VP-XF330K0000	J	33́µН	AB
٠.	SCS04		,	(VC-M43SM/M431SM)	. –				(VC-M23SM/M231SI	
٠.	SC601	QSOCN0684REZZ		Socket, 6pin	AB	L6606	VP-XF2R2K0000	J	2.2μΗ	АВ
	SC701	QSOCN0795REZZ	J	Socket, 7pin	AC	4. 4			(VC-M43SM/M431SI	
1						L6651	VP-XF3R3K0000	J	3.3µH	AB
	-			•		L6652	VP-XF3R3K0000		3.3µН	AB
٠.								-		: 10
				End of Main +						

Ref. No.	Part No.	*	E	escri	ption (Code	Re	f. No.	Part No.	*		Description (Code
	CAPACITORS	S (Conti	nued)				CAPACITOR	S (Conti	inued)	
L6653	VP-XF120K0000		12µH			AB		C6657	VCKYCY1CF334Z	J	0.33	16V Ceramic	AA
E0030	VI -XI IZONOOOO	·	•	23SM	/M231SM)			C6658	VCKYCY1HF103Z	J	0.01	50V Ceramic	AA
L6653	VP-XF2R2K0000	.1	2.2µH		,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	AB		C6659	VCEAEA1CW107N		100	16V Electrolytic	AC
20033	VI -XI ENERGOOD	Ŭ		43SM	/M431SM)			C6661	VCCCCY1HH100D) J	10p	50V Ceramic	AA
			(10 111	100111				C6662	VCCCCY1HH100E	J	10p	50V Ceramic	AA
C601	VCKYCY1HB152K	J.	1500p	50V	Ceramic	AA		C6663	VCCCCY1HH101J	J	100p	50V Ceramic	AA
C603	VCEAEM1HW335M		,		Electrolytic						(VC-N	//23SM/M231SM)	
C604	VCEAEA1CW106M				Electrolytic			C6663	VCCCCY1HH221J	J	220p	50V Ceramic	AA
C605	VCQYTA1HM123J	J	0.012		Mylar	AA					(VC-N	//43SM/M431SM)	
C606	VCKYCY1HB272K	J	2700p		Ceramic	AA		C8851	VCKYCY1HB102K	J	1000	50V Ceramic	AA
C607	VCEAEA1CW476M		47		Electrolytic								
	VCKYCY1CF224Z				Ceramic	AA							
C608	VCEAEA1CW226M	-	22		Electrolytic								
C610	VCEAEA1CW226M		10		Electrolytic				RES	ST	ORS		
C611	VCKYCY1EB153K				Ceramic	AA		DCOO	VRS-CY1JF333J	J		1/16W Metal Oxide	в АА
C612	VCKYCY1EB133K				Ceramic	AA		R602	VRS-CY1JF221J	J		1/16W Metal Oxide	
C613	VORTOTIEBZZON	J			/M431SM)	741		R603		J		1/16W Metal Oxide	
0014	VOCCOVILLIA I	J	,		Ceramic	AA		R604	VRS-CY1JF274J			1/16W Metal Oxide	
C614	VCCCCY1HH151J	J	•		Ceramic	AA		R605	VRS-CY1JF682J	J		1/16W Metal Oxid	
C615	VCCCCY1HH151J	-	•		Ceramic	AA		R606	VRS-CY1JF682J	J			e AA
C616	VCCCCY1HH331J	J		50V	Ceramic	AA		7000	VDO OVA IEROO I		•	M43SM/M431SM) 1/16W Metal Oxid	
C617	VCCCCY1HH220J	J	22p		Ceramic	AA	,	R609	VRS-CY1JF332J	J.		1/16W Metal Oxid	
C619	VCKYCY1HB102K		1000p	50V	Ceramic	AA		R610	VRS-CY1JF225J	J			
C620	VCKYD41HB820K	J	82p			AA	,	R612	VRS-CY1JF103J	J		1/16W Metal Oxid	
C626	VCKYCY1EF104Z	J	0.1	25V	Ceramic			R615	VRS-CY1JF563J	J		1/16W Metal Oxid	
C640	VCEAEA1HW105M		1	50V	Electrolytic	AC		R616	VRS-CY1JF153J	J		1/16W Metal Oxid	
C2501	VCKYCY1AF105Z	J	1	10V	Ceramic Ceramic	AC		R617	VRS-CY1JF152J	J		1/16W Metal Oxid	
C2502	VCKYCY1AF105Z	J	1	10V	-			R618	VRS-CY1JF183J	J		1/16W Metal Oxid	
C2503	VCEAEA0JW227M			6.3V	-			R619	VRS-CY1JF471J	J		1/16W Metal Oxid	
C2504	VCKYCY1HF103Z			50V	Ceramic	AA		R620	VRS-CY1JF102J	J	1k	1/16W Metal Oxid	e AA
C2508	VCKYCY1AF105Z	J		10V	Ceramic	AC		1				M43SM/M431SM)	
C2509	VCEA2A0JW477M			6.3V				R621	VRS-CY1JF683J	J		1/16W Metal Oxid	
C2511	VCCCCY1HH181J			50V	Ceramic	AA AB		R622	VRS-CY1JF683J	J		1/16W Metal Oxid	
C2512	VCEAEA1CW476N			16V	Electrolytic			R623	VRS-CY1JF333J	J		1/16W Metal Oxid	
C2513	VCKYCY1HF103Z			50V		AA		R624	VRS-CY1JF563J	J		1/16W Metal Oxid	
C2606	VCEAEM1HW335N			50V	•			R625	VRS-CY1JF103J		10k	1/16W Metal Oxid	
C2607	VCEA2A0JW477M				Electrolytic			R629	VRS-CY1JF153J	_	15k	1/16W Metal Oxid	
C2654	VCKYCY1HB102K					AA		R630	VRS-CY1JF103J		10k	1/16W Metal Oxid	
C6601	VCKYCY1HB561K	J				AA		R636	VRD-RA2BE103J			1/8W Carbon	AA
			,		и/M231SM)			R637	VRD-RA2BE103J			1/8W Carbon	AA
C6601	VCKYCY1HB391K	J				AA		R638	VRD-RA2BE562J			1/8W Carbon	AA
			,		и/M431SM)			R639	VRS-CY1JF153J			1/16W Metal Oxid	
C6602	VCCCCY1HH100E)]			Ceramic	AA		R2501	VRD-RA2EE121J		120	1/4W Carbon	AA
					и/M231SM)			R2502	VRD-RA2EE121J		120	1/4W Carbon	AA
C6602	VCCCCY1HH221J	J				AA		R2503	VRS-CY1JF101J		100	1/16W Metal Oxid	
			,		M/M431SM)			R2504	VRS-CY1JF101J		100	1/16W Metal Oxid	de AA
C6603	VCCCCY1HH100I) J			Ceramic	AA		R2505	VRD-RA2EE151	J,	J 150	1/4W Carbon	AA
			,		M/M231SM)			R2506	VRS-CY1JF750J	,	J 75	1/16W Metal Oxid	de AA
C6603	VCCCCY1HH221J	١,	220p	50V	Ceramic	AA		R2507	VRS-CY1JF101J		J 100	1/16W Metal Oxid	AA ek
			,		M/M431SM)	•		R2508	VRS-CY1JF750J		J 75	1/16W Metal Oxid	AA ab
C6651	VCEAEA1CW106	VI .	10	16V	Electrolyti			R2509	VRS-CY1JF472J	,	J 4.7k	1/16W Metal Oxid	de AA
C6652				16V	-			R2510	VRD-RA2BE821	J,	J 820	1/8W Carbon	AA
C6653	VCEAEA1CW476	VI.	J 47	16V	Electrolyti	ic AB		R2513	VRS-CY1JF223J	١,	J 22k	1/16W Metal Oxid	de AA
C6654				16V	Ceramic	AA		R2514	VRS-CY1JF223J	١,	J 22k	1/16W Meta! Oxid	de AA
C6655	VCKYCY1CF334Z		0.33	16V	Ceramic	AA		R2520	VRS-CY1JF223J		J 22k	1/16W Metal Oxid	de AA
C6656	VCKYCY1CF334Z		0.33	16V	Ceramic	AA	_						

Ref. No.	Part No.		Description Cod	le	Ref. No.	Part No.	*	Description C	Code
ME	CHANISM CH	1/	ASSIS PARTS		47	NPLYV0155GEZZ	J	Motor Pulley	AR
1417	O MICHALIO	•	100101711110		48	NPLYV0156GEZZ	J	Limitter Pulley Ass'y	AU
			Tausian Band Apply /	<u> </u>	49	NROLP0110GEZZ	J	Guide Roller	AH
1	LBNDK1009GEZZ		, ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	/C	50	NSFTP0034GEZZ	J	Tension Pole Adjuster	AA
2	LBOSZ1001GEZZ		• • • • • • • • • • • • • • • • • • • •	NR	51	PGUMM0043GEZZ	J	Damper Rubber	AB
3	2002:002		0.0., 2.0	AR	52	PREFL1007GEZZ	J	Light Guide	AR
4				AD AY	53	QCNW-0247AJZZ	V	FFC For Drum Motor	AG
5	201,011101001		,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	AT AR	54	QCNW-7501GEZZ	J	Lead Wire For Loading	AD
6			zoaamg more	۱M				Motor	
7	_,		And have a second		55	QCNW-0272AJZZ	V	FFC For Audio/Control	AF
8	LPOLM0057GEZZ		Take-Up Pole Base Ass'y A					Head	
9	MLEVF0459GEZZ	J		AS	56	QPWBF5243AJZZ	V	Audio/Control Head PW	/B AE
			Ass'y		57	QSOCN0685REZZ	J	Socket, 6 pin	AB
10	MLEVF0461GEZZ	J		AS	58	RHEDT0031GEZZ	J	Full Erase Head	AH
			Ass'y		59	RHEDU0085GEZZ	J	Audio/Control Head Ass	у ВА
11	MLEVF0463GEZZ	J	,	AS.	60	RMOTM1062GEZZ	. J	Loading Motor	AP
12	MLEVF0464GEZZ	J		ΑW	61	RMOTN2053GEZZ	J	Capstan Motor	BF
15	MLEVF0467GEZZ		,	AS	62	RMOTP1129GEZZ		Drum Drive Motor	AX
16	MLEVF0468GEFW	J	Audio/Control Head Arm		63	DDRMW0014TEV			BN
17	MLEVP0271GEZZ	J		AS	00	DDIMMAGOTTIEV	. •	Ass'y (VC-M23SM/M23	
18 Name	MLEVP0272GEZZ	J	Pinch Double Action Lever	AS	. 63	DDRMW0015TEV2	Ų		BQ
19	MLEVP0273GEZZ	J	Reverse Guide Lever	ΑT	64	MSPRC0194GEFJ		Drum Earth Brush Sprin	
			Ass'y		64			Drum Earth Brush	AD
20	MLEVP0275GEZZ	J	Reverse Drive Lever	AB	65	QBRSK0034GEZZ			
. 21	MLEVP0276GEZZ	J	Slow Brake	AS	66	XBPSD26P05J00	J		AA
22		J	Open Lever	AS				Mounting Screw	
23		J	•	AS		DO'DOOSEOFFIE		(SW2.6P+5S)	A1
24		J	Supply Main Brake Ass'y	AS	67	PGiDC0055GEFW	J	Drum Base	AL
25	MLEVP0280GEZZ	J	Take-up Main Brake Ass'y						
26		٧	Auto Head Cleaner Ass'y (VC-M43SM/M431SM)						
· 27	MSLiP0008GEZZ	.1	•	AS					
28	MSPRC0205AJFJ	_		AB					
29	MCDDD0165GEEL	.1		AR					
30	MSPRT0402GEFJ			AR					
30	WORTHOTOZOLIO	•	Spring						
31	MSPRT0403GEFJ	J		AR					
33	MSPRT0405GEFJ	٧	Tension Spring	ΑE					
34	NBLTK0066AJ00	٧		ΑE					
35	NDAiV1070GE00	J	Reel Disk	AS					
36	NGERH1267GEZZ			AS					
37	NGERH1268GE00		•	AS					
38	NGERH1269GEZZ			AS					
39	NGERH1270GEZZ	J	Take-Up Loading Gear	AS					
40	NGERH1271GEZZ			AS					
41	NGERH1272GEZZ			AS				•	
42	NGERH1275GEZZ			AS					
43	NGERH1276GEZZ								
44	NGERW1062GEZZ		· ·	AS					
45	NGERW1063GEZZ			AS					
46	NiDR-0015GEZZ	J		AS					
+0	MPILOUIOGEZZ	Ų		-	-	— End of Med	cha	nism Chassis Parts	s —

CASSETTE HOUSING CONTROL PARTS

- 5/1 1	300 range	CHLDX3074GE02	J Cassette Housing Control Ass'y	ΑZ
:.	301	LANGF9592GEFW	J Upper Plate	ΑT
	302	LHLDX1028GE00	J Frame (L)	AS
	303	LHLDX1029GE00	J Frame (R)	AS
tur.	304	LHLDX1030GEZZ	J Holder (L)	AR
	305	LHLDX1031GEZZ	J Holder (R)	AR
- ` `	306	MLEVF0469GEFW	J Proof Lever (R)	AS
	307	MLEVP0281GE00	J Door Open Lever	AS
	308	MSLIF0073GEFW	J Slider	AT
37	309	MSPRD0151GEFJ	J Proof Lever (R) Spring	AB
H	310	MSPRD0166GEFJ	J Drive Gear (R) Spring	AR
	311	MSPRP0159GEFJ	J Cassette Spring	AD
* 1 %	312	MSPRT0381GEFJ	J Double Action Spring	AB
175	313	NGERH1278GEZZ	J Drive Gear (L)	AS
<i>i</i>	314	NGERH1279GEZZ	J Drive Gear (R)	AS
WS.	315	NGERR1008GE00	J Double Action Rack Gear	AS
, Vi	316 M	NGERR3005GEFW	J Drive Angle Gear	AS
), ,	317	NSFTD0041GEFD	J Main Shaft	AF
	a symp	the state of the state of		,


SCREWS, NUTS AND WASHERS


	200	LX-XZ3030GEFD	J	Set Screw	AC
	201	LX-BZ3176GEZZ	J.	Tilt Adjusting Screw	AD
	202	LX-HZ3082GEZZ	J	Audio/Control Head Screi	wAD
	203	XHPSD26P07WS0	J	Screw, C2.6P+7S (For	AA
		•		Capstan Motor)	
110	204	XBPSD30P05J00	J	Screw, SW2.6P+5S (For	AA
:				Loading Motor)	
٠.	205	XHPSD26P06WS0	J	Screw, C2.6P+6S (For	AA
	.,			Loading Motor Block)	
	206	XHPSD26P08WS0	J	Screw, C2.6P+8S	AA
		4		.(For F/E Head)	
	207	XHPSD30P08WS0	J	Screw, C3.0P+8S	AA
,				(For Drum Base)	
M.	208	XRESJ40-06000	J	E-Ring, E-4	AA
٠,٠	209	XWHJZ52-05095	J.	Washer, W5.2-9.5-0.5	AD
ΞÄ	feral ,.	1 ² −4	Ĥg	(Reel Hight Adj.)	
27	210	XWHJZ52-03095	J.	Washer, W5.2-9.5-0.3	AD
	17	(*)		(Reel Hight Adj.)	
	211	XWHJZ52-04095	J	Washer, W5.2-9.5-0.4	AD
				(Reel Hight Adj.)	
	212	XWHJZ52-06095	J	Washer, W5.2-9.5-0.6	AD
			٠.	(Reel Hight Adj.)	
	213	XWHJZ52-07095	J	Washer, W5.2-9.5-0.7	AD
				(Reel Hight Adj.)	
	214	PSPAP0009GEZZ	J	Reverse Guide Adjusting	AA
٠				Nut	
	215	LX-WZ1003GE00	J	CUT Washer	AA
	216	LX-WZ1041GE00	J	CUT Washer	AA
	217	LX-WZ1073GE00	J	CUT Washer	AB
	218	XBPSD30P08J00	J	Drum Base Mounting	AA
				Screw (SW3P+8S)	


→ End₂of Cassette Housing Control Parts —


End of Screws, Nuts And Washers

ef. No.	Part No.	*	Description	Code	Ref. No.	Part No.	*	Description Co	ode
	MECHANI	CA	L PARTS		501-7	JBTN-2770UMSA		Button, Operate (VC-M231SM/M431SM)	AC
	MECHANI	J/1			501-8	JBTN-2742UMSA		Button, CH/REC	AC
004	GCABB1172UMZZ	-	Main Frame	AQ				(VC-M231SM/M431SM)	
601 603	GCABA3102UMSN			AU	501-8	JBTN-2717UMSA	U	Button, CH/REC (VC-M23SM/M43SM)	AC
603	GCABA3102UMSE	U	•	UA (N	501-9	JBTN-2771UMSA	U	Button, Set (VC-M231SM/M431SM)	AC
604	GBDYU3098UMFV	W 11		AH	501-10	MSPRD0103AJFJ	V	Cassette Spring	AB
604			Earth Angle(Conv.)	AB	502	JKNBK1092UMSA	U	Dial (VC-M23SM/M43SM)	AD (
605	LANGQ9063UMFV			AB	502	JKNBK1099UMSB	U	Dial	AD
606	PFLT-0016AJZZ	V	Foot Felt	AB				(VC-M231SM/M431SM)	
607	PSLDM4531UMFV	-	H/A Shield	AB	503	CBTN-2723TEV3	U	Button Ass'y (VC-M23SM) AK
608			Screw	AA	503	CBTN-2723TEV5	U	Button Ass'y (VC-M43SM) AL
609	XEBSD30P12000	J	Screw	AA	503	CBTN-2723TEV7	U	Button Ass'y	AL
611	XHPSD30P06WS0			AA				(VC-M231SM)	
612	XJPSD30P10WS0		Screw	AA	503	CBTN-2723TEV6	U	Button Ass'y	AL
613	LX-BZ3014GEFD	J			000	222.2.2.2	-	(VC-M431SM)	
616	PSPAZ0532AJZZ	V	•	AD	503-1	JBTN-2723UMSA	11	Button, Stop	ΑE
617	LX-HZ3030GEFF	J	-	AA	300-1	3D 114 E) E001010K	_	(VC-M23SM/M43SM)	
618			Antenna Terminal Cov		503-1	JBTN-2723UMSB	U	Button, Stop (VC-M231SM/M431SM)	ΑE
	En	d o	f Mechanical Part	s —		1111 074004111477	1.1		4.0
					503-2	LHLDZ1964UMZZ	U		AD
	EDONE D	A-IN III	CL DARTE		503-3	JBTN-2734UMSA	U		
	FRONT PA	/IVI	EL PARTS		503-3	JBTN-2734UMSB	Ų	Button, Play (VC-M43SM/M431SM)	AE
501	CPNLC2145TEV0	U	Front Panel Ass'y (VC-M23SM)	AX	503-3	JBTN-2734UMSC	U	Button, Play (VC-M231SM)	AE
501	CPNLC2147TEV0	U	Front Panel Ass'y (VC-M43SM)	AZ					
501	CPNLC2152TEV	υ	Front Panel Ass'y (VC-M231SM)	AY					
501	CPNLC2158TEV) U	Front Panel Ass'y (VC-M431SM)	AZ				·	
501-2	HBDGB1008AJS/	4 V	Padgo SHAPP						
			Dauge, SHARF	AE					
501-3	HDECQ1521UMS	SA U	Cassette Flap (VC-M23SM)	AE AF		En	d c	of Front Panel Parts	_
501-3 501-3	HDECQ1521UMS		Cassette Fiap (VC-M23SM)					of Front Panel Parts	
		SA U	Cassette Flap (VC-M23SM) Cassette Flap (VC-M43SM)	AF		SUPPLIED A	- /C	CESSORIES	
501-3	HDECQ1522UMS	SA U	Cassette Fiap (VC-M23SM) Cassette Flap (VC-M43SM) Cassette Flap (VC-M231SM)	AF		SUPPLIED A	AC ESC	CESSORIES	
501-3 501-3	HDECQ1522UMS	SA U	Cassette Fiap (VC-M23SM) Cassette Flap (VC-M43SM) Cassette Flap (VC-M231SM)	AF AF AG		SUPPLIED A	AC ESC	CESSORIES	
501-3 501-3	HDECQ1522UMS	SA U SB U	Cassette Flap (VC-M23SM) Cassette Flap (VC-M43SM) Cassette Flap (VC-M231SM) Cassette Flap (VC-M431SM) UCASSETTE Flap (VC-M431SM) UNINDOW DECORATION	AF AF AG AG AH		SUPPLIED A ACCI QCNW-7544UMZ	AC ESC	CESSORIES	Al
501-3 501-3 501-3	HDECQ1522UMS HDECQ1521UMS HDECQ1522UMS HDECQ1474UMS	SA U SB U SB U	Cassette Flap (VC-M23SM) Cassette Flap (VC-M43SM) Cassette Flap (VC-M231SM) Cassette Flap (VC-M431SM) Window Decoration (VC-M23SM/M43SM) Window Decoration	AF AF AG AG AH AH		SUPPLIED A ACCI QCNW-7544UMZ	ESC Z L	CESSORIES DRIES J 750hm Coaxial Cable J Infrared Remote Control	Al Al
501-3 501-3 501-3 501-4	HDECQ1522UMS HDECQ1521UMS HDECQ1522UMS HDECQ1474UMS HDECQ1499UMS	SA U SB U SB U	Cassette Flap (VC-M23SM) Cassette Flap (VC-M43SM) Cassette Flap (VC-M231SM) Cassette Flap (VC-M431SM) Cassette Flap (VC-M431SM) Window Decoration (VC-M23SM/M43SM) Window Decoration (VC-M231SM/M431SM) Foot Decoration(R)	AF AF AG AG AH AH		ACCI QCNW-7544UMZ RRMCG0159AJS	ESC Z L	CESSORIES DRIES J 750hm Coaxial Cable J Infrared Remote Control Unit J Battery Civer, Infrared	Al Al
501-3 501-3 501-4 501-4	HDECQ1522UMS HDECQ1521UMS HDECQ1522UMS HDECQ1474UMS HDECQ1499UMS	SA U SBB U SA U SBB U	Cassette Flap (VC-M23SM) Cassette Flap (VC-M43SM) Cassette Flap (VC-M231SM) Cassette Flap (VC-M431SM) Window Decoration (VC-M23SM/M43SM) Window Decoration (VC-M231SM/M431SM) Foot Decoration(R) (VC-M231SM)	AF AG AG AG AH AH SM)		ACCI QCNW-7544UMZ RRMCG0159AJS 93GHR14172001	ESC Z L A .	CESSORIES DRIES J 750hm Coaxial Cable J Infrared Remote Control Unit J Battery Civer, Infrared Remote Control Unit	Al Al
501-3 501-3 501-3 501-4 501-4	HDECQ1522UMS HDECQ1521UMS HDECQ1522UMS HDECQ1474UMS HDECQ1499UMS HDECQ1501UM	SA LUSSA LUS	Cassette Flap (VC-M23SM) Cassette Flap (VC-M43SM) Cassette Flap (VC-M231SM) Cassette Flap (VC-M431SM) Window Decoration (VC-M23SM/M43SM) Window Decoration (VC-M231SM/M431SM) Foot Decoration(R) (VC-M231SM) Foot Decoration(R) (VC-M431SM) Foot Decoration(R) (VC-M431SM)	AF AG AG AH AH SM) AB		ACCI QCNW-7544UMZ RRMCG0159AJS 93GHR14172001 CESORIES (NOT	ESC Z L A .	CESSORIES J 750hm Coaxial Cable J Infrared Remote Control Unit J Battery Civer, Infrared Remote Control Unit EPLACEMENT ITEM Operation Manual (VC-M23SM/M43SM)	AL AL
501-3 501-3 501-4 501-4 501-5	HDECQ1522UMS HDECQ1522UMS HDECQ1474UMS HDECQ1499UMS HDECQ1501UM HDECQ1501UM HDECQ1501UM	SA USSA USSA USSA USSA USSA USSA USSA U	Cassette Flap (VC-M23SM) Cassette Flap (VC-M43SM) Cassette Flap (VC-M231SM) Cassette Flap (VC-M431SM) Window Decoration (VC-M23SM/M43SM) Window Decoration (VC-M231SM/M431SM) Foot Decoration(R) (VC-M231SM) Foot Decoration(R) (VC-M431SM)	AF AF AG AG AH AH SM) AB AB		ACCI QCNW-7544UMZ RRMCG0159AJS 93GHR14172001 CESORIES (NOT TINS-2875UMZZ TINS-2876UMZZ	ESO Z U	CESSORIES DRIES J 750hm Coaxial Cable J Infrared Remote Control Unit J Battery Civer, Infrared Remote Control Unit EPLACEMENT ITEM Operation Manual	AL AL AL










PRECAUTION ON FRONT PANEL SET-UP VORSICHTSMASSNAHMEN BEIM MONTIEREN DER FRONTPLATTE

Before attaching the front panel in position, make sure that the cassette cover open lever is in its right place (lower-most). If it is out of position, push It down with a finger.

Vor dem Anbringen der Frontplatte dafür sorgen, daßsich der Öffnungshebel für das Kassettenfach in der korrekten Position (ganz unten) befindet. Ist dies nicht der Fall, den Hebel mit dem Finger herunterdrücken.




Keep the cassette over about 45° open and make sure that the cassette cover open lever is between the front panel and the cassette cover. Now fix the front panel in place.

Den Kassettenfachdeckel auf ca. 45° offen halten und darauf achten, daß sich der Öffnungshebel zwischen der Frontplatte und dem Kassettenfach-deckel befindet. Frontplatte befestigen.


Casselte cover open lever

Öffnungehebel Kassettenfach



Do not mount the front panel with the cassette cover tilted too open. Otherwise the cassette covermight wrongly run on the cassette housing.

Die Frontplatte nicht montieren, wenn der Kassetten-fachdeckel zu weit geöffnet ist. Ansonsten kann der Kas-settenfachdeckel durch Reibung am Kassettengehäuse beschädigt werden.




Removing the cassette compartment cover.

- Open the cassette compartment cover fully.
- ② Remove the center positioner.
- 3 Slide the cover to the right.
- Slightly bend the cover.
- ⑤ Draw out the left-side rod.

Kassettenfachabdeckung entfernen.

- Die Kassettenfachabdsckung vollständig öffnen.
 Das Positionierungsteil in der Mitte entfernen.
 Die Abdeckung nach rechts schieben.


- Die Abdeckung etwas biegen.
 Die Stange an der linken Selte herausziehen.



PRECAUTION ON FRONT PANEL SET-UP VORSICHTSMASSNAHMEN BEIM MONTIEREN DER FRONTPLATTE

Before attaching the front panel in position, make sure that the cassette cover open lever is in its right place (lower-most). If it is out of position, push it down with a finger.


Vor dem Anbringen der Frontplatte dafür sorgen, daß sich der Öffrungshebel für das Kassettenfach in der korrekten Position (ganz unten) befindet, ist dies nicht der Fäll, den Hebel mit dem Finger herunterdrücken. .




Keep the cassette over about 45° open and make sure that the cassette cover open lever is between the front panel and the cassette cover. Now fix the front panel in place. Den Kassettenfachdeckel auf ca. 45° offen halten und darauf achten, daß sich der Öffnungshebet zwischen der Frontplatte und dem Kassettenfach-deckel befindet. Frontplatte belestigen.

Cassetté cové

open lever Öffnungehebel



Do not mount the front panel with the cassette cover tilted too open. Otherwise the cassette covermight wrongly run on the cassette housing. Die Frontplatte nicht montieren, wenn der Kassetten-fachdeckel zu weit geöffnet ist. Ansonsten kann der Kassettenfachdeckeldurch Reibungam Kassettengehäuse beschädigt werden.



Removing the cassette compartment cover.

- Open the cassette compartment cover fully.
- Remove the center positioner.
 Slide the cover to the right.
 Slightly bend the cover.
 Draw out the left-side rod.


- Kassettenfachabdeckung entfernen.

 ① Die Kassettenfachabdeckung vollständig öffnen.
 ② Das Positionierungsteil in der Mitte entfernen.
 ③ Die Abdeckung nach rechts schieben.
 ④ Die Abdeckung etwas biegen.
 ⑤ Die Stange an der linken Seite herausziehen.

12. PACKING OF THE SET / VERPACKUNG DES GERÄTES

■ Setting position of the Knobs / Einstellposition der Knöpfe

RF conv. CH. preset	at "E36" channel	Test Signal Switch	at "OFF" position
HF-Wandler, Kanal vorprogrammiert	auf Kanal "E36"	Testsignalschalter	auf Position "OFF"



MARK ★ Not Replacement Item MARKIERUNG ★ Keine Ersatzteile

SHARP